

[Manuals.plus](#) /

› [ASHATA](#) /

› ASHATA 1080P 48MP Digital Camera Instruction Manual

ASHATA ASHATA95sf6h78q3-12

ASHATA 1080P 48MP Digital Camera Instruction Manual

INTRODUCTION

This manual provides comprehensive instructions for the ASHATA 1080P 48MP Digital Camera. It covers essential information regarding setup, operation, maintenance, and troubleshooting to ensure you can effectively use your device and capture high-quality photos and videos.

SAFETY INFORMATION

Please read and adhere to the following safety guidelines to prevent damage to the camera and ensure user safety:

- Do not expose the camera to water, moisture, or extreme temperatures.
- Use only the specified battery type: Lithium Ion Battery NP6L.
- Keep the camera and its accessories out of reach of small children.
- Do not attempt to disassemble, modify, or repair the camera yourself. Refer to qualified service personnel.
- Dispose of batteries and electronic components responsibly, following local regulations.

PACKAGE CONTENTS

Upon unpacking, please verify that all the following items are included in your package:

- 1 x ASHATA Digital Camera
- 1 x USB Type-C Charging Cable
- 1 x Wrist Strap
- 1 x Instruction Manual





The package includes the ASHATA digital camera, a USB charging cable, and a wrist strap for secure handling.

PRODUCT OVERVIEW

The ASHATA digital camera is a compact and user-friendly device designed for capturing high-resolution photos and 1080P videos. Familiarize yourself with its key components:



Front view of the camera, showing the lens, flash, and '4K' branding.

2.4 inch Ultra HD Screen Helps you take better photos.



Rear view of the camera, displaying the 2.4-inch screen and control buttons for navigation and operation.



Side view of the camera, highlighting the Type-C charging interface.

SETUP

1. Battery Installation and Charging

The camera operates using a Lithium Ion Battery NP6L. Ensure the battery is fully charged before initial use.

1. Locate the battery compartment on the camera.
2. Insert the NP6L battery, ensuring correct polarity as indicated.
3. Close the battery compartment cover securely.
4. Connect the camera to a power source using the provided USB Type-C charging cable. The charging indicator will illuminate.
5. Charging is complete when the indicator light changes or turns off.



With a USB charging cable, you can take photos while charging



Illustration showing the camera being charged via a USB-C cable. The battery is removable for convenience.

2. Memory Card Installation

The camera supports small memory cards up to 64GB (memory card not included).

1. Locate the memory card slot, typically adjacent to the battery compartment.
2. Insert the memory card with the gold contacts facing the correct direction until it clicks into place.
3. To remove the memory card, gently press it inward until it springs out, then pull it out.

OPERATING INSTRUCTIONS

1. Powering On/Off

To power on the camera, press and hold the power key for approximately 3 seconds. To power off, repeat the same action.

2. Taking Photos

1. Power on the camera.
2. Use the video key to navigate and select the photo mode.
3. Frame your desired shot using the 2.4-inch display.

4. Press the shutter key to capture the photo. The camera supports automatic focus.

3. Recording Videos

1. Power on the camera.
2. Use the video key to navigate and select the video recording mode.
3. Press the shutter key to begin recording.
4. Press the shutter key again to stop recording.


4. Zoom Function

The camera features 5x digital zoom. Utilize the 'W' (Wide) and 'T' (Telephoto) buttons located on the right side of the display screen to adjust the zoom ratio.

5. Menu and Settings

Press the menu key to access various camera settings and modes. You can adjust the following:

- **White Balance:** Options include Auto, Daylight, Cloudy, Tungsten Lamp, and Fluorescent Lamp.
- **Portrait Beauty:** Enhance portraits with beauty effects.
- **Filter Adjustment:** Apply various filters to your photos.
- **Time Lapse Photography:** Set up time-lapse sequences.
- **Soft Fill Light:** Adjust settings for the built-in fill light.
- **Menu Language:** Select from multiple language options.



The camera is suitable for various shooting scenarios, including continuous shooting, daily photography, and charging while in use.

MAINTENANCE

Proper care and maintenance will extend the life of your ASHATA digital camera:

- Clean the camera lens and screen with a soft, lint-free cloth specifically designed for optical surfaces.
- Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the camera's finish and components.
- Store the camera in a dry, cool place, away from direct sunlight and excessive humidity.
- If the camera will not be used for an extended period, remove the battery to prevent leakage.

TROUBLESHOOTING

If you encounter issues with your camera, refer to the following common problems and solutions:

Camera does not power on:

Ensure the battery is fully charged and correctly inserted into the battery compartment. Try charging the camera for at least 30 minutes.

Cannot take photos or record videos:

Check if a memory card is inserted and has sufficient free space. Ensure the correct mode (photo or video) is selected using the video key.

Images are blurry:

Ensure the camera lens is clean and free from smudges. Allow the autofocus mechanism to engage fully before pressing the shutter button. Check lighting conditions.

SPECIFICATIONS

Feature	Detail
Item Type	Digital camera
Material	ABS + Aluminum Alloy
File Format	JPG.AVI
Image Resolution	48M (Maximum)
Video Resolution	1080p (Maximum)
Focus Mode	Auto, Manual Focus
Aspect Ratio	16:9
Zoom Ratio	5x Digital Zoom
White Balance	Auto, Daylight, Cloudy, Tungsten Lamp, Fluorescent Lamp
Auto Focus	Supported
Battery Type	Lithium Ion Battery NP6L
Battery Capacity	600mAh
Storage Support	Supports up to 64G small memory card (Memory card not included)
Connection	Type-C
WiFi Connection	Not Supported
Fill Light	Supported
Hot Shoe Extension	Not Supported
Menu Language	Multi languages
Charging Interface	Type-C
Display Screen	2.4 inch 16:9 Screen
USB Support	2.0

Feature	Detail
Bottom Jack	1/4 inch Screw Hole
Model Name	ASHATA95sf6h78q3-12
Color	Silver Grey
Manufacturer	ASHATA

WARRANTY AND SUPPORT

This ASHATA digital camera comes with a manufacturer warranty for 90 days from the date of purchase. For warranty claims, technical support, or any inquiries regarding your product, please contact ASHATA customer service through the official channels provided at the point of purchase or on the manufacturer's website.