

Torchlet WL-S100

Torchlet WL-S100 Battery Operated Wall Sconces Instruction Manual

Model: WL-S100 | Brand: Torchlet

INTRODUCTION

Thank you for choosing the Torchlet WL-S100 Battery Operated Wall Sconces. This manual provides detailed instructions for the safe and efficient use of your new wall lights. Please read this manual thoroughly before installation and operation, and retain it for future reference.

WHAT'S IN THE BOX

Upon unpacking, please ensure all items listed below are present and undamaged:

- Wall Light Fixture (x2)
- Mounting Hardware (screws, expansion nails)
- Instruction Manual
- Remote Control
- USB Charging Cables (x2)





Image: Contents of the Torchlet Wall Sconces package.

PRODUCT FEATURES

- **Modern Design:** Sleek and minimalist, suitable for various decor styles.
- **Rotatable Light Bars:** Both ends of the light can rotate independently for customized lighting angles.
- **Easy Installation:** Wireless design eliminates the need for electrical wiring, making it renter-friendly.
- **Rechargeable Battery:** Equipped with a 12000mAh battery, rechargeable via USB-C port.
- **Adjustable Colors & Brightness:** Features 3 color temperatures (3000K, 4500K, 6500K) and 3 brightness levels (25%, 50%, 100%).
- **Remote Control & Timer:** Convenient remote for power, brightness, color adjustment, and timer settings (1H, 2H, 4H, 6H, 8H).
- **Versatile Use:** Ideal as picture lights, wall lights for living rooms, bedrooms, mirrors, or decorative accents.



DIY the Shape You Want




Image: The rotatable design allows for various lighting configurations.




Image: Highlighting the 12000mAh battery capacity and USB-C charging port.


INSTALLATION GUIDE

The Torchlet wall sconces are designed for easy, wireless installation. No electrical wiring is required.

1. **Marking Punch Points:** Choose your desired installation location. Use the mounting bracket as a template to mark the two drill points on the wall.
2. **Drill Holes:** Drill holes at the marked points.
3. **Install Expansion Nails:** Insert the provided expansion nails into the drilled holes.
4. **Install Iron Plate:** Align the iron mounting plate with the expansion nails and secure it to the wall using the provided screws.
5. **Hang the Sconce:** Carefully align the back of the sconce with the installed iron plate and slide it down to secure. Ensure the sconce is stable.

Note: You need to keep the two poles symmetrically during installation to ensure stability.

OURS



Easy to Install:
No additional wiring or electricians required

OTHERS



Image: Easy installation process, no additional wiring or electricians required.

Your browser does not support the video tag.

Video: Detailed installation steps for the Torchlet wall sconce.

Your browser does not support the video tag.

Video: Demonstrating the easy installation and adjustable features of the wall sconce.

OPERATING INSTRUCTIONS

Remote Control Functions:

The included remote control allows for convenient operation of your wall sconces. Ensure the remote is aimed at the infrared receiver on the light fixture (distance 3-5 meters).

- **ON/OFF:** Press the red ON/OFF button to power the lights on or off.
- **Brightness Adjustment:** Use the '+' and '-' buttons to increase or decrease brightness (25%, 50%, 100%).

- **Color Temperature:** Cycle through 3000K (Warm White), 4500K (Natural White), and 6500K (Cool White) using the dedicated buttons.
- **Timer Settings:** Set the lights to automatically turn off after 1H, 2H, 4H, 6H, or 8H using the timer buttons.



3 Color Temperatures & 3 Levels Brightness




Image: Demonstrating the 3 color temperatures and 3 brightness levels.




Image: The timing function ensures the lights turn off automatically.

CHARGING INSTRUCTIONS

Your Torchlet wall sconces are equipped with a 12000mAh rechargeable battery. To charge:

1. Gently remove the light fixture from its mounting plate.
2. Locate the USB-C charging port on the side of the fixture.
3. Connect the provided USB charging cable to the port and a suitable USB power adapter (not included).
4. The indicator light will show red while charging and turn green when fully charged.
5. **Important:** For the initial charge, allow at least 12 hours to fully activate the battery function.

A full charge provides approximately 30-50 hours of use, depending on brightness and color settings.

Your browser does not support the video tag.

Video: Demonstrating the charging process and battery life of the wall sconce.

MAINTENANCE

To ensure the longevity and optimal performance of your Torchlet wall sconces:

- Clean the surface with a soft, dry cloth. Avoid abrasive cleaners or solvents.
- Do not expose the lights to excessive moisture or direct water spray. They are not water resistant.
- Periodically check the mounting hardware to ensure it remains secure.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	Battery is depleted.	Charge the light using the provided USB cable.
Remote control not working.	Remote battery is dead or not aimed correctly.	Replace remote batteries. Ensure remote is aimed at the light's infrared receiver within 3-5 meters.
Light is unstable on the wall.	Improper installation of the light bars or mounting plate.	Ensure both light poles are symmetrically positioned and the mounting plate is securely fastened. Re-check installation steps.
Short battery life.	Frequent use at high brightness/cool white settings; initial charge not long enough.	Reduce brightness or use warmer color temperatures. Ensure initial charge is at least 12 hours.

SPECIFICATIONS

Feature	Detail
Brand	Torchlet
Model Name	WL-S100
Color	Black
Material	Glass, Metal
Product Dimensions	4"L x 6"W x 12"H (Base dimensions, light bar is 28.3 inches)
Power Source	Battery Powered (12000mAh Lithium Polymer)
Light Source Type	LED
Color Temperature	3000K-6500K (Warm White, Natural White, Cool White)
Brightness Levels	25%, 50%, 100%
Control Method	Remote Control
Timer Function	1H, 2H, 4H, 6H, 8H
Indoor/Outdoor Usage	Indoor Only

Feature	Detail
Item Weight	2 Pounds (per sconce)
Certification	ETL, UL Listed

28.3-Inch Scale Display



Image: Scale display of the 28.3-inch wall sconce.

WARRANTY AND SUPPORT

This product comes with a Limited Manufacturer Warranty. For any issues during installation or use, please contact Torchlet customer care service. We are committed to providing great lighting and support. Contact information can typically be found on the product packaging or the official Torchlet website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question