

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [MUSTAR](#) /

> [MUSTAR 88-Key Digital Piano Keyboard with Bench and 3 Pedals \(Model U6010402100/U6010402200\) - Instruction Manual](#)

MUSTAR U6010402100/U6010402200

MUSTAR 88-Key Digital Piano Keyboard Instruction Manual

Model: U6010402100/U6010402200

1. INTRODUCTION

Thank you for choosing the MUSTAR 88-Key Digital Piano Keyboard. This instrument is designed to provide a comprehensive and enjoyable musical experience for beginners and advanced players alike. It features semi-weighted keys, a versatile three-pedal unit, built-in speakers, and extensive connectivity options including USB/MIDI. This manual will guide you through the setup, operation, and maintenance of your new digital piano.

2. WHAT'S INCLUDED

Please verify that all items listed below are present in your package:

- MUSTAR 88-Key Digital Piano Keyboard
- Wooden Piano Bench with Storage
- Power Adapter
- Removable Music Stand
- Three-Pedal Unit
- Instruction Manual (this document)



Image: The complete MUSTAR 88-Key Digital Piano Keyboard set, including the piano, bench, and pedal unit.

3. SETUP

3.1 Assembling the Piano and Bench

Follow the assembly instructions provided in the separate assembly guide for the piano and bench. Ensure all components are securely fastened before use.

3.2 Connecting the Components

1. Connect the three-pedal unit to the 'Pedal Jack' on the piano's rear panel.
2. Plug the power adapter into the 'DC Power' input on the piano, then into a wall outlet.
3. Attach the removable music stand to the designated slot on the piano.

Guide To Linking Functions

- 1 Power Jack
- 2 Pedal Jack
- 3 Audio Out
- 4 Audio In
- 5 Headphone Jack
- 6 USB MIDI
- 7 MP3



Image: Rear panel connections including Power Jack, Pedal Jack, Audio Out, Audio In, Headphone Jack, USB MIDI, and MP3 input.

3.3 Bench Features

The included piano bench features a PU leather seat with high-density foam for comfort. Its sturdy wooden legs and non-slip rubber feet ensure stability. The seat also lifts to reveal a storage compartment for sheet music and accessories.

Simple & Elegant



Image: Dimensions of the MUSTAR digital piano and its accompanying bench, highlighting its compact and elegant design.

4. OPERATING INSTRUCTIONS

4.1 Basic Controls and Functions

The piano features an easy-to-operate control panel with an LED display and multifunction buttons. Use the volume control for comfortable listening levels.



Image: Overview of the piano's extensive sound capabilities, including tones, rhythms, demos, and polyphony.

4.3 Pedal System

The three-pedal system includes Sustain, Soft, and Sostenuto pedals, allowing for expressive playing. Refer to the assembly guide for proper connection.

Three-pedal System

Ensure you practice in all directions



Image: Illustration of the three-pedal system and its individual functions.

4.4 Touch-Sensitive Keys

The 88 semi-weighted, touch-sensitive keys respond to your playing dynamics, making it suitable for developing proper piano technique.

88 Key Fully Semi-Weighted Keyboard

Low-medium-high touch feel, very friendly for beginners



Image: Visual representation of the semi-weighted keys and their touch-sensitive response.

4.5 Connectivity

- **Headphone Jack:** Practice privately by plugging headphones into the 3.5mm jack. This automatically mutes the built-in speakers.
- **USB/MIDI:** Connect to mobile phones or computers for interactive learning and composition.
- **AUDIO INPUT:** Play external audio through the piano's speakers.
- **AUDIO OUTPUT:** Connect external speakers for enhanced sound projection.
- **Bluetooth:** Utilize wireless options for seamless connectivity with compatible devices.

4.6 Special Modes

- **Split Mode:** Divide the keyboard into two sections for dual-player performance or practicing different parts simultaneously.
- **Record/Playback:** Easily record, review, and refine your musical performances.



Image: Demonstrates the Split Keyboard feature, allowing two players to use the piano simultaneously.

4.7 Product Video Overview

Your browser does not support the video tag.

Video: An official product video from FlatsonsDirect (a seller of similar products) showcasing the features and performance of an 88-key fully weighted electric piano. This video provides a general overview of a high-performance digital piano.

5. SPECIFICATIONS

Feature	Detail
Brand	MUSTAR
Model Number	U6010402100/U6010402200
Number of Keys	88
Key Type	Semi-Weighted, Touch-Sensitive

Dimensions (Piano)	10.6"D x 50.8"W x 28.7"H
Item Weight	40 Pounds
Tones	800
Rhythms	600
Demo Songs	80
Pedals	3 (Sustain, Soft, Sostenuto)
Connectivity	USB/MIDI, Bluetooth, 3.5mm Headphone Jack, Audio In/Out
Speakers	Built-In
Power Source	Corded Electric
Bench Seat Material	PU Leather with 3cm high-density foam

6. MAINTENANCE

6.1 Cleaning

To clean the piano and bench, use a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water and a mild soap solution, then wipe dry immediately. Avoid abrasive cleaners, solvents, or waxes, as these can damage the finish.

6.2 Storage and Care

- Keep the piano away from direct sunlight, heat sources, and excessive humidity to prevent damage to the electronic components and wooden parts.
- Avoid placing heavy objects on the keyboard or control panel.
- When not in use, consider covering the keyboard to protect it from dust.

7. TROUBLESHOOTING

7.1 No Sound

- Ensure the power adapter is securely connected and the piano is turned on.
- Check the volume level. Increase it if necessary.
- If headphones are plugged in, unplug them to enable the built-in speakers.
- Verify that external speakers (if connected) are powered on and properly connected to the AUDIO OUTPUT.

7.2 Keys Not Responding

- Ensure the piano is powered on.
- Check if any specific mode (e.g., demo mode) is active that might prevent manual playing.
- If only certain keys are not responding, contact customer support.

7.3 Connectivity Issues (USB/MIDI/Bluetooth)


- For USB/MIDI, ensure the cable is correctly connected to both the piano and your device. Check device drivers if necessary.
- For Bluetooth, ensure the piano's Bluetooth function is enabled and your device is in pairing mode.
- Consult your device's manual for specific connection instructions.

8. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included in your product packaging or visit the official MUSTAR website. For technical support, troubleshooting assistance, or inquiries about replacement parts, please contact MUSTAR customer service through their official channels.

Manufacturer: MUSTAR

Related Documents - U6010402100/U6010402200

	<p>MK-809 61-Key Electronic Keyboard Owner's Manual Comprehensive owner's manual for the MUSTAR MK-809 61-Key Professional Electronic Keyboard, detailing its features, controls, operation, and performance functions.</p>
	<p>Arhiva Direcției Generale a Prețurilor: Documente privind Stabilirea Prețurilor (1944-1946) Acest document prezintă cuprinsul arhivelor Direcției Generale a Prețurilor din România, detaliind corespondența, deciziile și calculele financiare legate de stabilirea prețurilor pentru produse alimentare, agricole și industriale între anii 1944 și 1946.</p>