



[Manuals.plus](#) /

> [GXJ](#) /

> GXJ Brown Leather Office Chair (Model GXJ-OL8056-brown) Instruction Manual

## GXJ GXJ-OL8056-brown

# GXJ Brown Leather Office Chair (Model GXJ-OL8056-brown) Instruction Manual

Comprehensive guide for assembly, operation, and maintenance.

## INTRODUCTION

This instruction manual provides detailed guidance for the assembly, operation, and maintenance of your GXJ Brown Leather Office Chair, Model GXJ-OL8056-brown. Please read this manual thoroughly before assembly and use to ensure proper function, safety, and longevity of your product. Keep this manual for future reference.

## SAFETY INFORMATION

**Important:** Please read and follow all assembly instructions carefully. Do not exceed the maximum weight recommendation of 330 lbs. Use the adjustable height and tilting backrest features with caution to avoid injury.

- Ensure all screws and bolts are tightened securely before use.
- Do not stand on the chair.
- Avoid placing heavy objects on the chair's backrest or armrests.
- Keep children and pets away during assembly.
- Regularly check for loose parts and tighten as necessary.

## PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. The package should include:

- Backrest (1)
- Seat Cushion (1)
- Armrests (2)
- Five-star Base (1)

- Caster Wheels (5)
- Gas Lift Cylinder (1)
- Tilt Mechanism (1)
- Hardware Pack (screws, washers, Allen wrench)

## SETUP AND ASSEMBLY INSTRUCTIONS

---

Follow these steps to assemble your GXJ Brown Leather Office Chair. An assembly video is also provided for visual guidance.

Your browser does not support the video tag.

**Video:** Installation Guide of Stylish Office Chair. This video demonstrates the step-by-step assembly process for the GXJ office chair, including attaching the base, wheels, and seat components.

1. **Assemble the Five-Star Base:** Attach the five golden legs to the central hub of the base using the provided screws. Ensure they are securely fastened.
2. **Install Caster Wheels:** Insert the five caster wheels into the holes at the end of each leg on the assembled five-star base. Push firmly until they click into place.
3. **Insert Gas Lift Cylinder:** Place the gas lift cylinder vertically into the center hole of the five-star base.
4. **Attach Tilt Mechanism to Seat:** Secure the tilt mechanism to the underside of the seat cushion using the provided screws and washers. Ensure the front of the mechanism aligns with the front of the seat.
5. **Connect Backrest to Seat:** Align the backrest with the seat cushion and attach it using the designated screws.
6. **Install Armrests:** Attach the armrests to both sides of the seat and backrest assembly using the remaining screws. Ensure they are firmly secured.
7. **Connect Upper and Lower Parts:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring proper alignment. Press down firmly to secure.

# Dimensions



**Image:** Side and front view of the GXJ Brown Leather Office Chair with key dimensions labeled, including seat depth, width, and overall height range.

# Adjustable Angle 90°-120°

Height adjustable

Rocking adjustable



**Adjustable  
Design**

**Image:** Detailed view highlighting the high rebound memory foam in the seat and backrest, emphasizing optimal comfort for extended sitting.

## OPERATING INSTRUCTIONS

Your GXJ office chair offers several adjustable features for personalized comfort.

Your browser does not support the video tag.

**Video:** Comfy Desk Chair for Home Office. This video showcases the chair's features including height adjustment, 360-degree swivel, and rocking function, demonstrating its versatility for home and office use.

- **Height Adjustment:** Locate the lever on the right side beneath the seat. To raise the chair, lift the lever while standing. To lower the chair, lift the lever while seated. The seat height adjusts from 15.7" to 20".
- **Rocking Function (Tilt):** The chair features a rocking function from 90 to 120 degrees. Pull the same lever outwards to enable rocking. Push the lever inwards to lock the chair in an upright position.
- **360-Degree Swivel:** The chair's base allows for full 360-degree rotation, providing flexibility and ease of movement.
- **Non-Adjustable Armrests:** The armrests are fixed for stability and design.



**Image:** Close-up of the chair's adjustable mechanism, illustrating the lever for height and rocking angle adjustments (90-120 degrees).

## MAINTENANCE

---

Proper maintenance ensures the longevity and appearance of your GXJ office chair.

- **Cleaning:** For the leather upholstery, dry clean only. For general cleaning, wipe with a soft, damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically inspect all screws and bolts to ensure they remain tight. Re-tighten any loose fasteners to maintain stability and safety.
- **Caster Wheels:** Keep the caster wheels free of debris (hair, dust, etc.) to ensure smooth rolling. Clean them regularly with a damp cloth.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the leather to fade or crack. Position the chair away from direct sunlight when possible.

## TROUBLESHOOTING

---

If you encounter any issues with your chair, refer to the following common solutions:

| Problem                             | Possible Cause   | Solution  |
|-------------------------------------|--|---|
| Chair does not adjust height.       | Gas lift cylinder malfunction or lever not engaged properly. | Ensure the height adjustment lever is fully engaged. If the issue persists, the gas lift cylinder may need replacement. Contact customer support.                                   |
| Chair wobbles or feels unstable.    | Loose screws or improper assembly of the base.               | Check all screws connecting the base, seat, and backrest. Tighten any loose fasteners. Refer to assembly instructions.  |
| Caster wheels do not roll smoothly. | Debris caught in wheels or wheels not fully inserted.        | Remove any hair or debris from the wheels. Ensure each wheel is fully inserted into the base.   |
| Backrest does not recline or lock.  | Tilt mechanism lever not engaged or tension knob too tight.  | Pull the tilt lever outwards to enable rocking. Adjust the tension knob (usually a large round knob under the seat) to your preference. Ensure the lever is pushed inwards to lock. |

## SPECIFICATIONS

| Feature                        | Detail  |
|--------------------------------|---|
| Brand                          | GXJ   |
| Model Name                     | Brown Leather Office Chair  |
| Item Model Number              | GXJ-OL8056-brown  |
| Color                          | Brown   |
| Material                       | Leather (Upholstered), Memory Foam (Fill)   |
| Product Dimensions (D x W x H) | 17.3"D x 19.7"W x 40"H  |
| Seat Depth                     | 17.3 inches   |
| Adjustable Height Range        | 15.7" to 20" (seat height)  |
| Reclining Position Count       | 2 (90 to 120 degrees)   |
| Maximum Weight Recommendation  | 330 Pounds  |
| Special Features               | Adjustable Height, Ergonomic Design, Memory Foam Seat Cushion, Upholstered Leather Material, Swivel, Wheels |
| Product Care Instructions      | Dry Clean   |

| Feature     | Detail       |
|-------------|--------------|
| Item Weight | 35.4 pounds  |
| UPC         | 748327263530 |

## WARRANTY AND SUPPORT

---

For warranty information, technical support, or assistance with parts, please contact GXJ customer service directly. Refer to your purchase documentation for specific contact details or visit the official GXJ website.