

[Manuals.plus](#) /

> [JONR](#) /

> JONR ED12 Lite 3-in-1 Cordless Wet & Dry Stick Vacuum Cleaner User Manual

JONR ED12 Lite

JONR ED12 Lite 3-in-1 Cordless Wet & Dry Stick Vacuum Cleaner User Manual

Model: ED12 Lite

1. INTRODUCTION

This manual provides detailed instructions for the JONR ED12 Lite 3-in-1 Cordless Wet & Dry Stick Vacuum Cleaner. Please read this manual thoroughly before use to ensure proper operation, maintenance, and safety. Keep this manual for future reference.

2. PRODUCT OVERVIEW

The JONR ED12 Lite is a versatile 3-in-1 cordless stick vacuum cleaner designed for both wet and dry cleaning. It features powerful suction, automatic self-cleaning, and a lightweight, self-propelled design for efficient floor care.



Figure 2.1: JONR ED12 Lite 3-in-1 Cordless Wet & Dry Stick Vacuum Cleaner.

2.1 Key Features

- **3-in-1 Functionality:** Vacuums, washes, and dries floors simultaneously.
- **Powerful Suction:** 20000Pa for effective removal of various debris.

- **Automatic Self-Cleaning:** Roller brush self-cleans while docked.
- **Edge-to-Edge Cleaning:** Designed to clean close to walls and into crevices.
- **Lightweight & Self-Propelled:** Easy to maneuver with minimal effort.
- **Long Runtime:** Up to 45 minutes on a single charge (Auto mode).
- **Large Capacity Tanks:** Separate tanks for clean and dirty water.

2.2 Components



Figure 2.2: Overview of the JONR ED12 Lite and its key features compared to other cleaning types.

- Main Unit (Handle, Motor, Water Tanks)
- Floor Head with Roller Brush
- Charging Dock
- Power Adapter
- Cleaning Solution (included)

3. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Assemble:** Connect the handle to the main unit until it clicks into place.
3. **Charge:** Place the main unit on the charging dock. Ensure the power adapter is connected to the dock and a power outlet. The battery indicator lights will show charging status.
4. **Fill Clean Water Tank:** Remove the clean water tank (usually located at the top of the main unit). Fill it with clean water, and if desired, add a small amount of the provided cleaning solution. Do not overfill.

水だけのシンプルで、
床はいつもきれい



Figure 3.1: The clean water tank (850ml) and dirty water tank (450ml) are easily accessible for filling and emptying.

4. OPERATING INSTRUCTIONS

1. **Power On:** Press the power button on the handle to start the cleaner.
2. **Select Mode:** The cleaner typically starts in Auto mode. Press the mode switch button on the handle to toggle between 'Auto' and 'Powerful' modes as needed.
 - **Auto Mode:** Suitable for daily dust and light spills, operating quietly and efficiently.
 - **Powerful Mode:** Provides maximum suction (20000Pa) for stubborn dirt, heavy spills, or dried-on messes.
3. **Cleaning:** Gently push the cleaner forward. The self-propelled feature assists movement. The 6cm thick head and 150° flat mechanism allow cleaning under furniture and close to edges (up to 1mm).

2種類のモードで様々な状況に対応



Figure 4.1: The cleaner can operate in Auto mode for general cleaning or Powerful mode for tougher messes.

隅々まで逃さず掃除する設計




Figure 4.2: The slim design allows for effective cleaning along edges and in tight spaces.

Your browser does not support the video tag.

Video 4.1: Demonstration of the JONR ED12 Lite cleaning various wet and dry debris on a hard floor.

Your browser does not support the video tag.

Video 4.2: The JONR ED12 Lite effectively cleans dry debris and liquid spills, including spaghetti, from hard floors.

4. **Empty Dirty Water Tank:** When the dirty water tank is full, empty it and rinse thoroughly.
5. **Power Off:** Press the power button to turn off the cleaner.

5. MAINTENANCE

5.1 Automatic Self-Cleaning

1. After use, place the cleaner back on its charging dock.
2. Press the self-cleaning button on the handle. The roller brush will undergo a 40-second bi-directional wash cycle with high-speed water flow.

手放しでセルフクリーニング



Figure 5.1: The cleaner performs an automatic self-cleaning cycle when placed on the charging dock.

Your browser does not support the video tag.

Video 5.1: Demonstration of the self-cleaning function, showing the roller brush being cleaned automatically.

3. The system will then air dry the roller brush to prevent odors and mold.

5.2 Roller Brush Cleaning & Hair Tangle Prevention

The ED12 Lite features a real-time scraper and comb blade structure that automatically cuts and collects hair as the brush rotates, reducing tangles by 99%. This minimizes hair accumulation on the brush and prevents allergens from scattering.

毛の絡まりゼロ

ダブル櫛スクレーパーが、髪の毛を自動で梳きながら切断




Figure 5.2: The internal mechanism with a scraper and comb blade prevents hair from tangling around the roller brush.

Your browser does not support the video tag.

Video 5.2: Visual demonstration of the roller brush cleaning and hair removal process after use.

5.3 Filter Maintenance

Regularly check and clean the HEPA filter to maintain optimal suction performance. Rinse the filter with water and allow it to air dry completely before reinserting.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No Power	Battery drained, not charged properly.	Ensure the unit is correctly placed on the charging dock and connected to power. Allow sufficient charging time.

Problem	Possible Cause	Solution
Poor Suction	Dirty water tank full, clean water tank empty, clogged filter, tangled roller brush.	Empty dirty water tank. Refill clean water tank. Clean the HEPA filter. Check and clean the roller brush for tangles.
Streaks on Floor	Dirty roller brush, insufficient clean water, excessive cleaning solution.	Run self-cleaning cycle. Ensure clean water tank is filled. Use recommended amount of cleaning solution.
Unusual Noise	Obstruction in roller brush, motor issue.	Turn off and inspect the roller brush for any foreign objects. If the issue persists, contact customer support.

7. SPECIFICATIONS

- **Brand:** JONR
- **Model:** ED12 Lite
- **Suction Power:** 20000Pa
- **Battery Type:** Lithium Ion (2600mAh)
- **Max Runtime:** Up to 45 minutes (Auto mode), approx. 25 minutes (Powerful mode)
- **Clean Water Tank Capacity:** 850ml
- **Dirty Water Tank Capacity:** 450ml
- **Product Weight:** 3.4 kg (approx. 500g perceived weight with self-propulsion)
- **Package Dimensions:** 55.4 x 34 x 31 cm
- **Features:** Wet/Dry, Low Noise, Rechargeable, Self-Propelled, Lightweight, Edge Cleaning
- **Filter Type:** HEPA Filter
- **Recommended Use:** Various floor types (hard floors, carpets, tatami)

8. WARRANTY AND SUPPORT

The JONR ED12 Lite comes with a **2-year product warranty** covering initial defects and malfunctions. For any issues or inquiries, **24-hour online support** is available. Please refer to your purchase documentation for contact details or visit the official JONR website for support information.

