

## TIMU S11

# TIMU S11 Bluetooth Speaker with Light User Manual

Model: S11

## 1. INTRODUCTION

Thank you for purchasing the TIMU S11 Bluetooth Speaker with Light. This manual provides important information regarding the setup, operation, and maintenance of your device. Please read it carefully before use and retain it for future reference.

### Safety Information

- Do not expose the speaker to extreme temperatures or direct sunlight.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not disassemble or attempt to repair the speaker yourself.
- Keep the speaker away from water and other liquids, despite its waterproof rating, to prevent damage to charging ports or internal components.
- Use only the provided charging cable or a certified equivalent.

## 2. PACKAGE CONTENTS

Please check the package for the following items:

- TIMU S11 Bluetooth Speaker
- Power Cable
- User Manual (this document)

## 3. PRODUCT OVERVIEW

The TIMU S11 is a portable Bluetooth speaker featuring integrated lighting. It offers stereo and surround sound output with Bluetooth 5.4 connectivity.

### Controls and Indicators

(Note: Specific button layout and indicator descriptions are not available in the provided data. Please refer to the physical product for exact button locations and functions.)

- **Power Button:** Press and hold to turn on/off.
- **Bluetooth Pairing Button:** Initiates Bluetooth pairing mode.
- **Volume Up/Next Track:** Short press for volume up, long press for next track.
- **Volume Down/Previous Track:** Short press for volume down, long press for previous track.
- **Play/Pause Button:** Controls music playback and answers/ends calls.
- **Light Mode Button:** Cycles through different light modes.
- **Charging Port:** For connecting the power cable.
- **LED Indicator:** Shows power status, charging status, and Bluetooth connection status.

## 4. SETUP

### 4.1 Charging the Speaker

1. Connect the provided power cable to the charging port on the speaker.
2. Plug the other end of the cable into a suitable USB power adapter (not included) or a powered USB port.
3. The LED indicator will show the charging status (e.g., red for charging, off or green for fully charged).
4. Allow approximately 3-4 hours for a full charge before first use.

### 4.2 Bluetooth Pairing

1. Ensure the speaker is fully charged.
2. Press and hold the Power Button to turn on the speaker. The LED indicator will flash, indicating it's in pairing mode.
3. On your mobile device (smartphone, tablet, computer), enable Bluetooth.
4. Search for available Bluetooth devices. You should see "TIMU S11" in the list.
5. Select "TIMU S11" to connect. Once connected, the LED indicator will stop flashing and remain solid.
6. The speaker is now ready to play audio from your device.

## 5. OPERATING INSTRUCTIONS

### 5.1 Audio Playback

- **Play/Pause:** Press the Play/Pause button once to play or pause music.
- **Volume Control:** Short press the Volume Up or Volume Down buttons to adjust the volume.
- **Next/Previous Track:** Long press the Volume Up button for the next track, and long press the Volume Down button for the previous track.

### 5.2 Light Control

Press the Light Mode Button to cycle through various lighting effects. Continue pressing to find your preferred mode or to turn the lights off.

### 5.3 Hands-Free Calling

When connected to a smartphone via Bluetooth:

- **Answer Call:** Press the Play/Pause button once to answer an incoming call.
- **End Call:** Press the Play/Pause button once during a call to end it.
- **Reject Call:** Press and hold the Play/Pause button to reject an incoming call.

## 6. MAINTENANCE

### 6.1 Cleaning

- Ensure the speaker is turned off and disconnected from any power source before cleaning.
- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners, alcohol, or chemical solvents.
- Do not immerse the speaker in water.

### 6.2 Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery periodically (e.g., every 3 months) to maintain battery health.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on	Low battery	Charge the speaker fully.
Cannot pair via Bluetooth	Bluetooth not enabled on device; speaker not in pairing mode; too far from device	Ensure Bluetooth is on. Put speaker in pairing mode. Move device closer (within 50 feet). Clear previous Bluetooth connections on your device.
No sound	Volume too low; device not connected; incorrect audio source	Increase volume on both speaker and connected device. Re-pair Bluetooth. Check audio output settings on your device.
Lights not working	Light mode off; low battery	Press the Light Mode Button to cycle through modes. Charge the speaker.

## 8. SPECIFICATIONS

Feature	Specification
Model Name	S11
Brand	TIMU
Product Dimensions (L x W x H)	19 x 8 x 8 cm
Weight	760 grams
Connectivity Technology	Bluetooth 5.4
Wireless Communication Range	Up to 50 Feet (approx. 15 meters)
Speaker Size	60 Millimeters
Maximum Speaker Output Power	30 Watts
Audio Output Mode	Stereo, Surround
Surround Sound Channel Configuration	2.0
Speaker Type	3D
Power Source	Battery and Cable
Waterproof	Yes
Included Components	Power Cable
Color	Green

## 9. WARRANTY AND SUPPORT

TIMU products are designed and manufactured to the highest quality standards. This product is covered by a limited warranty against defects in materials and workmanship. Please refer to the warranty card included with your purchase or visit our official website for detailed warranty terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact TIMU customer service through the contact information provided on our official website or your purchase platform.