

[Manuals.plus](#) /

› [Think Tank](#) /

› Think Tank FocusPoint 22L RollTop Camera Backpack - Instruction Manual

Think Tank 720201

Think Tank FocusPoint 22L RollTop Camera Backpack

Model: 720201

Brand: Think Tank

INTRODUCTION

Thank you for choosing the Think Tank FocusPoint 22L RollTop Camera Backpack. This versatile bag is designed for photographers and travelers, offering quick access, expandable storage, and durable construction. It is crafted with sustainable, bluesign certified, recycled, and PFAS-free materials, ensuring eco-friendly durability. This manual provides essential information for setting up, operating, and maintaining your backpack.



Image: The Think Tank FocusPoint 22L RollTop Camera Backpack in Asphalt Black, showcasing its sleek design and roll-top closure.

SETUP

Internal Configuration

The main camera compartment features adjustable, closed-cell foam dividers. These can be customized to securely fit your camera body, lenses, and other accessories. The photo insert dimensions are 9.25" W x 9.5" H x 3.75" D (23.5 x 24.1 x 9.5 cm).



Image: The main compartment of the FocusPoint backpack with a camera body and multiple lenses organized by adjustable dividers.

Roll-Top Closure

The roll-top compartment expands to provide additional storage. Secure it by rolling the top down and fastening the quick-release parachute-style buckles. This ensures your belongings are protected and the bag maintains a compact profile when not fully loaded.



Image: A detailed view of the roll-top closure mechanism, highlighting the quick-release parachute-style buckle.

Shoulder and Waist Straps

Adjust the long shoulder straps and adjustable sternum strap for a comfortable fit. The breathable air mesh and cushioned foam back panel with an air channel enhance comfort during extended wear. The padded waist belt is removable for those who prefer to use only the shoulder straps.



Image: The back of the FocusPoint backpack, illustrating the padded shoulder straps, sternum strap, and breathable back panel.

Laptop Sleeve

A dedicated internal laptop sleeve is provided. It accommodates laptops up to 8.75" W x 13.5" H x 0.75" D (22.2 x 34.3 x 1.9 cm).

OPERATING

Quick Side Access

Access your camera quickly and conveniently through the side entry option. This allows you to retrieve your gear without fully removing the backpack.



Image: The side panel of the FocusPoint backpack unzipped, showing a camera body and lens ready for quick retrieval.

Rear Panel Access

For full access to your main camera compartment, utilize the rear panel entry. This allows you to lay the bag down and organize or retrieve all your gear efficiently.

INCLUDED PHOTO ACCESSORIES

- Photo insert
- Tripod attachment strap
- Removable waist belt



Image: The rear panel of the FocusPoint backpack fully unzipped, displaying the entire internal camera compartment with organized gear.

Accessory Pockets

The backpack features ten smartly designed pockets for organizing your gear and essentials. This includes a water bottle pocket, a hidden AirTag pocket, and a front storage pocket with internal organization for keys, wallet, and other small items.



Image: The front storage pocket of the backpack, open to show various compartments for organizing small personal items like keys and a wallet.

Luggage Pass-Through

For convenient travel, utilize the luggage handle pass-through on the back panel to secure the backpack to

your rolling luggage.

MAINTENANCE

Rain Cover

A seam-sealed rain cover is included to provide additional protection against heavy downpours. Store it in one of the external pockets for quick access.



Image: The included seam-sealed rain cover being pulled over the FocusPoint backpack for weather protection.

Cleaning

For general cleaning, wipe the exterior with a damp cloth and mild soap. Do not machine wash or tumble dry. Allow to air dry completely. The materials are treated with a DWR (Durable Water Repellent) coating for weather resistance.

TROUBLESHOOTING

Gear Not Fitting Properly

- **Adjust Dividers:** Reconfigure the internal closed-cell foam dividers to better accommodate your specific camera body and lenses.
- **Utilize Roll-Top:** For non-camera items or additional clothing, use the expandable roll-top compartment.

Discomfort During Wear

- **Adjust Straps:** Ensure shoulder straps and sternum strap are properly adjusted to distribute weight evenly.
- **Use Waist Belt:** If carrying heavier loads, attach and adjust the removable padded waist belt for added support and comfort.
- **Check Load Distribution:** Ensure heavier items are positioned closer to your back for better balance.

SPECIFICATIONS

- **External Dimensions:** 11.25" W x 16.5" H x 6" D (28.6 x 41.9 x 15.2 cm)
- **Photo Insert Dimensions:** 9.25" W x 9.5" H x 3.75" D (23.5 x 24.1 x 9.5 cm)
- **Laptop Sleeve Dimensions:** 8.75" W x 13.5" H x 0.75" D (22.2 x 34.3 x 1.9 cm)
- **Item Weight:** 3.53 lbs. (1.62 kg) / 1600 Grams
- **Volume:** 20.5 Liters expanded (with insert) / 22 Liters Total Capacity
- **Materials:** Sustainable, bluesign certified, recycled, and PFAS-free materials
- **Zippers:** YKK RC fuse zipper on main camera compartment

WARRANTY

Think Tank products are known for their quality and durability. For detailed warranty information regarding your FocusPoint 22L RollTop Camera Backpack, please refer to the official Think Tank website or contact their customer service directly.

SUPPORT

For further assistance, product registration, or to explore other Think Tank products, please visit the official Think Tank website:

[Visit the Think Tank Store on Amazon](#)

You can also find additional resources and contact information on their main website.

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video showcasing the features and functionality of the FocusPoint Rolltop Backpack Series by Think Tank Photo Inc. This video highlights various aspects of the backpack's design and use.

