

ScrubWiz KS-7880

ScrubWiz 10-in-1 Steam Cleaner and Mop (Model KS-7880) Instruction Manual

Your comprehensive guide to effective, chemical-free cleaning.

INTRODUCTION

Thank you for choosing the ScrubWiz 10-in-1 Steam Cleaner and Mop. This versatile appliance is designed to provide powerful, chemical-free cleaning for a wide range of surfaces in your home and beyond. Utilizing high-temperature steam, it effectively removes dirt, grime, and stains, ensuring a clean and hygienic environment for your family and pets. Please read this manual thoroughly before initial use to ensure safe and optimal operation.

SAFETY INSTRUCTIONS

- Always ensure the appliance is unplugged before filling or emptying the water tank, or when changing accessories.
- Do not direct steam at people, pets, or electrical appliances. Steam is extremely hot and can cause burns.
- Use only clean tap water in the water tank. Do not add cleaning solutions, perfumes, or other chemicals, as this can damage the appliance and void the warranty.
- Keep the appliance out of reach of children and pets.
- Never leave the steam cleaner unattended while it is powered on or producing steam.
- Ensure the safety lock is engaged when not actively using the steam trigger to prevent accidental steam release.
- Do not use on unsealed hardwood floors, unglazed ceramic tiles, or any surfaces that are sensitive to heat or moisture. Test on an inconspicuous area first.
- Regularly inspect the power cord for damage. Do not operate if the cord is damaged.

INCLUDED COMPONENTS

Your ScrubWiz 10-in-1 Steam Cleaner comes with a comprehensive kit of accessories to tackle various

cleaning tasks:

Your Complete Steam Cleaner Kit

1. Nylon Brush
2. Metal Brush
3. Scouring Pad Brush
4. Scraper Tool
5. Bent Nozzle
6. Flat Surface Tool
7. Long Nozzle
8. Window Cleaner with Squeegee
9. Mesh storage bag
10. Window Cleaner Cloth
11. Scrubby Mop Pad
12. Garment Cloth
13. Mop Head
14. Carpet Glider
15. Mop Extension Wand
16. Handheld steam cleaner



Image: Complete kit of the ScrubWiz 10-in-1 Steam Cleaner, showing the main unit, extension poles, mop head, carpet glider, various brushes, nozzles, scraper, window cleaner with squeegee, and storage bag.

1. Handheld Steam Cleaner Host (1)
2. Mop Extension Pole (3)
3. Mop Head (1)
4. Carpet Glider (1)
5. Washable Microfiber Pad (2)
6. Window Cleaner Cloth (1)
7. Garment Cloth (1)
8. Scouring Pad Brush (1)
9. Scraper Tool (1)
10. Nylon Brush (1)
11. Metal Brush (1)
12. Bent Nozzle (1)
13. Long Nozzle (1)

14. Window Cleaner with Squeegee (1)

15. Storage Bag (1)

ASSEMBLY

1. Filling the Water Tank:

- Ensure the steam cleaner is unplugged.
- Remove the water tank from the main unit by twisting it counter-clockwise and pulling it down.
- Open the rubber cap on the water tank.
- Fill the tank with clean tap water up to the "Max" line (320ml / 11oz). Do not overfill.
- Close the rubber cap securely.
- Align the triangle arrow on the water tank with the triangle arrow on the steam kettle and twist clockwise to tighten and secure it to the main unit.




Image: A hand filling the detachable 320ml water tank of the ScrubWiz steam cleaner with water.

2. Attaching Accessories:

- For handheld use, select the desired nozzle or brush (e.g., long nozzle, bent nozzle, nylon brush, metal brush, scraper tool, scouring pad brush, flat surface tool, window cleaner with squeegee).
- Insert the accessory into the steam outlet until it clicks into place. Ensure it is securely fastened.
- For steam mop use, connect the three extension poles together. Attach the mop head to the end of the last extension pole. Then, attach the main handheld unit to the top of the assembled extension poles. Secure a washable microfiber pad to the mop head. For carpet cleaning, attach the carpet glider over the mop head with the microfiber pad.

Adjustable-Length Handheld Steamer



Steam Mop

Steam Cleaner



Image: The ScrubWiz steam cleaner shown in two configurations: as a steam mop for floor cleaning and as a handheld steamer for stovetop cleaning.

OPERATION

1. Power On and Heating:

- Plug the power cord into a grounded electrical outlet.
- The red indicator light will illuminate, indicating the unit is heating.
- The steam cleaner heats up in approximately 10-15 seconds. The green indicator light will turn on when it's ready to produce steam.



Image: An illustration of the ScrubWiz steam cleaner highlighting its 10-second fast heating, 248°F steam temperature, 320ml water tank, and 99% stain removal capability.

2. Steam Activation:

- Press and hold the steam switch on the handle to release steam.
- For continuous steam, push the safety lock to the "Lock" position. This frees your hands for easier cleaning of larger areas or stubborn stains.
- To stop continuous steam, push the safety lock back to the "Unlock" position and release the steam switch.



Image: Close-up of the ScrubWiz steam cleaner's handle showing the safety lock mechanism for continuous steam operation.

3. Cleaning Various Surfaces:

- **Floors:** Use the steam mop configuration with a microfiber pad. Move the mop slowly over sealed hardwood, tile, and laminate floors.
- **Carpets:** Attach the carpet glider over the mop head with a microfiber pad. Glide over carpets to refresh and deodorize.
- **Kitchen Surfaces:** Use handheld with brushes or scraper tool to remove grease and grime from stovetops, countertops, and sinks.
- **Windows/Glass:** Attach the window cleaner with squeegee. Steam the surface and then use the squeegee for streak-free results.
- **Grout Lines:** Use the metal or nylon brush with the handheld unit to target stubborn dirt in grout.
- **Garments/Upholstery:** Use the garment cloth attachment to refresh fabrics and remove wrinkles.

Our



Free your hands

320ml large capacity detachable water tank

Add water at any time

Connectable extension poles

Others



Manual steaming

Non-detachable

Need to cool before adding water

Cannot be spliced

VS

Image: A collage showing the ScrubWiz steam cleaner being used for various tasks including cleaning a stovetop, bathroom sink, window, carpet, and garments.

Official Product Videos

Your browser does not support the video tag.

Video: An official product video demonstrating the ScrubWiz 10-in-1 Steam Mop Cleaner in action, showcasing its versatility across different cleaning scenarios.

Your browser does not support the video tag.

Video: An official product video highlighting the features and various uses of the ScrubWiz 10-in-1 Steam Cleaner.

MAINTENANCE

- **Emptying the Water Tank:** After each use, unplug the appliance and allow it to cool. Remove the water tank and empty any remaining water.
- **Cleaning Microfiber Pads:** The microfiber pads are washable and reusable. Remove them from the mop head and wash them by hand or machine wash with mild detergent. Air dry.
- **Cleaning Accessories:** Wipe down all accessories with a damp cloth after use. Ensure they are dry before storing.
- **Descaling:** If you notice reduced steam output or mineral buildup, descale the unit. Consult the full user manual for detailed descaling instructions.
- **Storage:** Store the steam cleaner and its accessories in a cool, dry place, preferably in the provided storage bag.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam output	Water tank empty; Not heated sufficiently; Steam switch not pressed.	Refill water tank; Wait for green indicator light; Press and hold steam switch.
Low steam pressure	Mineral buildup; Water tank low.	Perform descaling procedure; Refill water tank.
Water leaking	Water tank not securely attached; Accessory not properly installed.	Ensure water tank is tightened; Re-attach accessory until it clicks.

If you encounter any issues not listed here or if the problem persists, please contact ScrubWiz customer support for assistance.

SPECIFICATIONS

Brand: ScrubWiz

Model Name: KS-7880

Heat Time: 10 Seconds

Capacity: 320 Milliliters (11oz)

Item Weight: 2.39 Kilograms

Special Feature: 10-in-1, Detachable, 10s Fast Heating, 248°F Powerful Steam, Lightweight, Clear Indicator Lights, 13.12 FT Power Cord, Adjustable-Length

Surface Recommendation: Hardwood, Tile, Laminate Floors; Kitchen Surfaces; Windows; Grout Lines; Barbecue Grill; Shower Tracks; Toys; Clothes; Car Interiors

UPC: 784602510531

WARRANTY AND SUPPORT

ScrubWiz is committed to providing high-quality products and excellent customer service. For any questions, concerns, or warranty claims regarding your 10-in-1 Steam Cleaner, please refer to the contact information provided in your product packaging or visit the official ScrubWiz website. Our dedicated support team is available to assist you.

For additional protection, 2-Year and 3-Year Protection Plans are available for purchase. Please refer to your retailer for details.