ROCKPOINT HX2025-49

ROCKPOINT HX2025-49 70-inch Fireplace TV Stand Instruction Manual

Model: HX2025-49

1. Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Keep away from naked flame or direct heat sources.
- Ensure all components are securely fastened before use.
- Do not overload shelves or the top surface.
- Always unplug the electric fireplace before cleaning or maintenance.
- Do not block the air vents of the electric fireplace.

2. Product Overview

The ROCKPOINT HX2025-49 is a versatile 70-inch TV stand designed to accommodate televisions up to 80 inches, featuring an integrated 36-inch electric fireplace. This entertainment center combines functional storage with aesthetic appeal, offering a modern farmhouse style.

Key Features:

- **3-Sided Glass Display Fireplace:** Offers expansive views with dynamic 3D flame effects. Features 5 settings for flame brightness, 12 colors of backlight, and 12 LED colors for light strips. Controls are available via a digital LED display or remote control.
- **Powerful Customization:** Allows adjustment of LED strip placement. The heater includes heating tubes with temperature settings ranging from 60°F to 84°F (with an extra 99°F boost option). Timer settings (0.5H, 1H, 2H…9H) are available for energy efficiency.
- **Flexible & Spacious Storage:** Includes open shelving, hidden compartments, and two smooth-sliding drawers. Doors feature stops for stability. The 70-inch wide surface supports TVs up to 80 inches.
- **Quality Materials & Durability:** Constructed from modern MDF and premium PB, ensuring scratch-resistant, water-resistant, and odorless properties. A textured tabletop adds a sleek finish, and cable

management holes keep wires organized.

- **Convenient 2-Box Delivery:** The unit ships in two separate boxes, each with its own tracking number. If they do not arrive simultaneously, the second box is typically delivered within one day.



Image 1: The ROCKPOINT 70-inch Fireplace TV Stand in Espresso, showcasing its overall design and integrated fireplace.

3. Package Contents

Your ROCKPOINT Fireplace TV Stand is delivered in two separate packages. Please ensure you have received both boxes before beginning assembly.

- TV Stand Components (MDF and PB panels)
- 36-inch Electric Fireplace Insert
- Hardware Pack (screws, dowels, cam locks, etc.)
- Remote Control (requires 2 AAA batteries, included)
- Adjustable Glass Shelves (for cabinet sections)
- Instruction Manual




Image 2: Visual representation of the TV stand's dimensions and the two-box delivery method.

4. Assembly Instructions

Assembly is designed to be straightforward, with clear directions and all necessary hardware provided. It is recommended to have two people for assembly, which typically takes 45-60 minutes.

General Steps:

1. Unpack all components and verify against the parts list in the manual.
2. Assemble the main frame of the TV stand according to the step-by-step diagrams.
3. Install the drawers and cabinet doors, ensuring smooth operation.
4. Insert the adjustable glass shelves into the desired positions within the cabinets.
5. Carefully place the 36-inch electric fireplace insert into its designated opening.
6. Connect any necessary cables through the cable management holes.

Video 1: A user demonstrating the assembly and features of a similar ROCKPOINT TV stand, highlighting the ease of setup and storage options.

5. Operating Instructions (Electric Fireplace)

The integrated electric fireplace offers various customizable settings for ambiance and warmth.

Controls:

The fireplace can be operated using the touch screen controls on the unit or the included remote control.

- **Power Button:** Turns the fireplace on or off.
- **Flame Brightness:** Select from 5 settings to adjust the intensity of the flame effect.
- **Flame Colors:** Choose from 12 distinct flame colors to match your mood or decor.
- **Backlight/LED Colors:** Activate and select from 12 LED colors for the light strips within the cabinets.
- **Heater Function:** Turn the heater on/off. Adjust temperature settings between 60°F and 84°F. An additional 99°F boost option is available for rapid heating.
- **Timer Settings:** Set an automatic shut-off timer for 0.5, 1, 2, up to 9 hours to conserve energy.
- **Child Lock:** Engage the child lock feature to prevent accidental changes to settings.



Image 3: Detailed view of the fireplace's digital touch screen controls and the remote control for convenient operation.



Image 4: Visual demonstration of the 12 available flame colors and 5 levels of flame brightness.



Image 5: The TV stand with the multi-color LED light strips illuminated in different hues, showcasing customization options.

Video 2: An official product video from ROCKPOINT demonstrating the features and functionality of the 70-

inch TV stand with its 36-inch electric fireplace.

6. Maintenance

To maintain the appearance and longevity of your TV stand:

- **Cleaning:** Wipe with a dry cloth. For tougher spots, use a slightly damp cloth and dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Fireplace Care:** Ensure the fireplace is unplugged before cleaning. Gently wipe the glass and exterior surfaces with a soft, dry cloth. Do not spray liquids directly onto the unit.
- **General Care:** Periodically check all fasteners to ensure they remain tight.

7. Troubleshooting

Common Issues and Solutions:

- **Missing or Damaged Parts:** If any components are missing or damaged upon arrival, please contact ROCKPOINT customer support immediately for assistance.
- **Two-Box Delivery Not Arrived Together:** As the unit ships in two separate boxes, it is common for them to arrive on different days. Please allow an additional day for the second box to arrive before contacting support.
- **Fireplace Not Functioning:** Ensure the unit is properly plugged into a working electrical outlet. Check if the power button is pressed and if the remote control batteries (2 AAA) are correctly installed and charged.
- **Unstable Stand:** Verify that all screws and fasteners are tightened according to the assembly instructions. Ensure the stand is placed on a flat, level surface.

8. Specifications

Feature	Detail
Brand	ROCKPOINT
Model Number	HX2025-49
Product Dimensions (L x W x H)	70 x 17.1 x 32 inches
Item Weight	105 pounds
Material	Engineered Wood (MDF, PB)
Color	Espresso
TV Size Compatibility	Up to 80 inches
Fireplace Size	36 inches
Special Features	2 Drawers, 36 Inch Fireplace, Glass Door, Highboy TV Stand, LED Light

Feature	Detail
Product Care Instructions	Wipe with Dry Cloth
Batteries Required	2 AAA (included for remote)



Image 6: Detailed view of the TV stand's storage solutions, including easy-access drawers, adjustable shelves, and quality buffer hinges.



Image 7: An aerial view highlighting the spacious tabletop and media equipment area, along with key dimensions.

9. Warranty and Support

For any questions, concerns, or support regarding your ROCKPOINT HX2025-49 Fireplace TV Stand, please contact ROCKPOINT customer service. Refer to your purchase documentation for specific warranty details and contact information.

We are committed to providing attentive service and ensuring your satisfaction with our products.