

LYNCAST X1Pro

LYNCAST X1Pro Mini Projector User Manual

Model: X1Pro (Netflix N300)

1. INTRODUCTION

Thank you for purchasing the LYNCAST X1Pro Mini Projector. This manual provides essential information for the safe and efficient use of your projector. Please read it thoroughly before operation and retain it for future reference.

2. SAFETY INFORMATION

- Do not look directly into the projector lens when the lamp is on.
- Ensure proper ventilation to prevent overheating. Do not block ventilation openings.
- Use only the power adapter provided with the projector.
- Keep the projector away from water or other liquids.
- Avoid placing the projector on unstable surfaces.
- Clean the lens regularly with a soft, lint-free cloth.
- If not used for a long time, seal the projector to avoid dust accumulation.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- LYNCAST X1Pro Mini Projector
- Remote Control
- Power Adapter
- HDMI Cable
- User Manual

4. PRODUCT OVERVIEW

The LYNCAST X1Pro is a compact and portable mini projector designed for versatile entertainment and productivity. It features a 270° rotatable design, multiple connectivity options, and a built-in Android 13 operating system.

Portable & Perfect for Outdoor Movies

Mini / Lightweight / Easy To Carry



13.63*8.54*11.15cm



Weight:356.5g



Image: The LYNCAST X1Pro Mini Projector, demonstrating its portable and lightweight design, easily held in one hand. Dimensions are approximately 13.6cm L x 8.54cm W x 11.15cm H, weighing 356g.

4.1. Interfaces

The projector is equipped with the following ports:

- **HDMI Port:** For connecting external devices such as TV sticks, laptops, PCs, game consoles (e.g., PS5), and TV boxes.
- **USB Port:** For connecting USB flash drives or other compatible USB devices.

Multiple Interfaces

Compatible With Multiple Devices



Image: A visual representation of the LYNCAST X1Pro Mini Projector's multiple interfaces, highlighting the HDMI and USB ports and listing compatible devices for each.

5. SETUP

5.1. Initial Placement

Place the projector on a stable, flat surface or mount it on a tripod. The 270° rotatable design allows for flexible projection angles, including ceiling projection. Ensure there is adequate space around the projector for ventilation.

270° Rotatable Design

Lying down or sitting up can use it



Image: The LYNCAST X1Pro Mini Projector positioned to project an image onto a ceiling, illustrating its 270° rotatable design for flexible viewing positions.

5.2. Power Connection

1. Connect the power adapter to the projector's power input port.
2. Plug the power adapter into a wall outlet.
3. Press the power button on the projector or remote control to turn it on.

5.3. Network Connection (Wi-Fi)

The projector supports Wi-Fi 6 for fast and stable internet connectivity.

1. Navigate to the **Settings** menu on the projector.
2. Select **Network & Internet**.
3. Turn on Wi-Fi and select your desired network from the list.
4. Enter the password if prompted and connect.



Image: The LYNCAS T X1Pro Mini Projector demonstrating its Wi-Fi 6 connectivity, projecting content wirelessly from a smartphone.

5.4. Bluetooth Pairing

The projector features Bi-directional Bluetooth 5.4 for connecting external audio devices or using the projector as a Bluetooth speaker.

1. Go to **Settings** and select **Connected Devices**.
2. Turn on Bluetooth.
3. Select **Pair new device** and choose your Bluetooth speaker or headphones from the list.




Image: The LYNCAST X1Pro Mini Projector utilizing Bluetooth 5.4 to connect to an external speaker, enhancing the audio experience for projected content.

6. OPERATING INSTRUCTIONS

6.1. Basic Operation

- Use the provided remote control to navigate the user interface.
- The projector runs on Android 13 OS, providing access to various applications.

6.2. Smart Features and Streaming Apps

The LYNCAST X1Pro comes with built-in streaming applications and access to the Play Store for additional apps.

- Pre-installed apps include Netflix, Prime Video, YouTube, Hulu, Disney+, and Tubi.
- Access the Play Store to download more applications.

Compatible with Netflix

Netflix streaming membership required

NETFLIX

YouTube

prime video

CRaVE



Image: The LYNCAST X1Pro Mini Projector highlighting its compatibility with popular streaming services like Netflix, YouTube, Prime Video, and Crave.

6.3. Image Adjustment

- **Manual Focus:** Adjust the focus ring on the projector lens until the image is clear.
- **Auto Keystone Correction:** The projector automatically adjusts the image to correct trapezoidal distortion, ensuring a rectangular picture even when projected at an angle.

Enjoy 1080P 4K HD Clarity



1080P
4K Support



2000
Lumens



10000:1
Contrast

Image: A detailed projection of a parrot, illustrating the 1080P 4K HD clarity supported by the projector, along with its brightness and contrast specifications.

6.4. Installation Methods

The LYNCAST X1Pro supports various installation methods to suit your viewing environment.

- **Front Projection (Tabletop):** Place the projector on a table in front of the screen.
- **Rear Projection:** Place the projector behind a translucent screen.
- **Ceiling Projection:** Mount the projector upside down from the ceiling. The 270° rotatable design facilitates this.

Three Installation Methods



Image: A visual guide to the three primary installation methods for the LYNCAST X1Pro Mini Projector, including tabletop, outdoor, and ceiling setups, with corresponding projection distances and screen sizes.

7. MAINTENANCE

- **Lens Cleaning:** Gently wipe the projector lens with a soft, non-abrasive cloth. Avoid using harsh chemicals.
- **Dust Prevention:** When not in use for extended periods, store the projector in a dust-free environment or cover it to prevent dust accumulation.
- **Ventilation:** Ensure the ventilation ports are clear of obstructions to maintain optimal operating temperature.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No Power	Power cable not connected; Power outlet faulty.	Check power cable connection; Try a different outlet.
Blurry Image	Focus not adjusted; Projector too far/close.	Adjust the manual focus ring; Reposition the projector within optimal throw distance.
No Sound	Volume too low; External audio device not connected/paired.	Increase volume; Check Bluetooth connection or external speaker cable.
Cannot Connect to Wi-Fi	Incorrect password; Router issue; Out of range.	Verify password; Restart router; Move projector closer to router.
Image is Trapezoidal	Projector not perpendicular to screen.	Auto keystone correction should activate; if not, check settings for manual adjustment options.

9. SPECIFICATIONS

Model Name	X1Pro
Item Model Number	Netflix N300
Brand	LYNCAST
Native Resolution	1280 x 720 pixels
Display Resolution Maximum	3840 x 2160 pixels (4K Support)
Brightness	600 Lumen (400 ANSI Lumens)
Contrast Ratio	15000:1
Operating System	Android 13 OS
Connectivity Technology	Bluetooth 5.4, HDMI, USB, Wi-Fi 6
Light Source Operating Life	50000 Hours
Maximum Image Size	100 Inches
Minimum Image Size	40 Inches
Maximum Throw Distance	3 Meters
Minimum Throw Distance	0.6 Meters
Product Dimensions (L x W x H)	13.6 x 8.5 x 11 cm
Item Weight	356 Grams
Special Features	Compatible with Netflix, Built-in Stream Apps Officially Licensed, Auto Keystone, Built-In Stereo Speakers, Portable Mini Size, 270° Rotatable Design
Chip	T950D4

10. WARRANTY AND SUPPORT

10.1. Warranty Information

The LYNCAST X1Pro Mini Projector comes with a**2-Year Warranty** and a **1-Year Free Replacement** policy. Please retain your proof of purchase for warranty claims.

10.2. Manufacturer Contact

For technical support or warranty inquiries, please contact LYNCAST INC.
Contact details (e.g., email, website) would typically be provided here by the manufacturer.

© 2024 LYNCAST. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question