

[Manuals.plus](#) /

› [Lawyette](#) /

› Lawyette 18-Inch Modern Exterior Dusk to Dawn Outdoor Wall Sconce with Rippled Glass (Model XG7062O-1BK)

Lawyette XG7062O-1BK

Lawyette 18-Inch Modern Exterior Dusk to Dawn Outdoor Wall Sconce

Model: XG7062O-1BK

Brand: Lawyette

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Lawyette 18-inch Modern Exterior Dusk to Dawn Outdoor Wall Sconce. This fixture is designed to enhance your outdoor space with its contemporary aesthetic and functional features. It includes a built-in IC sensor for automatic dusk-to-dawn operation and features durable, weather-resistant construction with a unique water ripple glass design.



Figure 1: Lawyettle 18-inch Modern Exterior Outdoor Wall Sconce

2. SAFETY INFORMATION

Please read all instructions carefully before installation and use. Retain this manual for future reference.

- **WARNING:** Risk of electric shock. Turn off power at the circuit breaker or fuse box before installation or servicing.
- All wiring connections must be in accordance with local and national electrical codes. If you are unfamiliar with proper electrical wiring connections, consult a qualified electrician.
- Ensure the fixture is securely mounted to a structural element of the building.
- Do not exceed the maximum wattage specified for the bulb (60W for E26 base).
- Wear safety glasses and gloves during installation.

3. WHAT'S IN THE BOX

Verify that all components are present and undamaged before proceeding with installation.

- Outdoor Wall Sconce Fixture
- T300 LED Bulb (E26 base, 8W, 3000K)
- Mounting Hardware (screws, wire nuts)
- Instruction Manual
- Removable Sensor Cap (for manual operation)

T300 LED Bulb Included

- Wattage: 8W
- Color Temperature: 3000K
- Bulb Base: E26



All E26 Bulbs are Suitable (60W MAX)



Figure 2: Included T300 LED Bulb (8W, 3000K, E26 Base)

4. SPECIFICATIONS

Feature	Specification
Brand	Lawyettle
Model Name	XG7062O-1BK

Color	Black
Material	Metal, Clear Hammered Texture Glass
Product Dimensions	6.73"L x 6.14"W x 18"H
Item Weight	9.79 Pounds
Power Source	Corded Electric
Voltage	110 Volts
Wattage (Max)	60 watts (for E26 base)
Light Source Type	T300 LED (Included)
Bulb Base	E26 Medium
Color Temperature	3000 Kelvin (Warm White)
Brightness	800 Lumen
Special Features	Anti-Rust, Energy Efficient, Waterproof, Dusk to Dawn Sensor
Indoor/Outdoor Usage	Outdoor

E26 bulb included



110V



8W



3000K





Figure 3: Product Dimensions and Bulb Information

5. SETUP AND INSTALLATION

Follow these steps for proper installation. It is recommended to have a qualified electrician perform the installation if you are not experienced with electrical wiring.

1. **Prepare for Installation:** Turn off power at the main circuit breaker before starting any electrical work.
2. **Remove Mounting Bracket:** Unscrew the small screws at the bottom of the fixture to detach the mounting bracket from the lamp body.
3. **Install Mounting Bracket:** Secure the mounting bracket to the wall using the provided screws. Ensure it is firmly attached to a junction box or structural support.
4. **Connect Wiring:** Connect the fixture's wires to your household wiring. Typically, connect black to black (live), white to white (neutral), and copper/green to copper/green (ground) using the provided wire nuts. Ensure all connections are secure.
5. **Attach Fixture to Bracket:** Carefully align the lamp body with the mounted bracket and secure it using the screws

removed in step 2.

6. **Install Bulb:** Screw the provided T300 LED bulb into the E26 socket at the bottom of the fixture. Do not overtighten.
7. **Insert Glass Panel:** Carefully slide the water-patterned glass panel into the lamp body from bottom to top until it is securely seated.
8. **Restore Power:** Once installation is complete and all components are secure, restore power at the circuit breaker.

Your browser does not support the video tag. Please download the video to view it.

Video 1: Easy Installation Guide for Lawyettle Outdoor Wall Lights. This video demonstrates the step-by-step process of mounting the fixture, connecting wires, and assembling the light.

Your browser does not support the video tag. Please download the video to view it.

Video 2: Unboxing and Assembly of the 18-inch Modern Exterior Lighting Fixture. This video provides a closer look at the components and initial assembly steps.

6. OPERATING INSTRUCTIONS

Your Lawyettle outdoor wall sconce features a built-in dusk-to-dawn sensor for automated operation.

- **Automatic Mode:** The integrated IC sensor will automatically detect ambient light levels. The light will turn on at dusk and turn off at dawn, providing energy-efficient illumination without manual intervention.
- **Manual Override:** If you prefer to operate the light manually (e.g., keep it off during dusk or on during dawn), you can cover the sensor located at the top of the fixture with the provided removable cap. Removing the cap will reactivate the automatic dusk-to-dawn function.

Dusk to Dawn Outdoor Lighting




Figure 4: Dusk to Dawn Sensor Operation

Your browser does not support the video tag. Please download the video to view it.

Video 3: Demonstration of the Dusk to Dawn Outdoor Lighting feature with rippled glass. This video highlights the automatic on/off functionality.

7. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your outdoor wall sconce.

- **Cleaning:** To clean the fixture, ensure power is off. Wipe with a soft, damp cloth. Avoid abrasive cleaners or solvents that may damage the finish or glass.
- **Bulb Replacement:** The open-bottom design allows for easy bulb replacement. Ensure power is off before replacing the bulb. Use an E26 base bulb, not exceeding 60W.
- **Sensor Maintenance:** Keep the dusk-to-dawn sensor free from dirt, debris, or obstructions to ensure proper automatic operation.
- **Weather Resistance:** The fixture is designed to be waterproof and rust-proof. Periodically inspect for any signs of wear or damage to maintain its weather-resistant properties.



Figure 5: Weather Resistance Features (Waterproof, Stormproof, Snow-Resistant, Heat-Resistant)

8. TROUBLESHOOTING

If you encounter issues with your outdoor wall sconce, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on at dusk.	1. Power is off. 2. Bulb is faulty. 3. Sensor is covered or obstructed. 4. Wiring connection is loose.	1. Check circuit breaker/fuse. 2. Replace bulb. 3. Ensure sensor is clear and not covered by the cap. 4. Inspect and secure wiring connections (with power off).

Light does not turn off at dawn.	1. Sensor is obstructed or dirty. 2. Sensor cap is installed.	1. Clean the sensor and ensure no objects are blocking it. 2. Remove the sensor cap if automatic operation is desired.
Light flickers or is dim.	1. Loose bulb. 2. Incorrect bulb wattage. 3. Faulty bulb.	1. Tighten bulb. 2. Ensure bulb wattage is within specified limits (max 60W). 3. Replace bulb.

9. WARRANTY AND SUPPORT

This Lawyettle product comes with a limited warranty. For specific warranty details, please refer to the documentation included with your purchase or contact Lawyettle customer support.

For further assistance, product information, or to explore other Lawyettle products, please visit the official Lawyettle Store: [Lawyettle Store on Amazon](#).

© 2025 Lawyettle. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question