Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ROCKPOINT Fireplace TV Stand 70inch

ROCKPOINT 3 Sided Glass 70" Fireplace TV Stand User Manual

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your ROCKPOINT 3 Sided Glass 70" Fireplace TV Stand. Please read all instructions carefully before use to ensure safe and efficient operation.

Safety Information

- Keep away from naked flame or direct heat sources.
- Ensure the product is assembled on a flat, stable surface to prevent tipping.
- Do not overload shelves or the top surface beyond the specified weight capacity.
- For the electric fireplace, ensure proper ventilation and do not block air vents.
- Always unplug the electric fireplace before cleaning or maintenance.

Package Contents

Your ROCKPOINT Fireplace TV Stand package includes the following components:

- Fireplace Heater
- Hardware (screws, connectors, etc.)
- TV Stand Cabinet components
- Assembly Instructions

Note: The fireplace entertainment center ships in two separate boxes, each with its own tracking number. These boxes may arrive on different days. Please ensure you have received both packages before beginning assembly.

Setup and Assembly

Assembly is required for this product. Please follow the detailed instructions provided in the included assembly manual. It is recommended to have at least two people for assembly to ensure safety and ease of construction. An electric screwdriver can significantly speed up the process.




Image showing the overall dimensions of the TV stand, measuring 70 inches wide, 13.8 inches deep, and 31.4 inches high. It indicates compatibility with TVs up to 90 inches and a weight capacity of 150 lbs. The image also notes that the item ships in two packages which may arrive separately.

Operating Instructions - Electric Fireplace

The integrated 36-inch electric fireplace offers various customizable settings for ambiance and heating.

Flame and Backlight Customization:

- **3-Sided Glass Display:** Provides expansive views of the 3D flame effects.
- **Flame Brightness:** Choose from 5 adjustable levels.
- **Backlight Hues:** Select from 12 rich backlight colors.
- **LED Strip Colors:** Enjoy 12 vibrant LED strip colors.
- **Control:** Adjust flame color, brightness, and flickering speed using the digital LED display or the included remote control.

Heating Functions:

- **Heating Modes:** Dual heating modes (750W/1500W) to heat up to 375 sq ft.
- **Temperature Settings:** 14 temperature settings ranging from 60°F to 84°F, plus a 99°F option.
- **Timer Settings:** 11 timer settings available (0.5H, 1H, 2H up to 9H) for energy efficiency.

Smart Features:

- **Memory Function:** The 'favorite setting' memory function automatically remembers your preferred settings.
- **Power-on State:** The unit can be set to remember its last state (e.g., standby).
- **Child Lock:** For added safety, a child lock feature is included.



Close-up of the 36-inch panoramic fireplace, highlighting the touch screen controls and remote. Features include flame settings, dimmer, heater (up to 400 sq. ft.), child lock, 'My Flame' setting, and power button. Temperature range from 60°F to 84°F is also shown.



Display of 12 flame colors and 5-level flame brightness options for the electric fireplace, ranging from dim to bright.

Your browser does not support the video tag.

Official product video demonstrating the features and functionality of the ROCKPOINT 70-inch TV Stand with a 36-inch electric fireplace, including flame effects and overall design.

Storage Features

The TV stand is designed with flexible and spacious storage options to keep your living area organized.

- **Ample Storage:** Features open shelving and hidden compartments for various items.
- **Adjustable Shelves:** Cabinets include adjustable shelves for customized storage.
- **Stable Doors:** Doors are equipped with stops for enhanced stability.
- **Cable Management:** Integrated cable management holes help organize LED strips and other wires, maintaining a tidy appearance.
- **Durable Construction:** Crafted from modern MDF and premium PB, ensuring scratch-resistant, water-resistant, and odorless surfaces.



Detailed view of the storage cabinets, showcasing the stable and solid base, comfortable handle, adjustable shelf, and quality buffer hinges for silent, anti-pinch operation.



Top-down view emphasizing the high-base thickened tabletop (70"W x 13.8"D) and extra space for media equipment, including cable management holes.

Maintenance

To maintain the appearance and longevity of your TV stand, follow these simple care instructions:

- Wipe with a dry cloth to remove dust and debris.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- For spills, wipe immediately with a soft, damp cloth and dry thoroughly.

Troubleshooting

If you encounter any issues with your Fireplace TV Stand, consider the following common solutions:

- **Fireplace not turning on:** Ensure the power cord is securely plugged into a working outlet. Check the power switch on the unit and the remote control batteries.
- **No heat output:** Verify that the heater function is activated and the temperature setting is above the ambient

room temperature. Ensure air vents are not obstructed.

- **LED light strips not working:** Check all connections for the LED strips and ensure their power supply is properly connected.
- **Unstable unit:** Recheck all assembly hardware to ensure screws are tightened. Ensure the unit is placed on a level surface.

Specifications

Feature	Detail
Brand	ROCKPOINT
Model	Fireplace TV Stand 70inch
Color	Grey
Item Dimensions (L x W x H)	70 x 13.8 x 31.4 inches
Item Weight	86 Pounds
Material Type	Engineered Wood
Fireplace Size	36 inches
Heat Coverage	Up to 375 sq ft
Required Assembly	Yes

Warranty and Support

For any problems or inquiries regarding your ROCKPOINT Fireplace TV Stand, please contact our customer support. We aim to provide a 24-hour reply and are committed to ensuring your satisfaction.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FL27X7M7

More documents and user manuals: **https://manuals.plus/**