Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ROCKPOINT Fireplace TV Stand 80inch

ROCKPOINT 80-inch Fireplace TV Stand with 3-Sided Glass and 36-inch Electric Fireplace (Grey) - User Manual

Model: Fireplace TV Stand 80inch (ASIN: B0FL27YJB4)

Introduction Safety Information Package Contents Assembly Operation Maintenance Troubleshooting Specifications Support

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your ROCKPOINT 80-inch TV Stand Entertainment Center with a 3-Sided Glass 36-inch Electric Fireplace in Grey. Designed to accommodate TVs up to 90 inches, this media console combines functional storage with the ambiance of an electric fireplace.

2. Safety Information

WARNING:

- Keep away from naked flame or direct heat sources.
- Ensure all electrical connections are secure and meet local safety standards.
- Do not overload electrical outlets.
- Keep children and pets away from the fireplace unit when in operation.

3. Package Contents

Your ROCKPOINT Fireplace TV Stand will be delivered in two separate boxes. Please ensure both packages have arrived before beginning assembly. Allow 1-2 business days for both boxes to arrive.
The packages should contain the following components:

- Fireplace Heater
- Hardware (screws, dowels, cam locks, etc.)
- TV Stand Cabinet components

4. Assembly Instructions

Assembly of the ROCKPOINT Fireplace TV Stand is required. Please follow the included step-by-step instructions carefully. It is recommended to have at least two people for certain assembly steps, especially when handling larger components or flipping the unit.

General Assembly Tips:

- Lay out all parts and hardware before starting.
- Use a power drill with caution for faster assembly, but avoid overtightening screws.
- Ensure all connections are snug for stability.
- The unit is designed to be built upside down and then flipped; ensure proper support during this step.




Figure 1: Product Dimensions and TV Compatibility. The stand measures 80 inches wide, 15.7 inches deep, and 31.4 inches high, supporting TVs up to 90 inches and a weight capacity of 150 lbs.



Figure 2: Multi-color LED Light Strip. This image illustrates the integrated multi-color LED light strip, which can illuminate the storage compartments, enhancing the aesthetic appeal.

5. Setup

Once assembled, place the TV stand in your desired location. Ensure it is on a flat, stable surface. The 80-inch wide surface is designed to hold TVs up to 90 inches. Utilize the cable management holes to organize LED strips and other wires, keeping your entertainment area neat and tidy.

6. Operating Instructions (Electric Fireplace)

The integrated 36-inch electric fireplace offers various customization options for both ambiance and heating.

6.1. Fireplace Controls

The fireplace can be controlled via its digital LED display or the included remote control.

- **Flame Settings:** Adjust flame color, brightness (5 settings), and speed. The fireplace features 12 backlight colors and 12 LED light strip colors.
- **Heating:** The heater is equipped with heating tubes and offers 14 temperature settings, ranging from 60°F to 84°F, plus a 99°F setting. It provides heating for areas up to 375 sq ft with dual heat modes (750W/1500W).
- **Timer:** Utilize 11 timer settings (0.5H, 1H, 2H to 9H) to manage power usage and automatically turn off the fireplace.
- **Favorite Setting Memory:** The unit features a favorite setting memory function. You can set the power-on state to standby mode, and these settings will be saved automatically.
- **Child Lock:** A child lock feature is available for safety.



Figure 3: Electric Fireplace Controls. This image displays the touch screen and remote control options for managing flame effects, heat, and timer functions.



Figure 4: Panoramic Fireplace Flame Options. This image showcases the wide array of 12 flame colors and 5 brightness levels available for the electric fireplace, allowing for personalized ambiance.

6.2. Storage Cabinets

The entertainment center includes open shelving and hidden compartments with glass panel doors for ample storage. Doors are equipped with stops for stability. Adjustable shelves allow for flexible organization of media accessories, decorative items, or other household items.



Figure 5: Storage Features. This image highlights key construction details such as the stable base, decorative handles, adjustable shelves within the cabinets, and quality buffer hinges for smooth door operation.

7. Maintenance

To maintain the appearance and longevity of your TV stand, wipe surfaces with a dry cloth. Avoid using harsh chemicals or abrasive cleaners that may damage the finish. Regularly check all hardware connections to ensure they remain tight and secure.

8. Troubleshooting

If you encounter any issues with your ROCKPOINT Fireplace TV Stand, please refer to the following general troubleshooting tips:

- **Fireplace not turning on:** Ensure the unit is properly plugged into a working electrical outlet. Check the power switch on the unit and the remote control batteries.

- **No heat output:** Verify that the heater function is activated and the temperature setting is above the ambient room temperature. Check for any obstructions around the heater vents.
- **Unstable stand:** Recheck all assembly hardware to ensure screws and fasteners are tightened securely. Ensure the stand is on a level surface.
- **Doors not closing properly:** Adjust the hinges if necessary. Ensure no items are obstructing the door's path.

9. Specifications

Feature	Detail
Brand	ROCKPOINT
Model	Fireplace TV Stand 80inch
Color	Grey
Material Type	Engineered Wood (MDF and Premium PB)
Item Dimensions (L x W x H)	80 x 15.7 x 31.4 inches
Item Weight	112 Pounds
TV Size Compatibility	Up to 90 inches
Fireplace Size	36 inches
Heating Area	Up to 375 sq ft
Heat Modes	750W/1500W
Temperature Settings	14 settings (60°F to 84°F, plus 99°F)
Flame Brightness Settings	5 levels
Backlight/LED Strip Colors	12 colors each
Timer Settings	11 settings (0.5H, 1H, 2H to 9H)
Included Components	Fireplace Heater, Hardware, TV Stand Cabinet
Required Assembly	Yes

10. Warranty and Support

ROCKPOINT is committed to customer satisfaction. If you have any problems or questions regarding your product, please contact customer support. We aim to provide a response within 24 hours to address your concerns.
For further assistance, please refer to the contact information provided with your purchase or visit the official ROCKPOINT website.

© 2026 ROCKPOINT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FL27YJB4

More documents and user manuals: **https://manuals.plus/**