Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Uvital B0FL28P85M

Uvital Big Button Corded Phone for Seniors (Model B0FL28P85M) - Instruction Manual

Model: B0FL28P85M | Brand: Uvital

Introduction

This manual provides comprehensive instructions for the Uvital Big Button Corded Phone for Seniors. Designed for ease of use, this landline phone features large buttons, one-touch dialing, an SOS emergency button, and adjustable volume settings. Please read this manual thoroughly before operating your new phone.

What's in the Box

- Big Button Phone
- Handset Cord
- Telephone Line Cord
- User Manual

Setup

1. Connecting the Phone

The Uvital Big Button Phone requires no batteries or external power. Simply connect it to your existing telephone line.

1. Plug one end of the handset cord into the left side of the phone base unit.
2. Plug the other end of the handset cord into the handset.
3. Plug one end of the telephone line cord into the "TEL-LINE" jack on the side of the phone base.
4. Plug the other end of the telephone line cord into your telephone wall socket.



Image: Connection diagram for the Uvital Big Button Phone. It illustrates plugging the handset cord into the base and handset, and the telephone line into the base and wall jack.

2. Desktop or Wall Mounting

The phone can be placed on a desktop or mounted on a wall for convenience.

Your browser does not support the video tag.

Video: This video demonstrates how to set up the Uvital Big Button Phone for either desktop use or wall mounting, showing the necessary adjustments for the handset cradle.

3. Inserting Pictures for One-Touch Dialing

The phone features 8 one-touch dialing buttons where you can insert pictures of your frequent contacts for easy recognition. The photo size is approximately 0.88 x 0.88 inches (2.23 x 2.23 cm).



Image: The phone's one-touch buttons are designed to hold small photos, making it easy to identify contacts at a glance.

Your browser does not support the video tag.

Video: This video demonstrates the process of replacing the pictures on the one-touch dialing buttons of the Uvital Big Button Phone.

4. Programming One-Touch Dialing Numbers

To program a phone number to a one-touch button:

1. Pick up the handset or press the **SPEAKER** button.
2. Press the **STORE** button.
3. Input the desired phone number using the numeric keypad.
4. Press the **STORE** button again.
5. Press the desired picture button (1-8) to assign the number.
6. Replace the handset or press the **SPEAKER** button to complete.

To program the **SOS** emergency button, follow the same steps, but press the **SOS** button in step 5.

Your browser does not support the video tag.

Video: This video provides instructions on how to store numbers for one-touch dialing on the Uvital Big Button Phone.

Operating Instructions

1. Making a Call

- **One-Touch Dialing:** Pick up the handset or press the **SPEAKER** button, then press the desired picture button (1-8) or the **SOS** button.
- **Standard Dialing:** Pick up the handset or press the **SPEAKER** button, then dial the phone number using the numeric keypad.
- **Redial:** Press the **REDIAL** button to call the last dialed number.

Your browser does not support the video tag.

Video: This video demonstrates the speakerphone function and how to use the one-touch dialing feature on the Uvital Big Button Phone.

2. Answering a Call

When the phone rings, pick up the handset or press the **SPEAKER** button to answer.



Image: The phone features a loud ringer (up to 110dB) and a flashing LED indicator to ensure incoming calls are not missed.

3. Using the SOS Emergency Button

The **SOS** button provides direct dialing to a pre-programmed emergency contact. This function is available in both on-hook and off-hook modes.



Image: The dedicated SOS button allows for quick emergency calls, designed for easy use by seniors.

4. Adjusting Volume

The phone offers adjustable volume settings for both the ringer and the handset.

- **Ringer Volume:** Use the switch on the side of the phone to select **OFF**, **LOW**, or **HI**. The maximum ringer volume is 110dB.
- **Handset Volume:** Use the switch on the side of the phone to select **MED**, **HI**, or **VHI**.
- **Hands-Free Speaker Volume:** The hands-free speaker volume can reach up to 110dB.



Image: Switches for adjusting ringer and handset volume are located on the side of the phone for easy access.



Image: The hands-free function allows for clear conversations without holding the handset, with an amplified speaker for better audibility.

5. LED Incoming Call Indicator

The phone is equipped with a bright LED light that flashes when there is an incoming call, making it more noticeable, especially in noisy environments. Please note that this phone does not have a display screen and therefore does not support caller ID functionality.

Maintenance

To ensure the longevity and optimal performance of your Uvital Big Button Phone, follow these maintenance guidelines:

- **Cleaning:** Wipe the phone's surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the ABS material.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the phone with care to prevent drops or impacts that could damage internal components.

Troubleshooting

If you encounter any issues with your Uvital Big Button Phone, please refer to the following common problems and solutions:

Problem	Possible Solution
No dial tone	Ensure the telephone line cord is securely plugged into both the phone base and the wall jack. Test the wall jack with another working phone to confirm line functionality.
Phone not ringing	Check the ringer volume switch on the side of the phone and ensure it is not set to **OFF**. Verify that the telephone line is active.

Problem	Possible Solution
Cannot hear caller / Caller cannot hear me	Adjust the handset volume switch on the side of the phone. If using speakerphone, ensure the **SPEAKER** button is active and adjust volume if necessary. Check the handset cord connection.
One-touch dialing not working	Ensure the number has been correctly programmed to the button (refer to "Programming One-Touch Dialing Numbers" section). Pick up the handset or press **SPEAKER** before pressing the one-touch button.

Specifications

Feature	Detail
Model	B0FL28P85M
Brand	Uvital
Telephone Type	Corded
Color	White
Material	Acrylonitrile Butadiene Styrene (ABS)
Power Source	Corded Electric (No external power/batteries required)
Dialer Type	Single Keypad
Multiline Operation	Single-Line Operation
Caller Identification	No (No display screen)
Product Dimensions	0.39 x 0.39 x 0.39 inches
Item Weight	1.76 pounds
Ringer Volume	3 adjustable levels (OFF, LOW, HI), max 110dB
Handset Volume	3 adjustable levels (MED, HI, VHI)
Hands-Free Speaker Volume	Up to 110dB
Special Features	8 One-Touch Dialing Buttons, 1 SOS Emergency Button, Flashing LED Indicator

Warranty Information

Uvital products are manufactured to the highest quality standards. For specific warranty details and terms, please refer to

the warranty card included with your product or contact Uvital customer support.

Customer Support

If you have any questions, require technical assistance, or need further support, please contact Uvital customer service through the contact information provided on the product packaging or the official Uvital website.

© 2025 Uvital. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FL28P85M

More documents and user manuals: **https://manuals.plus/**