



Manuals.plus /

- › VVFLU /
- › VVFLU Farmhouse 10 Drawer Dresser (Model I87010406A1) User Manual

## VVFLU I87010406A1

# VVFLU Farmhouse 10 Drawer Dresser User Manual

Model: I87010406A1 (Cherry Wood)

---

## 1. INTRODUCTION

This manual provides essential instructions for the safe assembly, proper operation, and effective maintenance of your VVFLU Farmhouse 10 Drawer Dresser. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



*Image 1.1: The VVFLU Farmhouse 10 Drawer Dresser in a Cherry Wood finish, featuring ten drawers and a spacious top surface.*

## **2. PRODUCT SPECIFICATIONS**

Feature	Detail
Brand	VVFLU
Model Name	I87010406A1
Product Dimensions (D x W x H)	15.8" x 63" x 31.5" (40cm x 160cm x 80.2cm)
Color	Cherry Wood
Material	Engineered Wood
Number of Drawers	10
Drawer Type	Ball Bearing Slide
Item Weight	124 Pounds (56.2 kg)
Assembly Required	Yes

## Farmhouse 10 Drawer Dresser



Image 2.1: Detailed dimensions of the dresser and individual drawers.

### 3. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is recommended to have at least two people for assembly due to the size and weight of the components. Ensure all parts are present before beginning.

### 3.1. Before You Begin

- Unpack all components and hardware. Verify against the parts list (typically included in the packaging) that all items are accounted for.
- Clear a spacious, clean, and level work area to prevent damage to components.
- Gather necessary tools (e.g., screwdriver, hammer, power drill for faster assembly).

### 3.2. General Assembly Steps (Refer to included detailed manual for specific steps)

1. Assemble the main frame of the dresser according to the provided diagrams.
2. Install the drawer slides onto the dresser frame. Ensure they are level and securely fastened.
3. Assemble each of the ten drawers. Attach the metal easy pull handles to the drawer fronts.
4. Insert the assembled drawers into the dresser frame, ensuring smooth sliding operation.
5. Attach the anti-tipping device to the back of the dresser and secure it to a wall stud. This is a critical safety step.



**Wood Grain Tabletop  
Retro Metal Handles**

**Upgraded  
Anti-tipping  
Device**



**Retro Carved  
Wood Grain**

**Drawer Slide Design  
Smooth Sliding**



*Image 3.1: Key features and components, including the anti-tipping device and drawer slides.*

## 4. OPERATION

The VVFLU Farmhouse 10 Drawer Dresser is designed for organized storage in various rooms, including bedrooms, hallways, and closets. Its ten spacious drawers provide ample room for clothing, linens, and other essentials.

### 4.1. Drawer Usage

- To open a drawer, gently pull the metal handle. The ball-bearing slides ensure smooth operation.
- To close a drawer, push it firmly until it is fully seated within the dresser frame.
- Avoid overloading drawers to ensure smooth function and prevent damage to the slides or drawer structure. The sturdy construction supports up to 70 lbs on the tabletop.



Image 4.1: The dresser with drawers open, illustrating its storage capacity.

## 5. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your dresser.

### 5.1. Cleaning

- Wipe the surface with a dry, soft cloth.

- For spills, immediately wipe with a slightly damp cloth and then dry thoroughly.
- Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the cherry wood finish.

## 5.2. General Care

- Keep the dresser away from direct sunlight and heat sources to prevent fading or warping.
- Periodically check all screws and fasteners to ensure they are tight. Retighten as necessary.
- Ensure the anti-tipping device remains securely attached to the wall.

## 6. SAFETY INFORMATION

To prevent serious injury, especially to children, it is crucial to follow these safety guidelines:

- **Always use the provided anti-tipping device.** Securely attach the dresser to a wall stud using the included hardware.
- Do not allow children to climb on or play with the dresser or its drawers.
- Place heavier items in the lowest drawers to improve stability.
- Do not open multiple drawers simultaneously, as this can destabilize the unit.

## 7. TROUBLESHOOTING

### 7.1. Drawers Do Not Align or Close Properly

- **Check Assembly:** Ensure all drawer slides are installed correctly and are level. Verify that the drawer boxes are assembled squarely.
- **Hardware:** Confirm all screws securing the slides to both the dresser frame and the drawers are fully tightened.
- **Obstructions:** Check for any objects or debris obstructing the drawer slides.

### 7.2. Dresser Feels Unstable or Tips Forward

- **Anti-Tipping Device:** Ensure the anti-tipping device is correctly installed and securely anchored to a wall stud. This is the most critical step for stability.
- **Level Surface:** Verify the dresser is placed on a flat, level surface. Adjust any leveling feet if present.
- **Weight Distribution:** Redistribute contents, placing heavier items in lower drawers.

### 7.3. Scratches on Surface

- Minor scratches can sometimes be touched up with a wood repair marker or furniture polish matching the cherry wood finish.
- Always use coasters or protective pads under items placed on the tabletop.

## 8. CUSTOMER SUPPORT

For any missing parts, assembly assistance, or product inquiries, please contact VVFLU customer support. Refer to the contact information provided with your purchase or visit the official VVFLU website.

While specific warranty details are not included in this manual, please retain your proof of purchase for any potential warranty claims.

