

Xuevcn CP8

Xuevcn CP8 Cell Phone Stand with Wireless Bluetooth Speaker User Manual

1. INTRODUCTION

Thank you for choosing the Xuevcn CP8 Cell Phone Stand with Wireless Bluetooth Speaker. This device combines a stable phone stand with a high-quality Bluetooth speaker, designed to enhance your mobile viewing and listening experience at home or outdoors. This manual provides essential information for proper setup, operation, and maintenance of your new device.

2. SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Keep the device away from water or other liquids.
- Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel for assistance.
- Use only the specified battery type (2 A batteries) and ensure correct polarity during installation.
- **Important Note:** This product does not have a power bank function and cannot charge your phone.

3. PACKAGE CONTENTS

Please check the package for the following items:

- Xuevcn CP8 Cell Phone Stand with Wireless Bluetooth Speaker (Main Unit)
- Quick Start Guide

- 2 x A Batteries (pre-installed or included separately)

4. PRODUCT OVERVIEW

The Xuevcn CP8 is a versatile device combining a stable stand for mobile devices with an integrated Bluetooth speaker. Its compact design makes it suitable for various environments.



Image Description: The Xuevcn CP8 Cell Phone Stand with Wireless Bluetooth Speaker, shown with a smartphone horizontally mounted, displaying a festive image. The device features a black, anti-slip base with an integrated speaker grille and four control buttons, and an adjustable phone holder.

Key Components:

- **Adjustable Phone Holder:** Securely holds smartphones and tablets.
- **Bluetooth Speaker:** Integrated into the base for audio output.
- **Control Buttons:** Located on the base for power, volume, and playback control.
- **Anti-Slip Base:** Provides stability on various surfaces.

5. SETUP

5.1 Battery Installation

1. Locate the battery compartment on the underside of the speaker base.
2. Open the compartment cover.
3. Insert the two A batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

5.2 Powering On/Off

- To power on, press and hold the Power button (usually marked with a power symbol) on the speaker base until an indicator light illuminates or an audio prompt is heard.
- To power off, press and hold the Power button again until the indicator light turns off or an audio prompt confirms shutdown.

6. OPERATING INSTRUCTIONS

6.1 Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode. The indicator light will typically flash rapidly.
2. On your smartphone, tablet, or e-reader, navigate to the Bluetooth settings menu.
3. Enable Bluetooth and search for available devices.
4. Select "CP8" (or similar device name) from the list of found devices.
5. Once paired, the indicator light will typically become solid, and an audio confirmation may be heard.
6. You can now play audio from your device through the CP8 speaker.

6.2 Phone Stand Usage

- The stand is compatible with most 4-10 inch smartphones, tablets, and e-readers.
- The hook of the stand accommodates devices up to 0.59 inches (15 mm) thick.
- Gently place your device into the holder. The stand is adjustable to provide an optimal viewing angle.
- Ensure your device is securely seated before releasing it.

6.3 Control Buttons

The speaker base features several buttons for controlling audio playback:

- **Power Button:** Press and hold to turn the device on or off.
- **Play/Pause Button:** Press once to play or pause audio.
- **Volume Up Button:** Press to increase the volume.
- **Volume Down Button:** Press to decrease the volume.

7. MAINTENANCE

- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.

- Ensure the speaker grille is free from dust and debris for optimal sound quality.
- If the device will not be used for an extended period, remove the batteries to prevent leakage.

8. TROUBLESHOOTING

- **No Power:** Ensure batteries are correctly installed and charged. Replace if necessary.
- **Cannot Pair Bluetooth:** Make sure the speaker is in pairing mode. Turn off and on Bluetooth on your mobile device. Ensure no other devices are currently connected to the speaker.
- **No Sound:** Check the volume levels on both the speaker and your connected device. Ensure the device is successfully paired.
- **Poor Sound Quality:** Ensure your device is within the Bluetooth range. Check for obstructions between the speaker and your device.

9. SPECIFICATIONS

Brand	Xuevcn
Model Name	CP8
Speaker Type	Soundbar
Connectivity Technology	Bluetooth
Speaker Maximum Output Power	5 Watts
Product Dimensions	2"D x 2"W x 2"H
Item Weight	0.035 ounces
Number of Batteries	2 A batteries required (included)
Compatible Device Size	4-10 inch smartphones/tablets (hook fits up to 0.59 inches / 15 mm thick)

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the Quick Start Guide included with your product or contact Xuevcn customer service through the retailer where the product was purchased. Please retain your proof of purchase for warranty claims.