Faber 330.0710.826

Faber Hood Zenith FL HC BK 60cm Autoclean Slant Chimney User Manual

Model: 330.0710.826

Introduction

Thank you for choosing the Faber Hood Zenith FL HC BK 60cm Autoclean Slant Chimney. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your appliance. Please read it thoroughly before use and keep it for future reference.



Image: Faber Hood Zenith FL HC BK 60cm Autoclean Slant Chimney. This image displays the sleek, black, slant design of the chimney, suitable for modern kitchens.

Important Safety Instructions

- Ensure the power supply matches the voltage specified on the rating label.
- Do not operate the chimney if the power cord or plug is damaged.
- Always disconnect the appliance from the power supply before cleaning or maintenance.
- This appliance is for domestic use only.
- Keep children away from the appliance during operation and cleaning.
- Ensure adequate ventilation in the room when the chimney is used simultaneously with gas or other fuel-burning appliances.

Setup and Installation

The Faber Hood Zenith FL HC BK is a 60cm wide slant design wall-mount chimney. Professional installation is recommended to

ensure proper functioning and safety.

Pre-Installation Checklist:

- Verify all components are present: Chimney unit, mounting bracket, ducting pipe (if included), screws, and instruction manual.
- Ensure the wall is strong enough to support the chimney's weight (approximately 15 kg).
- Confirm the availability of a suitable power outlet within reach of the power cord.
- Measure the distance from the cooking surface to the desired chimney position, adhering to local regulations and manufacturer recommendations (typically 65-75 cm).

Mounting Steps (Summary):

1. Mark the drilling points on the wall according to the mounting template.
2. Drill holes and insert wall plugs.
3. Secure the mounting bracket to the wall.
4. Carefully lift and attach the chimney unit to the mounting bracket.
5. Connect the ducting pipe to the chimney outlet and vent it to the outside.
6. Plug the chimney into the power outlet.

Operating Instructions

Your Faber Hood Zenith FL HC BK chimney features advanced controls for ease of use.

Control Panel Overview:

The chimney is equipped with a touch control panel and supports gesture control for convenient operation.

- **Power Button:** Turns the chimney ON/OFF.
- **Speed Control:** Adjusts suction power (e.g., Low, Medium, High).
- **Light Button:** Controls the integrated lighting.
- **Auto Clean Button:** Initiates the auto-clean cycle.
- **Odor Sensor Activation:** Activates or deactivates the automatic odor detection feature.

Using Touch Control:

Gently tap the desired function icon on the control panel to activate it.

Using Gesture Control:

Wave your hand in front of the designated sensor area to perform actions such as turning on/off or adjusting speed. Refer to the specific gesture patterns illustrated in the full manual for detailed instructions.

Odor Sensor Technology:

When activated, the advanced odor sensor automatically detects cooking odors and adjusts the chimney's suction speed to effectively clear the air. This feature ensures optimal air quality without manual intervention.

Powerful Suction:

The chimney provides a powerful suction capacity of 1400 m^3/hr, designed to efficiently remove smoke, grease, and cooking odors from your kitchen environment.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your chimney.

Auto Clean Technology:

This chimney features advanced auto-clean functionality. To initiate an auto-clean cycle, press the dedicated Auto Clean button on the control panel. The system will heat and melt accumulated oil and grease, collecting it in an oil collector tray. Empty the oil collector tray regularly.



Image: Illustration of the auto-clean process or the oil collector tray. This image shows the chimney's exterior, representing its overall design which facilitates the auto-clean function.

Cleaning the Exterior:

- Wipe the exterior surfaces with a soft cloth dampened with mild detergent.
- Do not use abrasive cleaners, steel wool, or harsh chemicals, as these can damage the finish.
- Ensure the chimney is switched off and unplugged before cleaning.

Cleaning the Oil Collector Tray:

- Regularly check and empty the oil collector tray, typically located at the bottom of the chimney.
- Wash the tray with warm, soapy water and dry thoroughly before reinserting.

Troubleshooting

Before contacting customer service, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Chimney not turning on.	No power supply; loose plug; tripped circuit breaker.	Check power connection; ensure plug is secure; reset circuit breaker.
Low suction power.	Oil collector tray full; blocked ducting; incorrect speed setting.	Empty and clean oil collector tray; check ducting for obstructions; increase fan speed.
Unusual noise during operation.	Loose components; foreign object in fan; motor issue.	Ensure all parts are securely fastened; inspect for foreign objects (with power off); contact service if motor noise persists.
Auto Clean not functioning.	System error; insufficient power.	Ensure stable power supply; try restarting the chimney; contact service if issue persists.

Specifications

Feature	Detail
Model Number	330.0710.826
Brand	Faber
Type	Autoclean Slant Chimney
Width	60 cm
Suction Capacity	1400 m^3/hr
Control Type	Touch, Gesture Control
Special Features	Filterless, Odor Sensor, Auto Clean Technology
Installation Type	Wall-Mount
Item Weight	15 kg
Manufacturer	Franke Faber India Pvt.Ltd

Warranty and Support

Faber provides comprehensive warranty coverage for your peace of mind:

- **Motor Warranty:** 12 years
- **Comprehensive Warranty:** 5 years (by Faber)

For warranty claims, technical assistance, or service requests, please contact Faber customer support. Keep your purchase receipt and model number handy.

Faber Customer Care: 1800-209-3485
Manufacturer/Importer: Franke Faber India Pvt Ltd, 1086/1/2, SANASWADI, TAL - SHIRUR, PUNE - 412208, MAHARASHTRA, INDIA.

© 2023 Faber. All rights reserved. Information in this manual is subject to change without notice.