

[Manuals.plus](#) /

› [VINGLI](#) /

› VINGLI Criss Cross Office Chair (Model B0FL2G9M3N) - Instruction Manual

VINGLI B0FL2G9M3N

VINGLI Criss Cross Office Chair

Model: B0FL2G9M3N

Instruction Manual

1. SAFETY INFORMATION

Always follow the assembly instructions provided. Be cautious when adjusting and folding the armrests to avoid injury. Do not exceed the maximum weight capacity of 330 lbs. Keep the chair away from heat sources to prevent damage to the fabric.

2. PRODUCT OVERVIEW AND DIMENSIONS

The VINGLI Criss Cross Office Chair is designed for comfort and versatility, featuring an extra-wide seat and adjustable components. Review the following dimensions for proper placement and use.

Solid load-bearing up to

330 LBS



Product Dimensions

Image: Product dimensions including overall height (33.9"-36.8"), width (30.3"), depth (25.2"), seat height (17.5"-20.1"), and seat width (25").



Image: Front view of the VINGLI Criss Cross Office Chair.

3. SETUP AND ASSEMBLY

This product requires assembly. Please follow the provided instructions carefully to ensure correct and safe setup. All necessary tools and hardware are included.

1. Unpack all components and verify against the parts list.
2. Attach the chair base to the gas lift cylinder.
3. Secure the seat plate to the bottom of the seat cushion.
4. Connect the backrest to the seat assembly.
5. Install the armrests, ensuring they are securely fastened.
6. Insert the casters into the chair base.



Image: Overview of chair functions, including height adjustment and swivel.

4. OPERATING INSTRUCTIONS

4.1. Adjustable Armrests

The armrests can be adjusted in height and angle to suit your preference. They can also be folded up to 91° to allow the chair to be stored neatly under a desk, maximizing space. To adjust, locate the release mechanism on the armrest support and move the armrest to the desired position.

Multifunctional Adjustable Armrests



Image: Demonstration of adjustable and flip-up armrests.

4.2. Seat Height Adjustment

Use the convenient height adjustment handle located under the seat to effortlessly raise or lower the seat. This allows you to match the chair's height to your desk and body size for an ergonomic sitting position.

4.3. Tilting Feature

Adjust the extent of the backrest's forward and backward movement by adjusting the tilt tension. This multi-functional adjustment supports your back and promotes good posture, providing a relaxing experience during breaks. A lever under the seat controls the tilt lock/unlock function.



Image: Illustration of the chair's tilting mechanism and controls.

4.4. 360° Swivel and Mobility

The chair is equipped with a smooth 360° swivel capability and high-quality, silent-rolling casters. This enables easy movement across various floor surfaces, such as carpet or hard-wood floors, without noisy distractions. The stable rotation helps relieve neck pressure.

Swivel Cross Legged Chair

Saving Space & Sturdy & Smooth & Silent



Image: Demonstration of 360° swivel and flexible casters.

4.5. Extra Wide and Soft Cushion

The chair features an extra-wide 25"x17.7" seat cushion, providing ample space for comfortable sitting, including cross-legged positions. The premium high-density foam materials ensure comfort during long hours and evenly distribute body weight to prevent soreness.



Image: Extra wide seat for comfortable sitting positions.



Image: Cross-section view of the cushion structure, detailing Chenille fabric, high-density foam, and sturdy plank.

5. MAINTENANCE

To ensure the longevity and optimal performance of your VINGLI Criss Cross Office Chair, follow these maintenance guidelines:

- **Cleaning:** For the Chenille fabric, gently spot clean with a mild detergent and a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Casters:** Periodically check the casters for hair or debris and clean them to ensure smooth rolling.
- **Hardware:** Regularly inspect all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading of the fabric.

6. TROUBLESHOOTING

If you encounter any issues with your chair, refer to the following common troubleshooting tips:

- **Chair not adjusting height:** Ensure the height adjustment lever is fully engaged or disengaged as required. Check if the gas lift cylinder is properly installed.
- **Casters not rolling smoothly:** Inspect casters for obstructions (e.g., hair, dust) and clean them. Ensure the casters are securely inserted into the base.
- **Chair feels unstable or wobbly:** Check all assembly screws and bolts, and tighten any that are loose. Ensure the chair base is correctly attached to the seat mechanism.
- **Armrests not folding/adjusting:** Verify that the armrest release mechanism is functioning correctly and not obstructed.

If problems persist, please contact VINGLI customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	VINGLI
Model Number	B0FL2G9M3N
Color	Black
Material	Chenille (Fabric), Foam (Fill), Engineered Wood (Frame)
Product Dimensions (D x W x H)	25.2"D x 30.3"W x 33.9"H
Seat Depth	17.7 inches
Maximum Weight Recommendation	330 Pounds

Additional Features	90°-120° Tilting Feature, Adjustable Height, Flip-Up Armrests, Space Saving, Wide and Soft Cushion
Room Type	Bedroom, Computer Room, Dressing Room, Home Office, Living Room
Required Assembly	Yes

8. WARRANTY AND SUPPORT

This VINGLI product comes with a standard manufacturer's warranty. For specific warranty details, claims, or technical support, please refer to the warranty card included with your purchase or contact VINGLI customer service directly. Contact information can typically be found on the VINGLI official website or through your retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question