

[Manuals.plus](#) /

› [AGPTEK](#) /

› AGPTEK M6U MP3 Player User Manual

AGPTEK M6U

AGPTEK M6U MP3 Player User Manual

Model: M6U

INTRODUCTION

Thank you for purchasing the AGPTEK M6U MP3 Player. This device is designed to provide a high-quality portable audio experience with its 64GB internal storage and Bluetooth 5.3 connectivity. This manual will guide you through the setup, operation, and maintenance of your new MP3 player to ensure optimal performance and longevity.

PACKAGE CONTENTS

Please check the package for the following items:

- AGPTEK M6U MP3 Player (1 unit)
- USB Type-C Cable (for data transfer and charging) (1 unit)
- Wired Earphones (can be used as FM antenna) (1 unit)
- User Manual (multi-language, including English) (1 unit)

PRODUCT OVERVIEW

The AGPTEK M6U MP3 Player features a sleek design with a 2.4-inch LCD screen and intuitive controls. Familiarize yourself with the device's physical components.

新採用 高級感 あふれる亜鉛合金ボデ

一体成型で、抜群の握り心地



高耐久



超スリム

Image: The AGPTEK M6U MP3 Player, showcasing its compact size and user interface. The device is held in a hand, highlighting its portability and the layout of its screen and physical control buttons.

The player is equipped with a durable zinc alloy body, providing a comfortable grip. It features a responsive display for easy navigation through menus and media files.

SETUP

1. Charging the Device

Before initial use, fully charge the MP3 player. Connect the provided USB Type-C cable to the player's charging port and the other end to a USB power adapter (not included) or a computer's USB port.

- A full charge typically takes 2 to 2.5 hours.
- The battery charges to 80% capacity in approximately 1.5 hours.
- A fully charged battery provides up to 40 hours of music playback.

長持ちバッテリー

充電1回で長時間再生可能



Image: The AGPTEK M6U MP3 Player displaying its battery charging status and indicating a long playback time. The image visually represents the charging process and extended battery life.

2. Power On/Off

- **To Power On:** Press and hold the Power button (usually located on the side) until the screen lights up.
- **To Power Off:** Press and hold the Power button until a power-off option appears on the screen, then confirm.

3. Transferring Music Files

Connect the MP3 player to your computer using the provided USB Type-C cable. The player will appear as a removable disk drive. You can then drag and drop your music files (FLAC, MP3, WMA, WAV, APE, ACELP, AAC, Audible, OGG) directly into the player's storage.

内蔵128GBメモリ

数千曲の音楽を収録可能



Image: The AGPTEK M6U MP3 Player screen showing various album covers and music playback information, with an overlay indicating internal memory. This illustrates the player's capacity for storing thousands of songs.

The player comes with 64GB of internal memory. You can also expand storage using a microSD card.

4. Bluetooth Pairing

To connect your AGPTEK M6U to Bluetooth headphones or speakers:

1. Go to the Bluetooth menu on your MP3 player.
2. Enable Bluetooth.
3. Put your Bluetooth headphones/speaker into pairing mode.
4. Select your device from the list of available devices on the MP3 player's screen.
5. The player supports automatic reconnection to previously paired devices upon power-on.

AGPTEK

Bluetooth 自動再接続

電源オン即接続！



他社製品

手動接続

再起動のたびに手動接続が必要



Image: The AGPTEK M6U MP3 Player connected wirelessly to a pair of Bluetooth earbuds, illustrating the automatic reconnection feature. The screen shows the Bluetooth icon, indicating an active connection.

OPERATING INSTRUCTIONS

1. Basic Navigation

Use the touch screen or physical buttons (Play/Pause, Next/Previous, Volume) to navigate through menus and control playback. The interface is designed for intuitive use.

2. Music Playback

From the main menu, select "Music" to browse your audio files. You can sort by artist, album, genre, or view all songs. Tap a song to begin playback.

- Press the Play/Pause button to start or pause music.
- Use the Next/Previous buttons to skip tracks.
- Adjust volume using the dedicated volume controls.

3. Voice Recording

The AGPTEK M6U features a one-key recording function, allowing you to quickly capture audio. This is

useful for lectures, meetings, or personal notes.

ワンキー録音

アイデアも議事録も即座に記録



Image: The AGPTEK M6U MP3 Player screen showing an active recording session, indicated by a large microphone icon and a filename. This highlights the device's one-key recording capability, useful for capturing ideas or discussions instantly.

To start a recording, locate the dedicated recording button (if available, otherwise navigate through the menu). Recordings are saved in MP3 or WAV format.

4. FM Radio

To use the FM radio function, connect the wired earphones to the player. The earphones act as an antenna. Navigate to the FM Radio application from the main menu, then scan for available stations.

5. Settings

Access the "Settings" menu to customize various aspects of your player, including display brightness, language, date and time, equalizer settings, and system information.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid liquid cleaners or abrasive materials.
- **Storage:** Store the player in a cool, dry place away from direct sunlight and extreme temperatures.

- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge it regularly, even if not in use for extended periods.
- **Software Updates:** Periodically check the official AGPTEK website for any available firmware updates to ensure optimal performance and new features.

TROUBLESHOOTING

Problem	Solution
Device does not power on.	Ensure the battery is charged. Connect the player to a power source for at least 10 minutes, then try powering on again.
Cannot connect to Bluetooth headphones.	Make sure Bluetooth is enabled on both the player and the headphones. Put headphones in pairing mode. Ensure they are within range and not connected to another device.
Music files are not recognized.	Verify that the music files are in a supported format (FLAC, MP3, WMA, WAV, APE, ACELP, AAC, Audible, OGG). Ensure files are transferred correctly to the player's internal storage or microSD card.
Screen is unresponsive.	Try restarting the device. If the issue persists, a factory reset might be necessary (note: this will erase all data).

SPECIFICATIONS

Feature	Detail
Brand	AGPTEK
Model Number	M6U
Internal Memory	64 GB
Screen Size	2.4 Inches
Display Technology	LCD
Connectivity Technology	USB, Bluetooth 5.3
Compatible Devices	PC, Headphones
Media Type	microSD Card (expandable storage)
Supported Audio Formats	FLAC, MP3, WMA, WAV, APE, ACELP, AAC, Audible, OGG
Supported Recording Formats	MP3, WAV
Supported Video Formats	AMV, AVI (240*320)
Battery Life (Average)	Up to 40 Hours
Color	Black
Origin	China

WARRANTY AND SUPPORT

The AGPTEK M6U MP3 Player comes with a 180-day warranty from the date of purchase. This warranty covers manufacturing defects under normal use.

For technical support, warranty claims, or further assistance, please contact AGPTEK customer service through their official website or the retailer where you purchased the product. Please have your model number (M6U) and proof of purchase ready when contacting support.

IMPORTANT SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble or repair the device yourself. This will void the warranty.
- Use only approved charging cables and accessories.
- Listen to audio at moderate volumes to prevent hearing damage.