

[Manuals.plus](#) /

› [TensaOne](#) /

› TensaOne 128 GB Voice Activated Recorder (Model TO007) Instruction Manual

TensaOne TO007

TensaOne 128 GB Voice Activated Recorder (Model TO007) User Manual

Your guide to operating and maintaining your TensaOne recording device.

PRODUCT OVERVIEW

The TensaOne 128 GB Voice Activated Recorder is a compact, magnetic recording device designed for clear audio capture. It features smart voice-activated recording, manual recording options, AI-powered voice clarity, and a large storage capacity. The device also functions as a USB flash drive and offers instant file access via USB-C connection.

AI VOICE CLARITY

CUTS BACKGROUND NOISE.
KEEPS VOICES CLEAR.

AI reduces background noise so voices stay clear and easy to understand.



Image: The TensaOne 128 GB Voice Activated Recorder, a compact black device.

WHAT'S IN THE BOX

- Magnetic Voice Recorder
- Instructions (this manual)

SETUP

Initial Charge

Before first use, fully charge the recorder. Connect the device to a USB-C power source (e.g., computer USB-C port or a USB-C wall adapter) using its built-in USB-C connector. The indicator light will show charging status.

Powering On/Off

To power on the device, slide the power switch to the 'On' position. To power off, slide the switch to the 'Off' position.

BIG CAPACITY.

SMALL DEVICE.

From meetings and lectures to interviews, notes, and voice memos, it goes wherever you do.



Image: The TensaOne recorder being plugged into a USB-C port for charging or data transfer.

OPERATING INSTRUCTIONS

Voice-Activated Recording (Auto Mode)

The device features smart voice-activated recording. When enabled, the recorder will automatically start recording when sound is detected and pause when silence occurs. This conserves battery life and storage space by only capturing relevant audio.




Image: The TensaOne recorder illustrating its voice-activated recording feature, starting when sound is detected.

Manual Recording

To bypass voice-activated mode and record continuously, activate manual recording. Refer to the device's physical controls for the specific switch or button to initiate and stop manual recording. This mode is suitable when continuous audio capture is required, regardless of sound presence.

AI-Powered Voice Clarity

The recorder incorporates AI technology to filter out background noise, such as hum or chatter, enhancing the clarity of recorded voices. This feature is active during recording to provide cleaner audio, even in noisy environments.

Your browser does not support the video tag.

Video: An overview of the TensaOne Recorder, highlighting its features and benefits. This video provides a general introduction to the device's capabilities.



Image: The TensaOne recorder highlighting its AI Voice Clarity feature, which cuts background noise for clear voice recordings.

Accessing and Transferring Files

To access, play, save, or delete recordings, simply plug the recorder directly into any USB-C compatible phone or computer. No special cables, apps, or setup are required. The device will appear as a standard USB storage device.

Your browser does not support the video tag.

Video: Demonstrates how to play recordings from the TensaOne Recorder on a USB-C iPhone. This video is useful for users with compatible Apple devices.

Using as a USB Flash Drive

With 128 GB of storage, the TensaOne recorder can also function as a portable USB flash drive. You can store various files alongside your audio recordings. Connect it to a computer or compatible device via USB-C to manage files.



tensaOne	OTHERS
✓ 128GB STORAGE UP TO 9,000 HRS RECORDING	32GB STORAGE ONLY 300 HRS RECORDING
✓ 460MAH BATTERY UP TO 9,000 HRS STANDBY	200MAH BATTERY ONLY 8 HRS CONTINUOUS
✓ SMART VOICE-ACTIVATED RECORDING	BASIC NOISE REDUCTION
✓ ADVANCED AI NOISE REDUCTION	STANDARD CONTINUOUS RECORDING
✓ BUILT-IN USB PLUG & PLAY	CABLE CONNECTION REQUIRED

Image: The TensaOne recorder emphasizing its large capacity, capable of storing up to 9000 hours of recordings.

MAINTENANCE

Charging the Battery

The device is powered by a built-in rechargeable battery. To charge, connect the recorder to a USB-C power source. A full charge provides approximately 700 hours of battery life in auto mode. Avoid overcharging by disconnecting once fully charged.

Cleaning and Storage

Wipe the device with a soft, dry cloth to remove dust or smudges. Do not use liquid cleaners or abrasive materials. Store the recorder in a cool, dry place away from direct sunlight and extreme temperatures to prolong its lifespan.

TROUBLESHOOTING

Recordings Not Playing on iPhone/iPad

If recordings are not visible or playable on an iPhone or iPad, ensure you are using the native 'Files' app. Navigate to 'Browse' and then select the TensaOne device. Some third-party file managers may not fully support direct access. If issues persist, try

transferring files to a computer first.

Your browser does not support the video tag.

Video: A comprehensive guide to the TensaOne Recorder, covering various operational aspects and settings. This video serves as a full instruction manual in video format.

General Issues

- **Device not responding:** Ensure the battery is charged. Connect to a power source and try again.
- **Poor audio quality:** Check the recording environment for excessive background noise. Ensure the device is placed optimally for sound capture.
- **Files not transferring:** Ensure the USB-C connection is secure and the device is properly recognized by your computer or phone. Try a different USB-C port if available.

Your browser does not support the video tag.

Video: Provides quick answers to frequently asked questions about the TensaOne Recorder. This video is helpful for addressing common user queries and troubleshooting.

SPECIFICATIONS

Feature	Detail
Model Number	TensaOne MINI DIGITAL VOICE RECORDER (TO007)
Memory Storage Capacity	128 GB
Digital Recording Time	Up to 9000 hours
Battery Average Life	Up to 700 hours (on auto mode)
Item Weight	1.87 ounces
Product Dimensions (D x W x H)	2.76" x 1.57" x 0.39"
Hardware Interface	USB Type C
Microphone Form Factor	Built-In
Microphone Operation Mode	Mono
Compatible Devices	WIN XP, WIN 7, WIN 8, WIN 10, IOS, Linux
Headphones Jack	No

WARRANTY

The TensaOne 128 GB Voice Activated Recorder includes a Lifetime Warranty. This warranty covers manufacturing defects. It does not cover damage resulting from misuse, accidents, or unauthorized modifications. For warranty claims or assistance, please contact customer support.

SUPPORT

For further assistance, technical support, or inquiries regarding your TensaOne Voice Activated Recorder, please refer to the contact information provided with your purchase or visit the official TensaOne website. When contacting support, please have your model number (TO007) and purchase details available.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question