

## OUKITEL G3

# OUKITEL G3 Rugged Smartphone User Manual

Model: G3

## 1. PRODUCT OVERVIEW

---

The OUKITEL G3 is a rugged smartphone designed for durability and performance in challenging environments. It features a 6.0-inch HD display, a 6300mAh battery, 16GB RAM (expandable), 256GB ROM (expandable to 1TB), and a 13MP main camera. The device is certified with IP68, IP69K, and MIL-STD-810H ratings, ensuring resistance to water, dust, and drops. It operates on Android 14 and supports 4G Dual SIM, GPS, Face ID, and OTG functionality.

## 2. PACKAGE CONTENTS

---

Verify that all items are present in your package:

- 1x OUKITEL G3 Smartphone
- 1x Charger
- 1x Type-C Cable
- 1x SIM Card Ejector Pin
- 1x User Manual



Image: Contents of the OUKITEL G3 retail package, including the smartphone, charger, Type-C cable, SIM ejector pin, and user manual.

## 3. INITIAL SETUP

### 3.1. Inserting SIM Cards and TF Card

1. Locate the SIM card tray on the side of the device.
2. Use the provided SIM ejector pin to open the tray.
3. Carefully place your Nano SIM cards (up to two) and/or a TF card (for memory expansion up to 1TB) into the designated slots.
4. Ensure the cards are correctly oriented as indicated on the tray.
5. Gently push the tray back into the phone until it clicks into place.

# Make Every Memory Crystal Clear

Record moments clearly and make every shot better



Image: Close-up of the OUKITEL G3's SIM and TF card tray, showing the slots for dual Nano SIM cards and a TF card for memory expansion.

## 3.2. Charging the Battery

Before first use, fully charge the device. Connect the Type-C cable to the phone's charging port and the other end to the provided charger. Plug the charger into a power outlet. The battery indicator on the screen will show charging status. The OUKITEL G3 features a 6300mAh battery for extended use.



Image: The OUKITEL G3 smartphone connected to a Type-C charging cable, illustrating the charging process.

### 3.3. Powering On/Off

- To power on: Press and hold the Power button until the OUKITEL logo appears.
- To power off: Press and hold the Power button, then select "Power off" from the options on the screen.
- To restart: Press and hold the Power button, then select "Restart" from the options.

## 4. OPERATING INSTRUCTIONS

### 4.1. Display and Navigation

The OUKITEL G3 features a 6.0-inch HD display with 450 nits brightness and Corning Glass 5 protection. Navigate the Android 14 interface using touch gestures: tap, swipe, pinch-to-zoom. Access quick settings by swiping down from the top of the screen.



Image: The OUKITEL G3 smartphone displaying a vibrant image on its 6.0-inch HD screen.

## 4.2. Camera Functions

The device is equipped with a 13MP rear camera and a 5MP front camera. Open the Camera app to capture photos and videos. Features include:

- **Standard Photo Mode:** For everyday photography.
- **AI Beauty Mode:** Enhances facial features in portraits.
- **Underwater Camera Mode:** Allows capturing photos and videos while submerged up to 1.5m for 30 minutes. Ensure all ports are securely sealed before underwater use.
- **Panorama Mode:** For wide-angle landscape shots.

# 6.0 inch Display

Breathtaking Clarity, Unforgettable Visuals



Image: Visual representation of the OUKITEL G3's camera capabilities, highlighting the 13MP rear camera, 5MP front camera, and underwater photography mode.

### 4.3. Battery Management and OTG

The 6300mAh battery provides extended usage. To optimize battery life, manage screen brightness, close unused applications, and enable power-saving modes when needed. The device supports OTG (On-The-Go) reverse charging, allowing you to use your OUKITEL G3 to charge other compatible devices via a Type-C OTG cable (sold separately).

# 16GB RAM + 256GB ROM

Providing ample storage capacity to meet daily usage and entertainment needs

 1TB Expansion

 Android 14

**16GB RAM**  
(4+12GB Virtual)

**256GB ROM**  
(Up To 1TB)

**Octa-  
Core**




Image: The OUKITEL G3 smartphone showcasing its 6300mAh battery capacity and support for OTG reverse charging.

## 4.4. Custom Key and Security Features

- **Custom Key:** A programmable button on the side of the device for quick access to specific applications or functions. Configure its actions (single click, double click, long press) in the phone settings.
- **Face ID:** Use facial recognition for secure unlocking of your device. Set up Face ID in the Security settings.
- **GPS Navigation:** The OUKITEL G3 supports GPS, GLONASS, Beidou, and Galileo navigation systems for accurate positioning.



Image: An illustration detailing the OUKITEL G3's custom key functionality, Face ID, GPS navigation, and built-in toolbox applications.

## 5. MAINTENANCE AND DURABILITY

The OUKITEL G3 is built to withstand harsh conditions, certified with IP68, IP69K, and MIL-STD-810H standards.

- **IP68 Water Resistance:** Protected against continuous immersion in water up to 1.5 meters for 30 minutes. Ensure all port covers are tightly sealed before exposure to water.
- **IP69K Dust Resistance:** Fully protected against dust ingress and high-pressure, high-temperature water jets.
- **MIL-STD-810H Drop Resistance:** Designed to withstand drops from up to 1.5 meters. The aluminum frame and rubberized corners provide enhanced shock absorption.

To clean the device, use a soft, damp cloth. Avoid harsh chemicals or abrasive materials. Regularly check port covers for proper sealing to maintain water and dust resistance.



Image: The OUKITEL G3 smartphone displayed in various rugged environments, highlighting its IP68 water resistance, IP69K dust resistance, and MIL-STD-810H drop resistance certifications.

## 6. TROUBLESHOOTING

If you encounter issues with your OUKITEL G3, refer to the following common solutions:

Problem	Possible Solution
Device does not power on	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
Poor network signal	Check if SIM cards are correctly inserted. Move to an area with better network coverage. Contact your service provider if the issue persists.
Applications crashing or freezing	Close background applications. Clear the cache of the problematic app. Restart the device. Ensure sufficient storage space is available.

Problem	Possible Solution
Battery drains quickly	Reduce screen brightness. Disable unused features like Wi-Fi, Bluetooth, GPS. Close power-intensive apps. Check battery usage in settings to identify culprits.
Touchscreen unresponsive	Restart the device. If the issue persists, perform a factory reset (backup data first).

## 7. TECHNICAL SPECIFICATIONS

Feature	Detail
Brand	OUKITEL
Model	G3
Operating System	Android 14
RAM	4GB (expandable to 16GB virtual RAM)
Internal Storage (ROM)	256GB
Expandable Storage	Up to 1TB (TF card)
Display Size	6.0 inches
Display Resolution	HD (450 nits brightness, Corning Glass 5)
Refresh Rate	60Hz
Rear Camera	13 Megapixels
Front Camera	5 Megapixels
Battery Capacity	6300 mAh
Charging Port	USB Type-C
Durability Ratings	IP68, IP69K, MIL-STD-810H
SIM Card Support	Dual 4G Nano SIM
Navigation	GPS, GLONASS, Beidou, Galileo
Biometric Security	Face ID
Audio Jack	3.5mm

For detailed energy efficiency information, please refer to the EU EPREL database:

<https://eprel.ec.europa.eu/qr/2400970>



## Jusqu'à 16GO RAM

Grâce à la technologie d'extension de la mémoire, vous pouvez étendre la mémoire vive d'origine de 4Go à un maximum de 16Go, vous offrant ainsi toute la fluidité dont vous avez besoin pour vos activités quotidiennes.

Image: Diagram illustrating the OUKITEL G3's memory configuration: 4GB physical RAM + 12GB virtual RAM for a total of 16GB, and 256GB ROM with up to 1TB expansion.

## 8. WARRANTY AND SUPPORT

OUKITEL provides the following support for the G3 smartphone:

- **Return Policy:** 30-day no-reason return.
- **Warranty:** TWO-YEAR warranty.
- **Technical Support:** Long-term technical assistance.
- **Customer Service:** 24-hour online customer service.

For any inquiries or support, please contact OUKITEL official customer service.