

Manuals.plus /

- › goodstumbler /
- › Mini GPS Tracker GF22 User Manual

## goodstumbler GF22

# goodstumbler Mini GPS Tracker GF22 User Manual

Model: GF22

## INTRODUCTION

The goodstumbler Mini GPS Tracker GF22 is a compact and versatile real-time location device designed for tracking elderly individuals, children, pets, and vehicles. It offers high-precision positioning, long battery life, and smart app integration to provide peace of mind by keeping you informed of important locations.

## PACKAGE CONTENTS



This image displays the complete package contents of the goodstumbler Mini GPS Tracker GF22. It includes the compact black GF22 tracker unit, a USB charging cable, and a printed instruction manual for setup and operation.

- 1 x goodstumbler Mini GPS Tracker GF22
- 1 x USB Charging Cable
- 1 x Instruction Manual

## PRODUCT OVERVIEW

---



This image shows a clear front view of the goodstumbler Mini GPS Tracker GF22. The device is black with a glossy top surface featuring a power button icon and "SOS GF-22" text, indicating its primary functions and model number.



This image illustrates the compact dimensions of the GF22 Mini GPS Tracker. Measurements are provided as 42mm in length, 26mm in width, and 15mm in height, highlighting its small and portable design.

The GF22 tracker is designed for discreet and effective tracking. Its compact size and robust build make it suitable for various applications.

### Key Features:

- **High Precision Tracking:** Offers pinpoint accuracy within 10 meters using advanced positioning technologies.
- **Long Battery Life:** Equipped with a 500mAh polymer battery, providing up to 3 days of standby time.
- **Smart App Integration:** Seamless monitoring via the 365GPS APP, compatible with iOS and Android devices.
- **Multiple Location Modes:** Supports GPS, WiFi, and LBS positioning for stable and accurate updates in diverse environments.
- **High Capacity Storage:** Supports up to 32GB memory cards for extensive tracking data storage.
- **SOS Functionality:** Dedicated SOS button for emergency alerts.

### SETUP GUIDE

Follow these steps to set up your GF22 Mini GPS Tracker:

1. **Charge the Device:** Connect the GF22 tracker to a power source using the provided USB charging cable. Ensure the device is fully charged before first use.
2. **Insert SIM Card (if applicable):** The GF22 requires a Nano SIM card for cellular connectivity to enable real-time tracking and SMS functions. Carefully open the SIM card slot cover and insert the SIM card with the chip facing upwards, ensuring it clicks into place. *(Note: SIM card is not included and must be purchased separately. Ensure it supports 2G GSM network for optimal performance.)*
3. **Power On:** Press and hold the power button (usually the SOS button) for a few seconds until the indicator lights illuminate, indicating the device is powered on.
4. **Download the App:** Search for "365GPS" in your smartphone's app store (Google Play Store for Android or Apple App Store for iOS) and download the official application.
5. **Register and Log In:** Open the 365GPS app, register a new account if you don't have one, and log in.
6. **Bind the Device:** In the app, locate the option to "Add Device" or "Bind Device". You will typically need to scan the QR code on the device or enter its unique ID number (usually found on a sticker on the device or packaging). Follow the on-screen prompts to complete the binding process.
7. **Initial Positioning:** Take the device outdoors or to an area with clear sky view for its first GPS fix. This may take a few minutes.

## OPERATING INSTRUCTIONS

Once set up, you can utilize the various functions of your GF22 tracker:

### Real-Time Tracking:



This image depicts the GF22 tracker positioned within a car interior, emphasizing its capability for precise positioning. Text overlays highlight "Wide coverage," "Accurate location," and "Fast positioning," illustrating the device's effectiveness in real-time tracking scenarios.

- Open the 365GPS app on your smartphone.
- The app will display the current location of your GF22 tracker on a map.
- The device uses a combination of GPS, WiFi, and LBS (Location Based Service) to provide the most accurate position available, automatically switching modes for optimal performance.

### Historical Track Playback:

# Track Playback Record

Automatically save historical track files

Finding people / finding objects / collecting / storing



This image shows a smartphone screen displaying a map with a historical track playback feature. The text "Track Playback Record" and "Automatically save historical track files" are visible, indicating the app's ability to review past movements of the tracker.

- Within the 365GPS app, navigate to the "History" or "Track Playback" section.
- Select a date range to view the past movements of the tracker. The app will display the route taken on the map.

## Geofence (Safety Fence):



# GPS tracker



**Security  
Fence**



**Precise  
Positioning**



**Historical  
Track**



This image features the GF22 GPS tracker alongside icons representing its core functionalities: a security fence symbol for geofencing, a location pin for precise positioning, and a winding path for historical track. It also shows various use cases like children, pets, and vehicles.

- In the 365GPS app, find the "Geofence" or "Safety Zone" feature.
- You can draw virtual boundaries on the map. When the tracker enters or exits these predefined areas, you will receive an alert notification on your smartphone.

## SOS Function:

- The GF22 tracker has an SOS button (often the power button). In an emergency, the user can press and hold this button.
- The device will send an emergency alert with its current location to pre-set emergency contacts via the app and/or SMS.

## MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your GF22 Mini GPS Tracker, please follow these guidelines:

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use harsh chemicals, cleaning solvents, or strong detergents.
- **Water Resistance:** The device is not waterproof. Avoid exposing it to water, rain, or high humidity.
- **Temperature:** Store and operate the device within recommended temperature ranges (typically 0°C to 45°C or 32°F to 113°F).

Extreme temperatures can affect battery life and device performance.

- **Storage:** When not in use for extended periods, store the device in a cool, dry place. Charge the battery periodically (e.g., every 3 months) to prevent deep discharge.
- **Avoid Drops:** Protect the device from severe shocks, vibrations, and drops, as these can damage internal components.
- **Battery Care:** Use only the provided charging cable. Do not attempt to replace the internal battery yourself.

## TROUBLESHOOTING

If you encounter issues with your GF22 Mini GPS Tracker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not powering on.	Low battery; device malfunction.	Charge the device for at least 2 hours. If still not powering on, contact support.
No location data or inaccurate positioning.	Poor GPS signal; no SIM card or insufficient balance; incorrect APN settings; device indoors.	Move the device to an open outdoor area. Ensure SIM card is correctly inserted, active, and has data/credit. Check APN settings in the app or via SMS commands (refer to app instructions).
App shows device offline.	Device powered off; no network signal; SIM card issues; server connection problem.	Ensure device is powered on. Check network coverage. Verify SIM card is active and has data. Try restarting the app or device.
Cannot bind device to app.	Incorrect ID/QR code; device already bound to another account.	Double-check the device ID or QR code. If previously bound, ensure it's unbound from the old account or contact support for assistance.
Battery drains quickly.	Frequent location updates; weak signal area; aging battery.	Adjust location update frequency in the app to a longer interval. Ensure device is in an area with good signal. Battery life naturally degrades over time.

## SPECIFICATIONS

Feature	Detail
Model	GF22
Dimensions (L x W x H)	42mm x 26mm x 15mm (1.65 x 1.02 x 0.59 inches)
Weight	Approximately 3.17 ounces (90 grams)
Color	Black
Positioning Modes	GPS, WiFi, LBS, AGPS
Positioning Accuracy	Within 10 meters (GPS)
Battery Type	3.7V 500mAh Polymer Battery
Standby Time	Up to 3 days
Memory Support	Up to 32GB memory card (for historical data storage)
App Compatibility	365GPS (iOS & Android)
Network	Requires 2G GSM Nano SIM card (not included)
Platform View	SMS + APP

## WARRANTY AND SUPPORT

Your goodstumbler Mini GPS Tracker GF22 comes with a standard manufacturer's warranty. Please refer to the specific warranty terms provided at the time of purchase or contact your retailer for details.

For technical support, troubleshooting assistance, or warranty claims, please contact goodstumbler customer service through the contact information provided on their official website or through your purchase platform.

