

manuals.plus /

- > [Michael Kors](#) /
- > [Michael Kors Lexington Watch Set MK4950SET Instruction Manual](#)

## Michael Kors MK4950SET

# Michael Kors Lexington Watch Set MK4950SET Instruction Manual

Model: MK4950SET

## 1. INTRODUCTION

This manual provides essential instructions for the Michael Kors Lexington Three-Hand Gold-Tone Stainless Steel Watch Gift Set, model MK4950SET. This set includes two distinct watches: a larger 48mm watch and a smaller 28mm watch, both featuring a gold-tone stainless steel design and a three-hand analog display. Please read this manual thoroughly to ensure proper use and maintenance of your watches.

### MICHAEL KORS について

マイケル・コースは、ラグジュアリー・アクセサリ&レディトゥウェアのデザイナーとして知られ、数々の受賞歴を誇ります。自身の名を冠した会社を1981年に設立し、現在ではマイケル・コース コレクション、マイケル マイケル・コース、マイケル・コース メンズのラインを展開し、アクセサリ、レディトゥウェア、フットウェア、ウォッチ、フレグランスなど幅広い商品を取り扱っています。マイケル・コース ストアは世界の主要都市に出店しており、さらに北アメリカ、ヨーロッパ、アジアでデジタル旗艦店を運営し、お客様にシームレスなオムニチャネル体験を提供します。

Image 1.1: The Michael Kors Lexington Watch Set MK4950SET, featuring both the larger and smaller gold-tone watches.

## 2. SETUP AND INITIAL USE

## 2.1 Setting the Time

1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch case) to the outermost position.
2. **Adjust the time:** Rotate the crown clockwise or counter-clockwise to move the hour and minute hands to the correct time.
3. **Push in the crown:** Once the time is set, push the crown back into its original position against the watch case. This will start the watch movement.



Image 2.1: Side view of the watches, illustrating the crown used for time adjustment.

## 2.2 Adjusting the Watch Band

The gold-tone stainless steel bracelet is designed with removable links to allow for size adjustment. For optimal fit, it is recommended to have a professional jeweler or watch technician adjust the band. Improper adjustment may damage the links or clasp.



Image 2.2: Rear view of the watches, illustrating the stainless steel band and deployment clasp mechanism.

### 3. OPERATING YOUR WATCH

#### 3.1 Time Display

Both watches feature a classic three-hand analog display, showing hours, minutes, and seconds. The larger 48mm watch also includes chronograph subdials and a date window, while the smaller 28mm watch features a simpler three-hand display with hour markers.



Image 3.1: Close-up of a Michael Kors Lexington watch face, showcasing the gold sunray dial and three-hand display.

### 3.2 Water Resistance

These watches are water resistant to 5 ATM (50 meters / 165 feet). This rating means the watches are suitable for short periods of recreational swimming or showering. They are **not** suitable for diving, snorkeling, or high-impact water sports. Avoid operating the crown or pushers when the watch is wet to prevent water intrusion.

## 4. MAINTENANCE AND CARE

---

### 4.1 Cleaning Your Watch

To maintain the appearance of your watch, wipe the case and band regularly with a soft, dry cloth. For stainless steel bands, a slightly damp cloth can be used, followed by a dry cloth. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the watch's finish.

### 4.2 Battery Information

The watches are powered by a quartz movement and require a battery. The battery included at the time of purchase is a monitor battery for checking operation and may have a limited lifespan. Battery depletion during storage or shortly after purchase is not covered under warranty. When the battery needs replacement, it is recommended to take the watch to an authorized service center or a qualified watch technician to ensure proper sealing and maintain water resistance.

## 5. TROUBLESHOOTING

---

- **Watch is not running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Time is incorrect:** Ensure the crown is fully pushed in after setting the time. If the time consistently loses or gains significantly, the movement may require inspection by a professional.
- **Condensation under the crystal:** This indicates a potential breach in water resistance. Immediately take the watch to a service center to prevent further damage.

## 6. SPECIFICATIONS

---



Image 6.1: Dimensional diagram illustrating the case size, lug width, and case thickness for both watches in the set.

Feature	Detail
Model Number	MK4950SET
Case Material	Stainless Steel
Case Diameter (Larger Watch)	48 mm
Case Diameter (Smaller Watch)	28 mm
Case Thickness	8 mm
Band Material	Stainless Steel
Band Width (Larger Watch)	22 mm
Band Width (Smaller Watch)	14 mm
Dial Window Material	Mineral Glass
Display Type	Analog (Three-Hand)
Movement	Quartz

Feature	Detail
Water Resistance Depth	50 meters (5 ATM / 165 feet)
Clasp Type	Push Button Deployment Clasp
Color	Gold-Tone

## 7. WARRANTY AND SUPPORT

The Michael Kors Lexington Watch Set MK4950SET comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from accidents, improper use, unauthorized repairs, or normal wear and tear, including battery depletion.

For warranty claims or service, please contact Michael Kors customer support or an authorized service center. Keep your proof of purchase, as it serves as your warranty documentation.

For further assistance or detailed information, please refer to the official Michael Kors website or contact their customer service department.