

[Manuals.plus](#) /

> [MineCtrl](#) /

> MineCtrl ZBPOWER 6000mAh Universal Battery Pack for Reclining Furniture Instruction Manual

MineCtrl BS-6-SC

MineCtrl ZBPOWER 6000mAh Universal Battery Pack for Reclining Furniture

Model: BS-6-SC

INTRODUCTION

This instruction manual provides essential information for the safe and efficient use of your MineCtrl ZBPOWER 6000mAh Universal Battery Pack. Please read this manual thoroughly before initial use and retain it for future reference.

IMPORTANT SAFETY INFORMATION

- Always fully charge the battery before initial use.
- Do not expose the battery pack to extreme temperatures, direct sunlight, or moisture.
- Do not disassemble, puncture, or modify the battery pack.
- Use only the provided charger for recharging the battery.
- Keep out of reach of children and pets.
- Ensure proper connection to avoid short circuits.
- This battery pack is UL and EMC certified for safety.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x MineCtrl ZBPOWER 6000mAh Battery Pack
- 1 x 29V2A Power Adapter (Charger)

- 1 x 6.6ft Extension Cable
- 1 x 4.0ft Y Splitter (for dual chair connection)
- 1 x User Manual (this document)

ALL YOU NEED TO GO CORDLESS

Battery Pack, Power Adapter and cable were tested and Listed by UL



1. 6000mAh Battery pack

2. 29V2A Power adapter

3. 6.6ft Extension cable

4. 4.0ft Y splitter

Image: Contents of the MineCtrl ZBPOWER 6000mAh Universal Battery Pack package, including the battery unit, power adapter, extension cable, and Y splitter.

SETUP INSTRUCTIONS

1. Initial Charging

1. Connect the 29V2A Power Adapter to a wall outlet.
2. Connect the charging cable from the power adapter to the charging port on the battery pack.
3. Allow the battery pack to charge fully until the indicator light changes (e.g., from red to green). This may take several hours for the first charge.

2. Connecting to Reclining Furniture

The battery pack is designed for universal 2-pin compatibility (one flat and one round pin connector).

1. Locate the power input cable on your reclining furniture. This cable typically connects to a wall

adapter.

2. Disconnect the furniture's power cable from its original power source.
3. Connect the furniture's power input cable directly to one of the output ports on the MineCtrl battery pack. Ensure the 2-pin connector is securely inserted.
4. If additional length is needed, use the provided 6.6ft Extension Cable between the furniture's power cable and the battery pack.

Universal 2-Pin Compatibility



Not Compatible With
USB connectors, 5-pin connectors,
RJ45 connectors, or barrel plug
connectors.



Image: Illustration of the universal 2-pin connector (one flat, one round) for input and output, highlighting compatibility.

Note: Not compatible with USB, 5-pin, RJ45, or barrel plug connectors.

3. Connecting Dual Chairs (Optional)

If you wish to power two pieces of reclining furniture from a single battery pack, use the 4.0ft Y Splitter:

1. Connect the Y Splitter's single input end to one of the output ports on the battery pack.
2. Connect the power input cables from each of your two reclining furniture pieces to the two output ends of the Y Splitter.

Enjoy your stay with family

Universal Compatibility

Easy to Install

Power Dual Chairs

Clean up the Power Cord and
Connect the battery pack



Image: A diagram illustrating how to connect the Y-splitter to the battery pack and then to two separate reclining furniture pieces, enabling a single battery to power dual chairs.

OPERATING INSTRUCTIONS

Once connected, your reclining furniture will operate as usual, drawing power from the battery pack instead of a wall outlet. This allows for flexible furniture placement without cord limitations.

- **Battery Life:** The 6000mAh battery offers up to 600 running cycles and can lift up to 275 lbs on a full charge.
- **Power Consumption:** Furniture with additional features like lights or USB charging ports will consume battery power faster, requiring more frequent recharging.
- **Low Power Warning:** The battery pack may provide an audible tone or visual indicator when the charge is low, signaling that a recharge is needed.

Eliminate Cord Chaos Instantly

Please read the instruction and fully charged the battery before initial use



Image: The MineCtrl battery pack connected to a recliner, illustrating its compact size and how it eliminates cord clutter. Dimensions are shown as 8.2" length, 1.6" height, and 3.9" width.

MAINTENANCE

- **Recharging:** Recharge the battery pack when the low power warning is activated or when you notice a decrease in furniture motor performance.
- **Storage:** If storing the battery pack for an extended period without use, ensure it is fully charged and recharge it at least every three months to maintain battery health.
- **Cleaning:** Wipe the exterior of the battery pack with a dry, soft cloth. Do not use liquid cleaners or immerse the unit in water.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Furniture does not operate.	Battery is depleted. Incorrect connection. Incompatible connector type.	Recharge the battery pack fully. Ensure all 2-pin connectors are securely seated. Verify your furniture uses a 2-pin (flat and round) connector. This battery is not compatible with USB, 5-pin, RJ45, or barrel plug connectors.
Battery drains quickly.	Furniture has high power consumption features (e.g., heat, lights, USB ports). Battery not fully charged.	This is normal for furniture with additional features; more frequent charging will be required. Ensure the battery is fully charged before use.
Battery pack not charging.	Charger not connected properly. Faulty charger or battery.	Check connections between the power adapter and the battery pack, and the wall outlet. Contact customer support if the issue persists.

If you encounter issues not listed here or if the suggested solutions do not resolve the problem, please contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	BS-6-SC
Battery Capacity	6000mAh
Output Voltage	12 Volts (DC)
Output Current	100 Milliamps
Connector Type	2-Pin (Flat and Round)
Dimensions (L x W x H)	Approximately 8.2 x 3.9 x 1.6 inches
Item Weight	3.61 pounds
Material	Plastic
Certifications	UL and EMC certified

WARRANTY AND CUSTOMER SUPPORT

Your MineCtrl ZBPOWER 6000mAh Universal Battery Pack comes with a **1-year, hassle-free replacement warranty**.

For any product support, questions, or warranty claims, please feel free to get in touch with our dedicated customer support team. Refer to your purchase documentation or the seller's contact information for assistance.

