Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MZYMI S36-PRO

MZYMI S36-PRO Open Ear Earbuds Instruction Manual

Model: S36-PRO

Introduction

Thank you for choosing the MZYMI S36-PRO Open Ear Earbuds. These earbuds feature an innovative clip-on design, Bluetooth 5.4 connectivity, and IPX5 water resistance, allowing you to enjoy audio while remaining aware of your surroundings. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

Setup

Package Contents

- MZYMI S36-PRO Open Ear Earbuds (Left and Right)
- Charging Case
- User Manual

Initial Charging

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the charging case to a power source using a compatible USB-C cable (not included).
3. The LED indicator on the charging case will show charging status. A full charge typically takes about 1 hour for the earbuds and the case.



Image: Earbuds inside the charging case, displaying the current battery percentage.

Pairing with a Device

The earbuds utilize Bluetooth 5.4 for a stable and efficient connection.

1. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing LED light.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices and select "MZYMI S36-PRO" from the list.
4. Once connected, the LED indicator on the earbuds will stop flashing, and you will hear an audible confirmation.

Wearing Instructions

The MZYMI S36-PRO earbuds feature a clip-on design for a secure and comfortable fit, allowing you to hear your audio and ambient sounds simultaneously.

1. Gently clip each earbud onto your earlobe, ensuring the speaker portion is positioned just outside your ear canal.

2. Adjust the flexible C-Bridge design to conform to your ear shape for a stable and comfortable fit.
3. Ensure the earbuds are securely in place before engaging in activities like sports or walking.



Image: A person wearing the MZYMI S36-PRO earbuds, demonstrating the secure and comfortable clip-on fit.

Your browser does not support the video tag.

Video: Official MZYMI demonstration of the S36-PRO Open Ear Earbuds, showcasing their design and how they are worn.

Operating Instructions

Touch Controls

The MZYMI S36-PRO earbuds feature intuitive touch controls for easy management of audio playback and calls.

- **Answer/Hang Up Call:** Long press any button.
- **Reject Incoming Call:** Long press any button.
- **Volume +:** Long press on the right earbud.
- **Volume -:** Long press on the left earbud.
- **Play/Pause:** Long press any button.
- **Previous Song:** Double click on the left earbud.
- **Next Song:** Double click on the right earbud.
- **Support Siri (Voice Assistant):** Three clicks on any earbud button.



Image: Visual guide to the touch controls on the MZYMI S36-PRO earbuds.

Audio Features

Experience clear and immersive sound with advanced audio technology.

- **12mm Driver:** Large drivers deliver deep bass and crisp highs for an immersive sound experience.
- **ENC Noise Cancellation:** Environmental Noise Cancellation ensures clear voices during calls by reducing background noise.



Image: Detailed view of the 12mm driver within the earbud structure.




Image: Illustration of ENC Noise Cancellation providing clear audio in public and work environments.

Maintenance

Cleaning

Regular cleaning helps maintain optimal performance and hygiene.

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Avoid using abrasive materials, alcohol, or chemical cleaners.
- Ensure charging contacts are clean and free of debris.

Water Resistance (IPX5)

The earbuds are rated IPX5 water resistant, meaning they can withstand sweat and light rain.

- Do not submerge the earbuds in water.
- They are not suitable for swimming or showering.
- If exposed to moisture, wipe them dry before placing them back in the charging case.

Battery Care

Proper battery care extends the lifespan of your earbuds.

- A single charge provides approximately 10 hours of playtime.
- The charging case extends total playtime up to 56 hours.
- A 10-minute quick charge can provide 2 hours of playtime.
- Store the earbuds and case in a cool, dry place when not in use.

Troubleshooting

If you encounter issues with your MZYMI S36-PRO earbuds, try the following solutions:

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget the device in your Bluetooth settings and re-pair. Place earbuds back in the case, close, then reopen to reset pairing mode.
No sound or low volume	Check device volume and earbud volume. Ensure earbuds are properly connected to your device. Clean any debris from the earbud speakers.
Uncomfortable fit or falling out	Adjust the clip-on position and the flexible C-Bridge for a more secure fit. Ensure the earbuds are oriented correctly for each ear (Left/Right).
Touch controls not responding	Ensure your fingers are clean and dry. Try restarting the earbuds by placing them in the case and taking them out again.

Specifications

Feature	Detail
Brand	MZYMI
Model Number	S36-PRO
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.4
Bluetooth Range	10 Meters
Ear Placement	Over Ear (Clip-On)
Form Factor	Clip-On
Audio Driver Type	Balanced Armature Driver (12mm)
Frequency Range	20 Hz - 20,000 Hz
Impedance	20 Ohms
Noise Control	Active Noise Cancellation (ENC for calls)
Control Method	Push Button, Touch
Battery Average Life (Earbuds)	10 Hours
Total Playtime (with Charging Case)	Up to 56 Hours
Battery Charge Time	1 Hour
Water Resistance Level	IPX5 (Waterproof)
Material	Silicone
Weight (single earpiece)	5.2g (as per feature bullets)



Image: Dimensions of the earbuds and charging case for reference.

Warranty Information

The MZYMI S36-PRO Open Ear Earbuds come with a 30-day warranty. Please refer to the product packaging or contact MZYMI customer support for detailed warranty terms and conditions.

Support

For further assistance, technical support, or inquiries regarding your MZYMI S36-PRO earbuds, please refer to the contact information provided on the product packaging or visit the official MZYMI website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FLC68RRN

More documents and user manuals: **https://manuals.plus/**