

[Manuals.plus](#) /

› [HOMCOM](#) /

› HOMCOM 700-176V80GY Recliner Chair with Massage and Heat User Manual

HOMCOM 700-176V80GY

HOMCOM 700-176V80GY Recliner Chair with Massage and Heat User Manual

Model: 700-176V80GY | Brand: HOMCOM

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the HOMCOM 700-176V80GY Recliner Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. This oversized manual reclining chair is designed for comfort, featuring vibration massage, lumbar heating, a 150-degree recline function, a 360-degree swivel base, and a gentle rocking motion. It is upholstered in a soft velvet-feel fabric with thick, high-density foam and a spring pocket seat for optimal support.



Image 1.1: The HOMCOM 700-176V80GY Recliner Chair in its upright position, showcasing its grey velvet-feel fabric and plush design.




Image 1.2: A detailed diagram illustrating the internal construction of the chair, highlighting the velvet-feel fabric, selected foam, and stretchy pocket springs for enhanced comfort and durability.

2. SAFETY INFORMATION

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in injury or damage to the product.

- **Maximum Weight Capacity:** This recliner chair supports a maximum weight of 298 lbs (135 kg). Do not exceed this limit.
- **Proper Use:** Use the chair only for its intended purpose as a seating and reclining furniture item. Avoid standing on the chair or using it as a step stool.
- **Children and Pets:** Keep children and pets away from the chair's moving parts, especially during reclining or adjusting the footrest, to prevent injury.
- **Electrical Safety:** Ensure the power cord for the massage and heat functions is not pinched or damaged. Do not operate the chair with a damaged cord or plug. Unplug the chair when not in use or before cleaning.
- **Placement:** Place the chair on a level surface. Ensure there is adequate space around the chair for safe reclining and swiveling without obstruction.
- **Heat Function:** Use the heat function responsibly. Prolonged use at high temperatures may cause discomfort or burns. Consult a physician before use if you have medical conditions that may be affected by

heat.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. Refer to the packaging for a complete list of parts and hardware. If any parts are missing or damaged, contact customer support.

4. ASSEMBLY INSTRUCTIONS

The HOMCOM 700-176V80GY Recliner Chair is designed for simple assembly. Follow the step-by-step instructions provided in your product packaging. Typically, assembly involves attaching the backrest to the seat base and connecting any necessary electrical components for the massage and heat functions.

1. Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify the main chair base and the backrest.
3. Align the metal brackets on the backrest with the corresponding slots on the chair base. Slide the backrest down firmly until it locks into place.
4. Connect any electrical cables for the massage and heat functions, ensuring they are securely fastened.
5. Ensure all connections are secure before using the chair.



Image 4.1: A diagram illustrating the key dimensions of the recliner chair in both its upright and fully reclined states, useful

for planning placement and understanding assembly.

5. OPERATING INSTRUCTIONS

5.1 Reclining Function

To recline the chair and raise the footrest, locate the side tab on the right side of the chair (when seated). Pull the tab to release the locking mechanism, then lean back gently. The chair will recline up to 150 degrees, and the footrest will extend simultaneously. To return to the upright position, push down on the footrest with your legs and lean forward until the chair locks into place.



Image 5.1.1: A visual guide demonstrating the manual reclining process, showing how to activate the recline and footrest with the side tab.



Image 5.1.2: A person comfortably seated in the recliner with the footrest extended, illustrating the chair's full recline capability.



Image 5.1.3: A person using a laptop while seated in the recliner, demonstrating the chair's versatility for various activities.

5.2 Massage and Heat Functions

The chair features eight vibrating massage points and a lumbar heating function, controlled by a wired remote. The remote offers five customizable massage modes. To use, ensure the chair is plugged into a power outlet. The remote can be stored in the convenient side pocket when not in use.

- **Power On/Off:** Press the power button on the remote to activate or deactivate the massage and heat functions.
- **Massage Modes:** Cycle through the five available massage modes using the designated buttons on the remote.
- **Intensity Adjustment:** Adjust the massage intensity (if available) using the remote controls.
- **Heat Activation:** Press the heat button to turn on the lumbar heating.
- **Timer:** Some models may include a timer function for automatic shut-off. Refer to your remote for specific options.



Image 5.2.1: A visual representation of the eight vibration massage points within the chair and the remote control used to operate the massage and heating functions.

Your browser does not support the video tag.

Video 5.2.2: An official product video demonstrating the features of the HOMCOM 700-176V80GY Massage Recliner Chair, including its reclining, massage, and heat functions.

5.3 Swivel and Rocking Functions

The chair is equipped with a 360-degree swivel base, allowing you to rotate freely. It also offers a gentle rocking motion for added relaxation. These functions operate independently of the recline mechanism.



Image 5.3.1: A diagram highlighting the 360-degree swivel base and the rocking functionality of the recliner chair.

5.4 Side Pockets

Two convenient side pockets are integrated into the chair's design, perfect for storing the remote control, magazines, or other small items within easy reach.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your recliner chair.

- **Cleaning:** The fabric is 100% Polyester. For general cleaning, wipe the surface with a clean, damp cloth. For spills, blot immediately with a clean, dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Vacuuming:** Regularly vacuum the chair using a soft brush attachment to remove dust and debris.
- **Inspection:** Periodically check all bolts and connections to ensure they are tight. Retighten if necessary.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading of the fabric.




Image 6.1: A close-up image of a hand touching the chair's fabric, highlighting its soft, velvet-like texture.

7. TROUBLESHOOTING

If you encounter issues with your recliner chair, refer to the following common solutions:

- **Chair does not recline:** Ensure the side tab is fully pulled. Check for any obstructions under the chair or around the reclining mechanism.
- **Massage/Heat not working:** Verify that the power cord is securely plugged into a working electrical outlet. Check the remote control for power and ensure it is connected to the chair.
- **Unstable or wobbly:** Ensure the chair is placed on a flat, even surface. Check all assembly connections and tighten any loose bolts.
- **Unusual noises:** Inspect the reclining mechanism for any foreign objects or loose parts. Lubricate moving metal parts with a silicone-based lubricant if squeaking persists.

If problems persist, please contact HOMCOM customer support.

8. SPECIFICATIONS

| Feature | Detail |
|---------|--------|
|---------|--------|

| | |
|---------------------------------|---|
| Brand | HOMCOM |
| Model Name | Massage Recliner Chair |
| Model Number | 700-176V80GY |
| Color | Grey |
| Upright Dimensions (D x W x H) | 36.2" x 36.2" x 40.2" |
| Reclined Dimensions (W x D x H) | 37.8" x 63" x 31.5" |
| Item Weight | 95 pounds |
| Maximum Weight Recommendation | 298 Pounds |
| Fabric Type | 100% Polyester (Velvet-feel) |
| Fill Material | Foam |
| Special Features | 360° swivel, Heating, Massage (8 points, 5 modes), Reclining (up to 150°), Side Pockets, Rocking Function |
| Product Care Instructions | Wipe Clean |
| UPC | 196393122075 |

9. WARRANTY AND SUPPORT

For warranty information or to obtain support for your HOMCOM 700-176V80GY Recliner Chair, please refer to the documentation included with your purchase or visit the official HOMCOM website. You may also contact the seller, Aosom Direct, for assistance.

For general inquiries or to explore other HOMCOM products, visit the [HOMCOM Store on Amazon](#).