

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Luoran](#) /

› [Luoran M4Pro MP3 Player for Kids User Manual](#)

Luoran M4Pro

Luoran M4Pro MP3 Player for Kids User Manual

Model: M4Pro-6750

1. INTRODUCTION

This manual provides detailed instructions for the Luoran M4Pro MP3 Player, a smart audio and media device designed for children and teenagers. It features a 4.0" IPS touchscreen, parental controls, and access to various streaming applications. Please read this manual thoroughly to ensure proper use and maintenance of your device.

2. WHAT'S IN THE Box

- Luoran M4Pro MP3 Player
- 64GB memory card (pre-installed)
- USB-C cable
- Wired earphone
- Silicone Case
- Instruction of use (this manual)

3. PRODUCT OVERVIEW

The Luoran M4Pro is a compact and durable MP3 player with a 4.0-inch IPS full-touchscreen display. It runs on Android 10, offering a smooth user experience.



Figure 1: Front view of the Luoran M4Pro MP3 Player showing the main interface with app icons.

The device features a metal frame and a tempered glass back for enhanced durability. It includes physical buttons for power and

volume control, along with a USB-C charging port and a 3.5mm headphone jack.




Figure 2: Detailed view of the Luoran M4Pro highlighting its metal frame and tempered glass back.

4. SETUP

- 1. Initial Power On:** Press and hold the power button located on the side of the device until the screen illuminates.
- 2. Parental Management PIN:** For first-time use, navigate to "Parental Management" in the settings. Set a PIN code and ensure you write it down and remember it. This PIN is crucial for accessing parental control functions and preventing unauthorized changes.
- 3. Connect to Wi-Fi:** Go to Settings > Network & Internet > Wi-Fi and connect to your preferred wireless network to enable streaming and app downloads.
- 4. Insert Memory Card:** The 64GB memory card is pre-installed. If you wish to expand storage further, insert a compatible micro SD card (up to 1TB) into the designated slot on the side of the device.

5. OPERATING INSTRUCTIONS

The Luoran M4Pro operates on an Android-based system, providing a familiar and intuitive interface. Navigate through applications by swiping the touchscreen and tapping on icons.

- **Power Button:** Press and hold to power on/off. Short press to wake/sleep the screen.
- **Volume Buttons:** Adjust audio volume using the dedicated buttons on the side.
- **Navigation:** Use the on-screen navigation buttons (Home, Back, Recent Apps) to move between screens and applications.

6. PARENTAL CONTROLS

The M4Pro includes a robust parental control system to manage your child's usage. Access these settings via the "Parental Management" app on the device's home screen.

- **App Blocking:** Block or unblock any application, including the Google Play Store, to control access to content.
- **Time Limits:** Set automatic ON/OFF times to control daily playing duration.
- **Night Light Mode:** Supported for eye care, adjustable in settings.




Figure 3: Parental Management password entry screen.

Figure 4: Parental Management app blocking settings.




Figure 5: Parental Management auto ON/OFF and password settings.



Figure 6: Night Light settings for eye care mode.

7. MEDIA INTEGRATION

The M4Pro comes pre-installed with popular apps and supports various media formats.

- **Pre-installed Apps:** Spotify Kids, Spotify, Amazon Music, Audible, Pandora, YouTube, Libby, and HiBy Music.
- **Google Play Store:** Download any additional music, audiobook, or entertainment apps.
- **Supported Audio Formats:** MP3, WAV, FLAC, APE, OGG, M4A, AAC, WMA, MP2, etc.



Figure 7: Home screen showing pre-installed music and media apps.

Supports music formats including

MP3, WAV, FLAC, APE, OGG, M4A, AAC, WMA, MP2, ETC.



Figure 8: Music playback options and Spotify Kids app interface.

8. STORAGE AND CONNECTIVITY

- **Internal Storage:** 32GB ROM with 3GB RAM.
- **Expandable Storage:** Comes with a 64GB memory card pre-installed (total 96GB). Supports external memory expansion up to 1TB via SDXC/SDHC cards.
- **Dual-Band WiFi:** Enjoy stable and fast wireless connections with 2.4GHz & 5GHz Wi-Fi.
- **Bluetooth 5.0:** Ensures seamless connectivity with headphones, speakers, and car stereos for a smooth audio experience.

Expandable Memory

Inbuilt 32GB, supports maximum 1TB micro SD card



Figure 9: Illustration of inserting a micro SD card for expandable memory.

9. BATTERY LIFE AND PORTABILITY

- **Battery:** Built-in 2000mAh LCO battery.
- **Music Playback:** Up to 70 hours of continuous music playback on a 2-hour charge.
- **Charging:** USB-C charging port.
- **Design:** Lightweight and portable, ideal for travel, exercise, and on-the-go use.

10. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the screen and device body. Avoid abrasive cleaners or solvents.
- **Protection:** Always use the provided silicone case to protect the device from drops and impacts.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the device frequently. Charge regularly.

11. TROUBLESHOOTING

- Device Not Turning On:** Ensure the device is charged. Connect to the USB-C charger and wait a few minutes before attempting to power on again.
- Forgotten Parental PIN:** If you forget your parental management PIN, you may lose access to certain functions. Refer to the device's support documentation or contact Luoran customer service for assistance.
- App Issues (e.g., frequent updates, not opening):** Ensure the device is connected to Wi-Fi. Check for system updates in Settings > System > System update. For specific app issues, try clearing the app's cache or reinstalling it via the Google Play Store.
- Sound Problems:** Check headphone connection. Ensure volume is not muted or too low. Test with different headphones or Bluetooth speakers.

12. SPECIFICATIONS

Feature	Detail
Product Dimensions	4.25 x 2.4 x 0.39 inches
Item Weight	4.9 ounces
Manufacturer	Luoran
Item Model Number	M4Pro-6750
Battery	Built-in 2000mAh LCO battery
Brand	Luoran
Model Name	M4Pro-6750
Special Feature	Bluetooth and WiFi, Google Play Store, Parental Controls
Connectivity Technology	Bluetooth, Wi-Fi
Memory Storage Capacity	96 GB (32GB ROM + 64GB SD card)
Color	Black
Screen Size	4 Inches
Compatible Devices	Earphone, Headphone
Media Type	Memory Card, SDHC, SDXC

13. WARRANTY AND SUPPORT

Luoran stands behind its products. If you encounter any unexpected issues or have questions, the Luoran support team is available 24/7 to assist you.

For support, please refer to the contact information provided in the "Instruction of use" booklet included in your product packaging or visit the official Luoran website.

Related Documents - M4Pro

	<p>Luoran MP3 Player: Guide to Installing Music and Podcast Applications</p> <p>This guide provides instructions for installing popular music and podcast applications like Spotify, Amazon Music, Pandora, and Audible on your Luoran MP3 Player. Learn how to connect your device and transfer applications for a seamless audio experience.</p>
	<p>Luoran M4 Pro Music Player User Manual</p> <p>Comprehensive user manual for the Luoran M4 Pro music player, covering key functions, button descriptions, connectivity options for PC and mobile devices, troubleshooting, specifications, warranty information, and safety warnings.</p>
	<p>Luoran M4 MP3 Player: Frequently Asked Questions</p> <p>Find answers to common questions about the Luoran M4 MP3 Player, covering features like Bluetooth, music playback, battery, FM radio, and more. Get detailed information to enhance your user experience.</p>
	<p>Luoran M4B MP3 Player User Manual and Specifications</p> <p>Comprehensive user manual and technical specifications for the Luoran M4B MP3 Player, covering setup, features, troubleshooting, and warranty information. Learn how to use your device, resolve common issues, and understand its capabilities.</p>
	<p>Luoran MP3 Player S5 User Manual and Specifications</p> <p>Comprehensive guide to the Luoran MP3 Player S5, covering key features, button descriptions, file transfer methods, troubleshooting, specifications, and warranty information.</p>
	<p>Luoran MP3 Player M4S User Manual</p> <p>User manual for the Luoran MP3 Player M4S (Updated), covering key diagrams, button descriptions, port functions, file transfer methods, parental controls, troubleshooting, specifications, and warranty information.</p>

