

[Manuals.plus](#) /

› [COLAMY](#) /

› COLAMY 360° Swivel Accent Chair User Manual

## COLAMY VC-W279-BR1-FL

# COLAMY 360° Swivel Accent Chair User Manual

Model: VC-W279-BR1-FL

## INTRODUCTION

---

Thank you for choosing the COLAMY 360° Swivel Accent Chair. This manual provides important information regarding the safe use, operation, and maintenance of your new chair. Please read it thoroughly before use and retain it for future reference.

## SAFETY INFORMATION

---

- Ensure the chair is placed on a flat, stable surface to prevent tipping.
- Do not exceed the maximum weight capacity of 275 pounds (125 kg).
- Keep children and pets away from the swivel mechanism during use to prevent injury.
- Avoid standing on the chair or using it as a step stool.
- Regularly inspect all components for wear or damage. Discontinue use if any part is compromised.
- Keep away from open flames and direct heat sources.

## PACKAGE CONTENTS

---

Your COLAMY 360° Swivel Accent Chair is delivered fully assembled in one box. Please verify that all components are present and undamaged upon arrival.

- 1 x COLAMY 360° Swivel Accent Chair
- 1 x User Manual (this document)
- 1 x Pillow (included with chair)

# SWIVEL ACCENT CHAIR

Refined Living, Effortless Comfort



Image: The COLAMY Swivel Accent Chair, showcasing its design and presence in a living room environment.

## SETUP

The COLAMY 360° Swivel Accent Chair arrives fully assembled and ready for immediate use. No tools or additional assembly steps are required.

1. Carefully remove the chair from its packaging.
2. Place the chair in your desired location, ensuring it is on a level surface.
3. Remove any protective coverings or tags.



Image: A diagram illustrating the chair's dimensions and confirming that no assembly is required, highlighting its ready-to-use nature.

## OPERATING INSTRUCTIONS

Your COLAMY Swivel Accent Chair is designed for comfortable seating and effortless rotation.

- **Seating:** Sit centrally on the chair, ensuring your weight is evenly distributed.
- **Swivel Function:** The chair features a 360° silent swivel mechanism. To rotate, gently push off the floor with your feet or use your hands on nearby surfaces. The weighted base ensures stable and smooth rotation.
- **Pillow Use:** The included pillow provides additional lumbar or head support as desired.



Image: A visual representation of the chair's 360-degree swivel capability, showing its rotation from different angles.

## MAINTENANCE

Proper care will extend the life and appearance of your COLAMY Swivel Accent Chair.

- **General Cleaning:** For routine cleaning, wipe the chair with a soft, damp cloth.
- **Stain Removal:** For spills or stains, use a mild soap solution and a clean cloth. Blot the area gently; do not rub vigorously. For stubborn stains, professional dry cleaning is recommended.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the material.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading of the upholstery.
- **Swivel Mechanism:** The swivel mechanism is designed for durability and typically requires no lubrication. If you notice any unusual noise or stiffness, ensure the base is clear of obstructions.



Image: A detailed view of the chair's premium PU leather, highlighting its texture and quality, relevant for cleaning instructions.

## TROUBLESHOOTING

| Problem                         | Possible Cause                              | Solution                                                                                              |
|---------------------------------|---------------------------------------------|-------------------------------------------------------------------------------------------------------|
| Chair does not swivel smoothly. | Obstruction under the base or uneven floor. | Check for any objects obstructing the swivel mechanism. Ensure the chair is on a flat, level surface. |

| Problem                      | Possible Cause                                      | Solution                                                                                      |
|------------------------------|-----------------------------------------------------|-----------------------------------------------------------------------------------------------|
| Unusual noise during swivel. | Debris in the swivel mechanism or loose components. | Inspect the base for debris and remove if found. If noise persists, contact customer support. |
| Chair feels unstable.        | Uneven floor or damaged base.                       | Relocate the chair to a level surface. Inspect the metal base for any visible damage.         |
| Upholstery appears faded.    | Prolonged exposure to direct sunlight.              | Move the chair away from direct sunlight or use curtains/blinds to protect it.                |

SPECIFICATIONS



Image: A comprehensive diagram detailing the dimensions of the COLAMY Swivel Accent Chair, including height, width, depth, seat dimensions, and maximum weight capacity.

| Feature                        | Detail                                                            |
|--------------------------------|-------------------------------------------------------------------|
| Brand                          | COLAMY                                                            |
| Model Name                     | VC-W279                                                           |
| Model Number                   | VC-W279-BR1-FL                                                    |
| Color                          | Y-brown                                                           |
| Material                       | Premium PU Leather, High-Density Foam                             |
| Frame Material                 | FSC-certified Rubberwood, Metal Base                              |
| Product Dimensions (D x W x H) | 31.5"D x 28.74"W x 28.74"H                                        |
| Item Weight                    | 43.1 pounds                                                       |
| Seat Height                    | 18.31 inches                                                      |
| Seat Depth                     | 17.91 inches                                                      |
| Maximum Weight Recommendation  | 275 pounds                                                        |
| Assembly Required              | No (Fully Assembled)                                              |
| Special Features               | 360° Swivel, Arm Rest, Ergonomic Design, Upholstered, No-Sag Foam |
| Indoor/Outdoor Usage           | Indoor                                                            |

## WARRANTY AND SUPPORT

COLAMY stands behind the quality of its products. For specific warranty details, please refer to the documentation included with your purchase or visit the official COLAMY website. If you encounter any issues or have questions regarding your Swivel Accent Chair, please contact COLAMY customer support through the retailer where the product was purchased or via the brand's official channels.

For additional information, you may visit the [COLAMY Store on Amazon](#).

© 2023 COLAMY. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question