

HOOBRO BF97CJ01

HOOBRO 3-Tier Purse Organizer

Model: BF97CJ01

Brand: HOOBRO

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your HOOBRO 3-Tier Purse Organizer, Model BF97CJ01. Please read this manual thoroughly before assembly and use to ensure proper function and safety.



Image 1.1: The HOOBRO 3-Tier Purse Organizer, Model BF97CJ01, showcasing its storage capabilities for handbags and accessories.

2. SAFETY INFORMATION

- **Anti-Tip Kit:** For your safety, it is crucial to secure the purse organizer to the wall using the included anti-tip kit. Failure to do so may result in injury or damage.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 120 pounds (54.4 kg) for the entire unit. Distribute weight evenly across shelves and hooks.
- **Assembly:** Assemble the unit on a soft, clean surface to prevent scratches. Ensure all screws and fasteners are tightened securely before use.
- **Placement:** Place the organizer on a level surface to prevent wobbling and ensure stability.
- **Children:** Keep small parts and packaging materials away from children during assembly.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact HOOBRO customer service.

- Metal Frame Components
- Wooden Shelves (3 tiers)
- Fabric Drawer (1)
- Movable Hooks (8)
- Hardware Pack (screws, bolts, etc.)
- Anti-Tip Kit
- Assembly Instructions

4. ASSEMBLY INSTRUCTIONS (SETUP)

The assembly process is designed to be straightforward. Each part is clearly numbered, and all necessary tools are included. Follow the step-by-step instructions provided in the separate assembly guide for detailed visual assistance.

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a clean, soft surface. Identify each part using the provided parts list.
2. **Assemble the Frame:** Connect the metal frame components according to the diagrams in the assembly guide. Ensure all connections are finger-tight initially.
3. **Attach Shelves:** Secure the three wooden shelves to the frame using the designated hardware.
4. **Install Drawer:** Insert the fabric drawer into its designated slot on the top tier.
5. **Attach Hooks:** Place the 8 movable hooks onto the side rails. Ensure they are securely seated.
6. **Final Tightening:** Once all components are in place, systematically tighten all screws and bolts using the provided tools. Do not overtighten.
7. **Install Anti-Tip Kit:** Securely attach the anti-tip kit to the top of the organizer and to a sturdy wall stud, following the specific instructions provided with the kit. This step is essential for safety.




Image 4.1: Dimensional diagram of the purse organizer, illustrating its overall size and internal shelf spacing.



Image 4.2: Detailed views of key components: movable hooks, adjustable feet for stability, and the convenient fabric drawer.

5. USAGE (OPERATING)

The HOOBRO 3-Tier Purse Organizer is designed for versatile storage of handbags, accessories, and small items.

- **Shelves:** Utilize the three wooden shelves to store folded bags, baskets, hats, or other accessories. The tiered design allows for categorized organization.
- **Movable Hooks:** The 8 detachable double-L hooks on the side rails are ideal for hanging handbags, shoulder bags, and wallets. The hooks feature round balls on both ends to prevent items from falling and protect them from damage.
- **Tabletop Drawer:** The integrated fabric drawer provides discreet storage for smaller items such as jewelry, keys, or other personal belongings.
- **Placement:** This floor-standing unit is suitable for bedrooms, closets, or hallways, effectively utilizing

vertical space.

Your browser does not support the video tag.

Video 5.1: An official HOOBRO video demonstrating the features and usage of the Purse Organizer, including its shelves, hooks, and overall design.

6. MAINTENANCE

- **Cleaning:** Wipe the metal frame and wooden shelves with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Dusting:** Regularly dust the unit to maintain its appearance.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.
- **Drawer Care:** The non-woven fabric drawer can be spot cleaned with a mild detergent if needed. Allow to air dry completely.

7. TROUBLESHOOTING

- **Unit is Wobbly:**
 - Ensure the unit is placed on a flat, level surface.
 - Check that all screws and bolts are securely tightened.
 - Verify that the adjustable feet (if present) are properly adjusted to compensate for uneven floors.
- **Hooks are Loose or Fall Off:**
 - Ensure the hooks are correctly seated on the side rails. The design includes round balls to prevent accidental falls, so proper placement is key.
- **Difficulty Assembling:**
 - Refer to the detailed assembly guide and diagrams. Ensure you are using the correct hardware for each step.
 - Do not force parts together. If a part does not fit, re-check the instructions and part numbers.
- **Missing or Damaged Parts:**
 - If you discover any missing or damaged components upon opening the package, please contact HOOBRO customer service immediately for assistance.

8. SPECIFICATIONS

Model Number	BF97CJ01
---------------------	----------

Material	Engineered Wood, Metal, Non-Woven Fabric
Product Dimensions (L x W x H)	47.2" x 11" x 33.5" (120 cm x 28 cm x 85 cm)
Weight Capacity	120 lbs (54.4 kg)
Number of Shelves	3
Special Features	1 Fabric Drawer, 8 Movable Hooks, Anti-Tip Kit
Mounting Type	Floor Mount (Freestanding)
Color	Black + Rustic Brown

9. WARRANTY AND SUPPORT

HOOBRO provides customer support for its products. For warranty information, assistance with assembly, or to report missing/damaged parts, please contact HOOBRO customer service through the retailer where the product was purchased or visit the official HOOBRO website for contact details.