

Cavevine mahjongtable

Cavevine Automatic Mahjong Table

Model: mahjongtable

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your Cavevine Automatic Mahjong Table. Please read it thoroughly before assembly and use to ensure proper functionality and longevity of your product. This electric mahjong table features an advanced auto-shuffling mechanism, designed for efficient mixing of tiles within seconds. Its innovative foldable frame with universal wheels allows for easy mobility and storage. The table includes two sets of durable 42mm tiles, resistant to wear and cracking, featuring clear Arabic numerals and traditional symbols.



Image: The Cavevine Automatic Mahjong Table set up for a game.

SAFETY INFORMATION

WARNING: To prevent injury or damage, always adhere to the following safety guidelines:

- Always use the table on a stable, level surface to prevent tip-over.
- Keep small children and pets away from the playing area to prevent accidents.
- Never operate the table with wet hands or near water.
- Always unplug the table before assembly or disassembly.
- Do not attempt to repair or modify the electrical components.
- Keep the table and its components out of reach of young children to prevent choking hazards.

SETUP AND INSTALLATION

The Cavevine Automatic Mahjong Table ships in three secure packages and requires assembly. Two people can

assemble this mahjong table in approximately 30 minutes. Following the provided video instructions can simplify the process.

1. Unpacking and Component Identification

Upon receiving the product, you will find three boxes containing the Mahjong Machine Core, Mahjong Tiles with Folding Legs, and the Mahjong Machine Frame. Carefully open the boxes and identify all components.

Bidirectional Motor

Noise reduction, better quality for more stable shuffling



Noise Reduction



Sufficient Power



Intelligent Chip

Fast shuffling without jamming
Support different playing styles



Stable Operation



Longer life




Image: The three packages containing the mahjong table components.

2. Installing Folding Legs

1. Open the folding leg box and take out the folding legs, mahjong tiles, and related accessories. The box contains a screwdriver and an L-shaped hex key.
2. Place the column upside down on the floor and align the chassis hole with the column. Use the hex wrench to secure the bottom bolt.
3. Lock the brakes on the Cardan wheel and then turn the wheel clockwise to install it.
4. Insert the M5 bolt through the cushion, then use a screwdriver to lock the two cushions.

5. Fasten the two buckles to the folding foot with M4 bolts.

3. Installing the Movement (Main Machine)

1. Stand the mainframe on its side. Remove 8 metal connectors with a screwdriver. (Caution: Do not remove screws in contact with the ground to prevent scratches).
2. Open the main box from the bottom and carefully take out the main machine. Ensure the movement switch is facing up.
3. Remove four screws from both sides of the motor case and install the angle iron with four bolts. (Caution: Pay attention to the fixed direction of the angle iron. Some electrical boxes contain screws that need to be removed first with a socket wrench).
4. After correctly installing the HASP and the metal fastener, the HASP will be locked. Then, turn the Mahjong machine over.
5. Remove all pearl cotton protective blocks, cut off the ties, turn on the power switch, and turn on the power to check if the machine is working properly. (Note: Please follow the guidance of the video. If the machine is not working properly, please take video and photos and then contact us. We will help you to solve the problem).

4. Installing the Border

1. Open the package and remove the border and accessories.
2. Remove the 8 screws around the side of the movement in turn. (Caution: You need to lock the Cardan wheel brakes).
3. Connect the USB port and install the 4 frames to the host with the previously removed bolts.
4. Fix tapping screws on top of the border.
5. The plastic fasteners are connected head to tail to form a mouth shape. The components are installed by tapping. Finally, connect the power cord.

Installation Video Guide

Your browser does not support the video tag.

Video: Detailed installation manual for the Cavevine Automatic Mahjong Table.

OPERATING INSTRUCTIONS

Your Cavevine Automatic Mahjong Table is designed for ease of use with an intelligent shuffling system and user-friendly features.

1. Setting Mahjong Tile Counts

The table supports various mahjong tile counts for different game styles. To adjust the tile count:

1. Turn on the power switch (within ten seconds) located on the underside of the table.
2. Press the setting button to adjust to the desired gear level for the number of tiles. For American Mahjong (152 tiles), set to gear 03. For Chinese Mahjong (144 tiles), set to gear 05. For Chinese Mahjong (136 tiles), set to gear 09. For Chinese Mahjong (108 tiles), set to gear 18.

2. Using the Automatic Shuffling System

The table automatically shuffles and sets up tiles. Once tiles are placed into the central well, the system will mix and

arrange them into walls.




Image: The control panel for setting tile counts and managing the shuffle.

3. Additional Features

- **Cup Holders:** Built-in cup holders are provided for convenience.
- **Storage Drawers:** Utilize the integrated storage drawers for accessories.
- **USB Charging Ports:** USB charging ports are available for charging devices.

HIGH QUALITY MAHJONG TILES

152 Melamine solid tile imitation jade mahjong tile



Waterproofing



Anti-scratch



Anti-cracking

Image: Overview of the table's convenient features.

4. Tibetan Card Function (Manual Tile Loading)

The Tibetan card function allows for manual loading of tiles into the internal shuffle mechanism. This function must only be used when the table is in its non-folding, operational state. Using it while folded may cause the table to tip over and affect safety.

1. Ensure the control panel shows that the shuffle is complete (e.g., current setting shuffling 136 cards).
2. Press the lift key to raise the control panel.
3. Push the mahjong tiles into the internal shuffle area.
4. When all cards are pushed inside, long press the opposite dice key on the control panel to initiate the shuffle.

Video Guide for Setting Tile Counts

Your browser does not support the video tag.

Video: Instructions on how to set up different numbers of mahjong tiles for various game styles.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your mahjong table.

- **Cleaning:** The tabletop is waterproof for easy cleaning. Use a soft, damp cloth to wipe down surfaces. Avoid abrasive cleaners.
- **Tile Care:** The 42mm tiles are made from high-strength composite materials. Store them in their designated box or a suitable container when not in use to prevent loss or damage.
- **Mechanism:** Keep the shuffling mechanism free from debris. Periodically inspect for any foreign objects that might obstruct tile movement.
- **Storage:** When not in use, the table can be folded and stored. Ensure all locks are secured before moving the folded table.



Image: The mahjong table in its folded position for storage.

TROUBLESHOOTING

If you encounter any issues with your mahjong table, refer to the following common problems and solutions:

- **Tiles Jamming:** Occasionally, a tile may get jammed during shuffling. Carefully inspect the shuffling mechanism for any misaligned tiles and gently remove them. Ensure tiles are placed correctly into the well.
- **Machine Not Powering On:** Check if the power cord is securely plugged into both the table and the wall outlet. Verify that the power switch is in the 'ON' position.
- **Incorrect Tile Count:** Ensure the correct gear setting is selected for your desired game style (e.g., gear 03 for American Mahjong, 152 tiles). Refer to the 'Operating Instructions' section for details on adjusting settings.

- **Wheels Not Moving Freely:** Check if the brakes on the universal wheels are disengaged. Ensure no debris is obstructing the wheels.

For persistent issues not covered here, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Cavevine
Model Number	mahjongtable
Material	Metal, Plastic
Product Dimensions	37 x 37 x 31 inches (Unfolded)
Size	40" x 40" x 32" (Unfolded)
Item Weight	100 pounds
Color	Green
Style	Foldable
Tile Size	42mm (2 sets of 152 tiles)
Assembly Time	Approx. 30 minutes (two people)

WARRANTY AND SUPPORT

Your Cavevine Automatic Mahjong Table is backed by a comprehensive one-year warranty. Our professional customer service team is available to provide prompt assistance for any quality-related issues, which qualify for free returns, ensuring a risk-free purchase experience.

For support, please refer to the contact information provided with your purchase or visit the official Cavevine store online.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question