ChooChoo SC2301-BK-NEW-1

ChooChoo 67" Tall Bathroom Storage Cabinet Instruction Manual

Model: SC2301-BK-NEW-1

Brand: ChooChoo

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your ChooChoo 67" Tall Bathroom Storage Cabinet. Designed for versatile storage in various rooms, this cabinet features two doors, one drawer, and adjustable shelves to help organize your space efficiently.

2. Safety Information

To prevent injury, it is crucial to secure the cabinet to a wall using the provided anti-tip kit. Always follow the installation instructions carefully. Keep small parts away from children during assembly.



Image showing the anti-tip kit being installed to secure the cabinet to the wall, preventing accidental tipping.

3. Package Contents

Before beginning assembly, ensure all parts are present and undamaged. The package should include all necessary panels, hardware (screws, dowels, cam bolts), handles, hinges, and the anti-tip kit. Refer to the included parts list for a complete inventory.

4. Setup and Assembly

Assembly is required for this product. It is recommended to assemble the cabinet on a soft, clean surface to prevent scratches. Follow the step-by-step instructions provided in the separate assembly guide. Typically, assembly involves attaching panels using cam bolts and dowels, installing hinges for doors, and securing the drawer slides. An average assembly time is approximately 1-2 hours with basic tools like a Philips screwdriver.



Image of the fully assembled ChooChoo 67-inch Tall Bathroom Storage Cabinet in an ink black finish, positioned in a kitchen or dining area, showcasing its narrow profile and storage capabilities.

5. Operating Instructions

Your storage cabinet features two hinged doors and one pull-out drawer for organized storage. The upper and lower compartments behind the doors contain adjustable shelves. To adjust a shelf, remove any items, lift the shelf, and reposition the shelf pins to the desired height. Ensure all four pins are securely inserted before placing items on the shelf.



Image showing the ChooChoo 67-inch Tall Bathroom Storage Cabinet with its upper and lower doors open, revealing multiple shelves and a central drawer, demonstrating its internal storage capacity for various items.



Close-up image of the pull-out drawer of the ChooChoo 67-inch Tall Bathroom Storage Cabinet, showing its depth and capacity for storing smaller items like toiletries or office supplies.

6. Maintenance

To maintain the appearance and longevity of your cabinet, wipe surfaces regularly with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish. Periodically check all hardware connections to ensure they remain tight. If the cabinet is exposed to moisture, wipe it dry immediately.

7. Troubleshooting

Issue: Cabinet feels wobbly after assembly.

Solution: Ensure all cam bolts and screws are fully tightened. Verify that the cabinet is placed on a level surface. Re-check the anti-tip kit installation to ensure it is securely fastened to both the cabinet and the wall.

Issue: Drawer does not close flush.

Solution: Check the drawer slide installation. Ensure the slides are correctly aligned and attached to both the drawer and

the cabinet frame. Some users have found that using the "further back" setting for the drawer runners can resolve this.

8. Specifications

- **Brand:** ChooChoo
- **Model Number:** SC2301-BK-NEW-1
- **Color:** Ink Black
- **Material:** Wood (MDF)
- **Overall Dimensions (W x D x H):** 15.7" x 11.8" x 67"
- **Number of Doors:** 2
- **Number of Drawers:** 1
- **Features:** Adjustable Shelves, Freestanding, Anti-tip Kit Included
- **Recommended Use:** Bathroom, Living Room, Kitchen



Image displaying the dimensions of the ChooChoo 67-inch Tall Bathroom Storage Cabinet, highlighting its height (66.8 inches), width (15.7 inches), and depth (11.7 inches).



Detailed image of the ChooChoo 67-inch Tall Bathroom Storage Cabinet, pointing out key features such as decorative molding top, line design on doors, exquisite handle, metal hinges, adjustable shelves, and a stable base.

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official ChooChoo website. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question