

Cecotec PrecisionCare X-Trim Pro

Cecotec PrecisionCare X-Trim Pro Razor User Manual

Model: PrecisionCare X-Trim Pro

1. PRODUCT OVERVIEW

The Cecotec PrecisionCare X-Trim Pro is a professional electric razor designed for efficient and precise shaving. It features a durable design with a leather-finish body for a secure grip and an LED display for real-time information.

Key Features:

- **Powerful Motor:** Equipped with a 9000 RPM motor for effective trimming.
- **Long Battery Life:** A 1400mAh battery provides up to 2 hours of runtime on a single charge.
- **LED Display:** Shows battery percentage and active revolutions per minute (RPM).
- **Adjustable Speed Settings:** Three distinct speed levels to customize shaving intensity.
- **Titanium Coated Blades:** Designed for precise cutting and enhanced durability.
- **Protective Cover:** Included to safeguard blades when not in use.



Image 1.1: The Cecotec PrecisionCare X-Trim Pro Razor shown with its retail packaging.

2. SAFETY INFORMATION

Please read all safety instructions before using the device to prevent injury or damage.

- Keep the device away from water and liquids. Do not use it in the shower or bath.
- Ensure the charging port is dry before connecting the USB cable.
- Do not attempt to disassemble or repair the device yourself. Contact authorized service personnel for assistance.
- Keep out of reach of children.
- Use only the provided charging cable and accessories.
- If the device shows signs of damage, discontinue use immediately.

3. SETUP

3.1 Initial Charge

1. Before first use, fully charge the razor.
2. Connect the provided USB cable to the charging port on the razor and to a compatible USB power adapter (not included).
3. The LED display will indicate the charging status. A full charge typically takes approximately 2 hours.
4. Once fully charged, disconnect the razor from the power source.

3.2 Attaching the Protective Cover

The razor comes with a transparent protective cover. Place this cover over the blade head when the razor is not in use to protect the blades from damage and maintain hygiene.



Image 3.1: The razor positioned on a surface, demonstrating the protective cap and cleaning brush.

4. OPERATING INSTRUCTIONS

4.1 Powering On/Off

- To turn on the razor, press and hold the power button (usually located on the side).
- To turn off the razor, press and hold the power button again.



Image 4.1: Close-up of the razor in hand, highlighting the power button and speed adjustment controls.

4.2 Adjusting Speed Levels

The PrecisionCare X-Trim Pro offers three speed levels. Use the '+' and '-' buttons on the side of the razor to cycle through the available speeds. The active RPM will be displayed on the LED screen.

4.3 Shaving Technique

1. Ensure your skin is clean and dry for optimal results.
2. Gently press the razor head against your skin.
3. Move the razor in short, straight strokes against the direction of hair growth.
4. For sensitive areas, use a lighter touch and a lower speed setting.
5. The flexible head is designed to adapt to facial contours for a close shave.



Image 4.2: A user demonstrating the razor's application on the neck area.



Image 4.3: Detailed view of the razor head making contact with the skin for a close shave.

4.4 LED Display Information

The integrated LED display provides two key pieces of information:

- **Battery Percentage:** Indicates the remaining battery charge.
- **Revolutions Per Minute (RPM):** Shows the current operating speed of the motor.



Image 4.4: The razor held in hand, clearly showing the LED display with battery and RPM readings.

5. MAINTENANCE

Regular cleaning and proper care will ensure the longevity and performance of your PrecisionCare X-Trim Pro razor.

5.1 Cleaning the Blades

1. After each use, turn off the razor and remove the protective cover.
2. Gently tap the razor head to dislodge loose hairs.
3. Use the provided cleaning brush to remove any remaining hair particles from the blades and the internal chamber.
4. Do not use water directly on the blades unless specified as waterproof in the product specifications. This model is listed as waterproof.
5. Ensure the blades are completely dry before reattaching the protective cover.

5.2 Blade Care

The titanium-coated blades are designed for long-lasting sharpness. Avoid dropping the razor or exposing the blades to hard surfaces, as this can dull or damage them.

5.3 Storage

Store the razor in a cool, dry place with the protective cover in place. Avoid extreme temperatures and direct sunlight.

6. TROUBLESHOOTING

If you encounter issues with your PrecisionCare X-Trim Pro, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Razor does not turn on.	Low battery or no charge.	Charge the razor fully. Ensure the charging cable is properly connected.
Razor does not shave effectively.	Blades are clogged with hair or dull.	Clean the blades thoroughly using the cleaning brush. Ensure blades are not damaged.
Razor makes unusual noise.	Hair caught in the motor or blades.	Turn off the razor and clean the blade area. If the noise persists, discontinue use and contact support.
LED display is not working.	Device malfunction.	Ensure the device is charged. If the issue persists, contact customer support.

7. SPECIFICATIONS

Feature	Detail
Product Name	Laminating razor
Brand	Cecotec
Model Name	PrecisionCare X-Trim Pro
Item Model Number	A01_EU01_116284
Product Dimensions	12 x 6.6 x 3.2 cm
Item Weight	0.22 Kilograms (220 g)
Power Source	Battery Powered
Battery Type	Lithium-Ion
Battery Life	Up to 2 Hours
Special Features	Battery Indicator, Ergonomic Design, Portable, Rechargeable, Waterproof
Recommended Uses	Beard, Face
Included Components	Product, cleaning brush, instruction manual, USB cable







8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product

or contact Cecotec customer service directly. Contact details can typically be found on the manufacturer's official website or in the product packaging.

© 2025 Cecotec. All rights reserved.

Related Documents - PrecisionCare X-Trim Pro

	<p>Bamba PrecisionCare Skull Head Shaver User Manual</p> <p>User manual for the Cecotec Bamba PrecisionCare Skull head shaver, covering safety instructions, operation, cleaning, maintenance, head replacement, technical specifications, disposal, and warranty information.</p>
	<p>Cecotec Bamba PrecisionCare 7500 Power Blade User Manual</p> <p>This user manual provides comprehensive guidance for the Cecotec Bamba PrecisionCare 7500 Power Blade beard trimmer. It details safety instructions, operation, cleaning and maintenance procedures, technical specifications, and warranty information to ensure optimal use and longevity of the device.</p>
	<p>Cecotec Bamba PrecisionCare 5in1 Multigroomer User Manual</p> <p>User manual for the Cecotec Bamba PrecisionCare 5in1 Multigroomer, providing detailed instructions on safety, operation, maintenance, and technical specifications for this personal grooming device.</p>
	<p>Cecotec Bamba PrecisionCare Wet&Dry Hair Trimmer User Manual</p> <p>Comprehensive user manual for the Cecotec Bamba PrecisionCare Wet&Dry hair trimmer, covering safety instructions, operation, cleaning, maintenance, technical specifications, and warranty information.</p>
	<p>Cecotec BAMBA PrecisionCare Power Blade Titanium Hair Clipper User Manual</p> <p>User manual for the Cecotec BAMBA PrecisionCare Power Blade Titanium corded hair clipper, detailing safety, operation, maintenance, specifications, and warranty information.</p>
	<p>Cecotec PrecisionCare Multigrooming Trimmer User Manual</p> <p>Comprehensive user manual for the Cecotec PrecisionCare Multigrooming Trimmer, covering safety instructions, operation, cleaning, maintenance, and technical specifications.</p>