

Dubstep Powerblitz X4

Dubstep Powerblitz X4 20,000 mAh Power Bank User Manual

Model: Powerblitz X4 (NPB06)

- [Overview](#)
- [What's in the Box](#)
- [Features](#)
- [Setup](#)
- [Operation](#)
- [Safety](#)
- [Troubleshooting](#)
- [Specifications](#)
- [Warranty & Support](#)

1. PRODUCT OVERVIEW

The Dubstep Powerblitz X4 is a 20,000 mAh multi-device charging power bank designed for portable power needs. It features advanced two-way fast charging with USB and Type-C compatibility, offering 22.5W superfast charging. The device includes an LED battery indicator and supports simultaneous charging of up to three devices.



Image: Main product view of the Dubstep Powerblitz X4 power bank.

unbeatable speed, plugged in.



*maximum output with type-C & USB-A charging ports

Image: The Powerblitz X4 is compact and offers 20,000 mAh of power.

2. WHAT'S IN THE BOX

Upon unboxing your Dubstep Powerblitz X4, you will find the following items:

- 1x Dubstep Powerblitz X4 Power Bank
- 1x USB-A to Type-C Charging Cable

stay amped, stay unstoppable.



Image: Front view of the Powerblitz X4 power bank.

3. KEY FEATURES

- **Massive Capacity:** 20,000 mAh battery for extended power backup.
- **Superfast Charging:** 22.5W output for rapid device charging.
- **Versatile Charging:** Dual USB ports and Type-C compatibility for simultaneous charging of up to 3 devices.
- **Smart Digital Display:** Clear LED indicator shows precise battery levels.
- **Two-Way Fast Charging:** Supports fast charging for both the power bank and connected devices.
- **Multiple Protection Layers:** Built-in safeguards against overheating, overcharging, and short circuits.
- **Compact Design:** Stylish and portable for everyday use and travel.

one power endless energy.




Image: Overview of the Powerblitz X4's key features and technology.

multiple layers of safety



overheat
protection



overcharge
protection



short circuit
protection



powerblitz™
technology



Image: Close-up of the Powerblitz X4's digital display and charging ports.

4. INITIAL SETUP

Before first use, it is recommended to fully charge your Dubstep Powerblitz X4 power bank.

1. Connect the provided USB-A to Type-C cable to the power bank's Type-C input port.
2. Connect the other end of the cable (USB-A) to a compatible USB wall adapter (not included).
3. Plug the wall adapter into a power outlet. The LED display on the power bank will show the charging progress.
4. Charge until the LED display shows 100%.

dubstep

more power in your pocket.



powerblitz x4 \ 20000mAh

multi-device charging powerbank with dual USB port & type-C

Image: Side view of the Powerblitz X4, showing the various input/output ports.

5. OPERATING INSTRUCTIONS

5.1 Charging the Power Bank

To recharge your Powerblitz X4:

- Use the included USB-A to Type-C cable or a Type-C to Type-C cable (if available) to connect the power bank's Type-C input port to a power source.
- The LED display will show the current battery percentage and indicate charging status.

5.2 Charging Your Devices

The Powerblitz X4 can charge up to three devices simultaneously.

1. Connect your device's charging cable to one of the available output ports on the power bank (USB-1A, USB-2A, or Type-C output).
2. Connect the other end of the cable to your device.
3. The power bank will automatically begin charging your device. The LED display will show the power bank's remaining charge.

4. To stop charging, simply disconnect your device.

digital display



**two way
fast charging**
USB + type-C



**stylish
make**



power on/off



Image: The Powerblitz X4 charging multiple devices at once, demonstrating its multi-device capability.

power that moves with you.



Image: The Powerblitz X4 offers universal compatibility for a wide range of portable electronic devices.

6. SAFETY INFORMATION

Please read and follow these safety guidelines to ensure safe operation and prolong the life of your power bank:

- Do not expose the power bank to extreme temperatures (hot or cold), direct sunlight, or fire.
- Do not immerse the power bank in water or other liquids.
- Avoid dropping or subjecting the power bank to strong impacts.
- Do not attempt to disassemble, repair, or modify the power bank. This will void the warranty and may cause harm.
- Keep out of reach of children.
- Use only certified charging cables and adapters.
- If the power bank swells, emits smoke, or shows any other abnormal behavior, discontinue use immediately.

unlock the power.



Image: The Powerblitz X4 incorporates multiple safety features for reliable operation.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging	Cable not connected properly; faulty cable/adaptor; power bank fully charged.	Ensure connections are secure. Try a different cable or wall adapter. Check LED display for charge level.
Device not charging from power bank	Power bank battery low; faulty cable; device not compatible; power bank not turned on.	Recharge the power bank. Try a different charging cable. Ensure your device is compatible. Press the power button on the power bank.
Slow charging	Using a non-fast charging port/cable; multiple devices charging simultaneously.	Ensure you are using the 22.5W Type-C or appropriate USB port with a fast-charging cable. Charging multiple devices may reduce individual charging speed.
LED display not working	Power bank is off; internal issue.	Press the power button to activate the display. If issue persists, contact customer support.

8. PRODUCT SPECIFICATIONS

Model Name	Powerblitz X4
Model Number	NPB06
Battery Capacity	20,000 mAh
Max Output Power	22.5W
Connector Type	USB Type C
Number of Ports	3 (1x Type-C Input/Output, 1x USB-1A Output, 1x USB-2A Output)
Battery Cell Type	Lithium Polymer
Dimensions (L x W x Thickness)	14.9L x 6.6W x 2.5Th Centimeters
Item Weight	392 Grams
Color	Matte Black
Country of Origin	India

9. WARRANTY AND SUPPORT

The Dubstep Powerblitz X4 comes with a **6-month warranty** from the date of purchase.

To avail warranty services or for any product-related inquiries, please contact Dubstep customer support:

- **Phone Number:** [+91-8826257630](tel:+91-8826257630)
- **Email Id:** hello@Dubstepworld.com

Manufacturer: Nuworld Retail Private Limited

Address: Plot No.17-18, Pole No.9, PO Dhoolsiras, Dwarka, Sector-28, New Delhi - 110077

10. PRODUCT VIDEO GUIDE

Watch this official video for a quick overview of the Dubstep Powerblitz X4 power bank, demonstrating its features and usage.



Video: An overview of the Dubstep Powerblitz X4, showcasing its design, ports, LED indicator, and multi-device charging capabilities.