

Little Live Pets 26765

Little Live Pets Baby Monkey Minis Chikki Cherry Instruction Manual

Model: 26765

INTRODUCTION

The Little Live Pets Baby Monkey Minis Chikki Cherry is an interactive toy designed to provide engaging play with realistic sounds and reactions. This manual provides essential information for setting up, operating, and maintaining your new interactive pet. Chikki Cherry features soft dark brown fur and responds to touch with over 20 unique sounds and reactions. It can grip, grab, and hang using its hands and feet, and reacts when fed or when its thumb is placed in its mouth.

WHAT'S INCLUDED

- 1 x Interactive Plush Monkey (Chikki Cherry)
- 1 x Instruction Booklet (this manual)
- 2 x AAA Batteries (pre-installed or included separately)

SETUP

Battery Installation

Your Chikki Cherry toy requires 2 AAA batteries. These batteries are typically included with the product. If replacement is needed, follow these steps:

1. Locate the battery compartment on the toy. This is usually found on the back or bottom, secured with a small screw.
2. Using a small Phillips head screwdriver, carefully open the battery compartment.
3. Insert 2 new AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment and secure it with the screw.

Important: Always use new batteries of the same type. Do not mix old and new batteries, or different types of batteries. Dispose of used batteries responsibly.

OPERATING INSTRUCTIONS

Chikki Cherry is designed to be highly interactive, responding to various forms of engagement. Here's how to interact with your Baby Monkey Mini:

Activating Reactions and Sounds

- **Petting:** Gently pet Chikki Cherry on its head or back to hear adorable sounds and see realistic reactions. The toy has sensors that detect your touch.
- **Feeding/Thumb Sucking:** Place your finger into Chikki Cherry's mouth. It will react by making sounds as if sucking its thumb or being fed.
- **Gripping and Hanging:** Chikki Cherry features grippy hands and feet. You can use these to have the monkey hold onto your finger, arm, or other objects. This allows for various play scenarios, such as hanging upside down.



Image: Chikki Cherry reacts with sounds like a baby monkey.



Image: Chikki Cherry's grippy hands and feet allow it to hang and hold onto objects.

The toy is designed to provide over 20 different sounds and reactions, encouraging varied interaction and nurturing play.

MAINTENANCE

Cleaning

To clean your Chikki Cherry, gently wipe the surface with a damp cloth. Do not immerse the toy in water, as this can damage the electronic components. Avoid using harsh chemicals or abrasive cleaners.

Storage

When not in use for extended periods, it is recommended to remove the batteries to prevent leakage and potential damage to the toy. Store Chikki Cherry in a clean, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Solution
Toy does not respond or make sounds.	• Check if the batteries are correctly installed with the correct polarity. • Replace old batteries with new AAA batteries. • Ensure the toy's power switch (if present) is in the "ON" position.
Sounds are distorted or weak.	• This usually indicates low battery power. Replace the batteries.
Toy is not gripping properly.	• Ensure the hands and feet are clean and free from debris. • Apply gentle pressure to help the toy grip.

SPECIFICATIONS

Model Number	26765
Brand	Little Live Pets
Character	Chikki Cherry
Toy Figure Type	Stuffed Toy
Dimensions (L x W x H)	7.8 x 11 x 18.8 cm (3.07 x 4.33 x 7.4 inches)
Weight	200 g (0.44 lbs)
Power Source	Battery (2 x AAA required)
Recommended Age	4 - 15 years
Material	Plush (outer), Plastic (internal components)
Country of Origin	Vietnam
UPC	630996267653



Image: Chikki Cherry is approximately 7.4 inches (18.8 cm) tall.

WARRANTY INFORMATION

Specific warranty details for the Little Live Pets Baby Monkey Minis Chikki Cherry are not provided in the product information. Please refer to the packaging or contact the manufacturer directly for warranty terms and conditions.

SUPPORT

For further assistance, questions, or to explore other Little Live Pets products, please visit the official Little Live Pets website or contact their customer support.

Official Brand Store: [Little Live Pets Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question