



[Manuals.plus](#) /

> [ChooChoo](#) /

> ChooChoo SC2404-WN Farmhouse Bathroom Floor Cabinet Instruction Manual

ChooChoo SC2404-WN

ChooChoo SC2404-WN Farmhouse Bathroom Floor Cabinet Instruction Manual

Model: SC2404-WN | Brand: ChooChoo

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your ChooChoo SC2404-WN Farmhouse Bathroom Floor Cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference.




Image: The ChooChoo SC2404-WN Farmhouse Bathroom Floor Cabinet, showcasing its elegant walnut finish and four closed doors.

2. SAFETY INFORMATION

- Always place the product on a flat, steady, and stable surface.
- Keep all small parts and packaging materials away from children as they pose a choking hazard.
- This cabinet includes an anti-tip device. For enhanced stability and safety, especially in households with children or pets, it is recommended to secure the cabinet to a wall using the provided anti-tip kit.
- Do not overtighten or under-tighten cam-bolts during assembly. Ensure shoulders are flushed with the panel.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Storage Cabinet Panels
- 4 Doors
- Adjustable Shelves (3 included)

- Accessory Bag (containing hardware: cam bolts, cam locks, screws, metal hinges, knobs, magnets, anti-tip device, anchors, shelf supports)
- Instruction Manual

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this product. A Phillips head screwdriver is the only tool generally needed. Follow the step-by-step instructions provided in the included manual and the video below for a smooth assembly process.

Video: Official ChooChoo Furniture installation guide for the Bathroom Floor Cabinet. This video demonstrates the step-by-step assembly process, including how to fasten cam bolts and cam locks, attach side panels, install magnetic catches, and secure the top panel. It also shows the installation of the base, doors, and adjustable shelves.

Key Assembly Steps:

1. **Prepare Panels:** Insert cam bolts into designated pre-drilled holes on panels (e.g., panels 12 and 13). Ensure the shoulder of the cam bolt is flush with the panel.
2. **Attach Side Panels:** Connect side panels (e.g., panel 5) to the base panels (e.g., panel 12) using cam locks. Align the arrow on the cam lock to the cam bolt head and turn clockwise until snug.
3. **Install Magnetic Catches:** Secure magnetic catches (F) to the designated areas on the panels using screws (Q).
4. **Assemble Cabinet Structure:** Continue attaching panels (e.g., panel 7) to form the main structure, ensuring all cam locks are properly fastened.
5. **Attach Top Panel:** Secure the top panel (e.g., panel 13) to the assembled structure using cam bolts and cam locks.
6. **Assemble Base:** Connect the base components (e.g., panels 9, 10, 11) using wooden dowels (C) and cam bolts (A).
7. **Attach Base to Cabinet:** Secure the assembled base to the bottom of the cabinet using cam locks (B).
8. **Install Anti-Tip Device:** Attach the anti-tip device (M) to the back of the cabinet using screws (O). Secure the cabinet to the wall using the anchor (N) and screw (O) as per instructions.
9. **Attach Door Hinges:** Install hinges (G) onto the doors (1 and 2) using screws (L).
10. **Install Knobs:** Attach knobs (I) to the doors using screws (H).
11. **Mount Doors:** Attach the doors to the cabinet frame by screwing the hinges into the pre-drilled holes on the cabinet.
12. **Insert Shelf Supports:** Place shelf supports (P) into the desired holes inside the cabinet.
13. **Place Adjustable Shelves:** Position the adjustable shelves (14) onto the shelf supports.



Image: Detail of the adjustable shelf mechanism, highlighting the multiple height options for customization.

5. OPERATING INSTRUCTIONS

The ChooChoo SC2404-WN cabinet is designed for versatile storage in various rooms. Its four doors open to reveal spacious compartments.

- **Adjustable Shelves:** The cabinet features three adjustable shelves. These shelves can be repositioned to five different height levels to accommodate items of various sizes. Simply remove the shelf supports, adjust them to the desired height, and reinsert the shelf.
- **Magnetic Door Closures:** Each door is equipped with magnetic closures to ensure they remain securely shut when not in use, maintaining a tidy appearance and protecting contents.



Image: The cabinet with its doors open, demonstrating its ample storage capacity for various household items.

6. MAINTENANCE

To ensure the longevity and appearance of your cabinet, follow these maintenance guidelines:

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the woodgrain finish.
- **Moisture Resistance:** The cabinet is crafted from moisture-resistant MDF board, making it suitable for humid environments like bathrooms. However, prolonged exposure to excessive moisture should be avoided. Promptly wipe away any spills.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary, but do not overtighten.

7. TROUBLESHOOTING

If you encounter any issues during assembly or use, consider the following:

- **Wobbly Cabinet:** Ensure all cam bolts and cam locks are fully tightened. Verify that the cabinet is placed on a level surface. If necessary, use the anti-tip device to secure it to the wall.

- **Doors Not Closing Properly:** Check that the magnetic catches are correctly installed and aligned. Ensure hinges are securely fastened and not bent.
- **Missing Parts:** Refer to the 'Package Contents' section. If any parts are missing, contact ChooChoo customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	ChooChoo
Model Name	SC2404-WN
Color	Walnut
Product Dimensions	11.81"D x 23.62"W x 43.31"H
Item Weight	37.92 Pounds
Material	Engineered Wood (MDF Board)
Finish Type	Rustic Walnut
Number of Doors	4
Number of Shelves	3 (Adjustable to 5 heights)
Mounting Type	Floor Mount (Freestanding)
Special Feature	Adjustable Shelf, Magnetic Door Closures, Anti-Tip Device
Recommended Uses	Bathroom, Living Room, Kitchen, Entryway (for cosmetics, decorative items, linens, toiletries, towels, kitchen appliances)



Image: Dimensional diagram of the cabinet, illustrating its height, width, and depth, along with internal shelf spacing.

9. WARRANTY AND SUPPORT

ChooChoo is committed to providing high-quality furniture. For any questions regarding your product, including assembly assistance or missing parts, please contact ChooChoo customer support.

- **Customer Support Email:** sapun@choochoofurniture.com
- **Protection Plans:** Extended protection plans are available for purchase separately to cover your product beyond the standard warranty.