

[Manuals.plus](#) /

› [VINGLI](#) /

› VINGLI Wooden Patio Glider Bench (Model VL-G56001233) Instruction Manual

VINGLI VL-G56001233

VINGLI Wooden Patio Glider Bench (Model VL-G56001233)

Instruction Manual

1. INTRODUCTION

Thank you for choosing the VINGLI Wooden Patio Glider Bench. This manual provides essential information for the safe assembly, operation, and maintenance of your new glider. Please read these instructions carefully before assembly and retain them for future reference.

This glider bench is designed to provide a comfortable and relaxing seating experience for your patio, garden, or backyard. It features durable wooden construction, a smooth gliding mechanism, and convenient cup holders.



Image 1.1: Front view of the VINGLI Wooden Patio Glider Bench, showcasing its white finish and classic design.

2. SAFETY INFORMATION

- **Read All Instructions:** Ensure you understand all assembly and safety instructions before use.
- **Weight Capacity:** Do not exceed the maximum weight capacity of **800 lbs (approximately 363 kg)**. Overloading can cause damage or injury.
- **Assembly:** Assembly requires two people. Ensure all fasteners are securely tightened before use. Periodically check and re-tighten fasteners.
- **Stable Surface:** Place the glider on a flat, stable, and level surface to prevent tipping.
- **Children and Pets:** Keep children and pets away from the glider during assembly. Supervise children when they are near or using the glider.
- **Moving Parts:** Be aware of moving parts during operation to avoid pinching fingers or clothing.
- **Weather Conditions:** While designed for outdoor use, extreme weather conditions (strong winds, heavy snow) may require securing or storing the glider to prevent damage.

3. PACKAGE CONTENTS

Please verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, contact VINGLI customer support.

- Glider Seat and Backrest Assembly
- Left and Right Side Frames
- Gliding Mechanism Components
- Hardware Pack (bolts, washers, nuts, wrench)
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly is estimated to take approximately 45 minutes with two people. Ensure you have adequate space and all tools (a wrench is typically included in the hardware pack) before starting.

Step-by-Step Assembly Instructions:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a soft, clean surface to prevent scratches. Refer to the parts list (if provided separately) to identify each piece.
2. **Attach Side Frames:** Connect the left and right side frames to the main seat and backrest assembly using the provided bolts and washers. Do not fully tighten bolts at this stage.
3. **Install Gliding Mechanism:** Attach the gliding arms to the base of the side frames and the underside of the seat assembly. Ensure the mechanism moves freely before tightening.
4. **Secure All Fasteners:** Once all components are in place and aligned, systematically tighten all bolts and nuts using the provided wrench. Do not overtighten, but ensure they are snug.
5. **Final Check:** Gently test the glider's movement and stability. Ensure there are no loose parts or wobbles.



Image 4.1: The VINGLI Glider Bench positioned on a porch, illustrating its intended outdoor use.


5. OPERATING INSTRUCTIONS

Using your VINGLI Wooden Patio Glider Bench is straightforward:

- **Seating:** Sit comfortably on the bench, ensuring your weight is evenly distributed. The bench is designed to accommodate two adults.
- **Gliding Motion:** Gently push off the ground with your feet to initiate the smooth gliding motion. The stainless steel rocking arms ensure a quiet and consistent sway.
- **Cup Holders:** Utilize the integrated cup holders on each armrest for beverages. Ensure cups are stable before gliding.

Smooth and Gentle Rocking System

Glide Back and Forth



 No noise



Image 5.1: Illustration of the glider's smooth and gentle rocking system, highlighting its back-and-forth movement without noise.

6. MAINTENANCE

Proper maintenance will extend the life and appearance of your VINGLI Glider Bench.

- **Cleaning:** Wipe down the wooden surfaces with a soft cloth and mild soap and water solution. Rinse thoroughly and dry immediately to prevent water spots or wood damage. Avoid harsh chemicals or abrasive cleaners.
- **Wood Care:** The fir wood construction is naturally resistant to outdoor elements and is UV-resistant and waterproof. However, for prolonged life and to maintain its finish, consider applying a wood sealant annually, especially if exposed to direct sunlight and rain constantly.
- **Fastener Check:** Periodically (e.g., every 3-6 months) inspect all bolts and nuts. Re-tighten any that have become loose due to use or environmental changes.
- **Storage:** During prolonged periods of non-use or harsh winter weather, storing the glider indoors or covering it with a protective cover is recommended.



Image 6.1: Visual representation of the glider's solid wood material, highlighting its UV-resistant and waterproof properties for all-season durability.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Glider is wobbly or unstable.	Loose fasteners; uneven surface.	Check and tighten all assembly bolts. Ensure the glider is on a flat, level surface.
Squeaking noise during gliding.	Friction in the gliding mechanism; dry joints.	Apply a silicone-based lubricant (not oil-based) to the moving parts of the gliding mechanism.
Difficulty in gliding smoothly.	Obstruction in the mechanism; uneven assembly.	Inspect the gliding mechanism for any debris. Re-check assembly steps to ensure all parts are correctly aligned and not overtightened.

8. SPECIFICATIONS

Feature	Detail
Model Number	VL-G56001233
Brand	VINGLI
Material	Fir Wood
Color	White
Overall Dimensions (L x D x H)	48" x 30.9" x 35.4" (121.9 cm x 78.5 cm x 89.9 cm)
Seat Dimensions (L x D x H)	42.5" x 20" x 18.7" (108 cm x 50.8 cm x 47.5 cm)
Weight Capacity	800 lbs (363 kg)
Item Weight	37.5 lbs (17 kg)
Features	Cup Holders, High Backrest, Smooth Gliding Motion, Ergonomic Design, UV-resistant, Waterproof

Dimensions



Load capacity
of 800lbs



weight 43.3LBS



Image 8.1: Detailed dimensions of the VINGLI Glider Bench, including overall size, seat size, and cup holder diameter.

9. WARRANTY AND SUPPORT

For specific warranty information regarding your VINGLI Wooden Patio Glider Bench, please refer to the documentation included with your purchase or visit the official VINGLI website. Warranty terms typically cover manufacturing defects for a specified period from the date of purchase.

If you encounter any issues, require replacement parts, or have questions not addressed in this manual, please contact VINGLI customer support:

Website: Visit the [VINGLI Store on Amazon](#) (for general product information)

Email: Refer to your purchase invoice or product packaging for direct support contact.

Phone: Refer to your purchase invoice or product packaging for direct support contact.

Please have your model number (VL-G56001233) and date of purchase ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FLJBXY9S>

More documents and user manuals: <https://manuals.plus/>