

[Manuals.plus](#) /

> [Jugeman](#) /

> Jugeman V10 Smart Watch User Manual

Jugeman V10

Jugeman V10 Smart Watch User Manual

Model: V10

INTRODUCTION

This manual provides detailed instructions for the operation and maintenance of your Jugeman V10 Smart Watch. Please read this manual thoroughly to ensure proper use and to maximize the device's features. The Jugeman V10 is designed to assist with fitness tracking, health monitoring, and communication.



Image: Overview of the Jugeman V10 Smart Watch and its key functionalities.

PACKAGE CONTENTS

Verify that all items are present in the package:


- Jugeman V10 Smart Watch (1 unit)
- Magnetic Charging Cable (1 unit)
- Instruction Manual (1 unit)

HOW TO CONNECT




1. Download "FitCloudPro" from App store.

Bluetooth



2. Turn on the Bluetooth and GPS on your cell phone.



3. Search "V10" on the app and click to connect.



4. After pairing, you can manage your device on your phone.

Image: Contents of the Jugeman V10 Smart Watch package.

SETUP

1. Charging the Smart Watch

Before first use, fully charge the device. Connect the magnetic charging cable to the charging points on the back of the watch and to a USB power source. A full charge takes approximately 2.5 hours. The watch has a 380mAh battery, providing up to 7 days of normal usage and 30 days of standby time.




Image: Magnetic charging process for the Jugeman V10 Smart Watch.

2. Downloading and Pairing with the App

The Jugeman V10 Smart Watch uses the **FitCloudPro** app for full functionality and data synchronization. It is compatible with iOS 9.0+ and Android 5.0+.

1. Download the **FitCloudPro** app from your device's app store (Apple App Store for iOS, Google Play Store for Android).
2. Ensure Bluetooth and GPS are enabled on your smartphone.
3. Open the **FitCloudPro** app, navigate to the device section, and search for "V10".
4. Select "V10" to connect. Follow any on-screen prompts to complete the pairing process.

Built-in GPS for Precise Tracking

Track your activity routes in real time, track your current location, and improve the accuracy of your exercise data.



Image: Step-by-step guide for connecting the smart watch to the FitCloudPro app.

3. Bluetooth Calling Setup

After initial pairing, you may need to enable Bluetooth calling functionality separately:

- On your smartphone, go to Bluetooth settings.
- Look for a second "V10" or "V10_CALL" device and pair with it. This enables the call audio feature.
- Confirm permissions for contacts and call history within the **FitCloudPro** app.

OPERATING INSTRUCTIONS

1. Basic Navigation

The V10 Smart Watch features a 2.06" HD TFT color touch screen (320*385 resolution) and physical buttons for navigation.

- **Touch Screen:** Swipe up, down, left, or right to access different menus and functions. Tap to select.
- **Side Button(s):** Typically used for power on/off, returning to the home screen, or accessing the app list. Refer to the watch's interface for specific button functions.

Smart IP68 Waterproof Watch

Easily cope with dailywater use scenarios.



Rainy



Wash hands



Sweat



Warm Tips:

Not for hot water bath, sauna, or high and corrosive places like seawater, etc.

Image: The 2.06-inch HD display of the Jugeman V10 Smart Watch.

2. Customizing Watch Faces

The watch supports over 100 watch faces. You can change them directly on the watch or through the **FitCloudPro** app. The app also allows you to customize watch faces using photos from your phone gallery.




Image: Examples of customizable watch faces available for the V10 Smart Watch.

3. Bluetooth Calling and Notifications

Once paired correctly, you can make and receive calls directly from your wrist. The watch also displays message notifications from various apps.

- **Making Calls:** Access the dial pad or contact list on the watch to initiate calls.
- **Receiving Calls:** Answer or reject incoming calls directly from the watch screen.
- **Notifications:** Set up which app notifications you wish to receive via the **FitCloudPro** app. Notifications will appear with a gentle vibration.



Image: Bluetooth calling functionality on the Jugeman V10 Smart Watch.

Answer/Make Bluetooth Calls

View recent call records, set favorite contacts and dial numbers on your watch.



Image: Information notification feature of the Jugeman V10 Smart Watch.

4. AI Voice Assistant

Activate the built-in AI voice assistant to control various functions using voice commands. This feature allows for hands-free operation for tasks such as setting alarms, checking weather, or controlling music.

Information Notification

Supports email and message reminders from multiple applications, so you won't miss any important messages.



Image: Voice assistant functionality on the Jugeman V10 Smart Watch.

5. Sports Modes and GPS Tracking

The V10 Smart Watch includes over 110 sports modes and built-in high-precision GPS. The GPS allows for tracking routes (linear tracks) without needing your phone.

- **Selecting a Sport Mode:** Navigate to the sports section on your watch and choose from activities like running, cycling, hiking, yoga, and skiing.
- **Tracking Data:** The watch tracks heart rate, steps, calories, distance, and duration during workouts.
- **GPS Functionality:** For outdoor activities, ensure GPS is active on the watch to record your route. Review detailed statistics in the **FitCloudPro** app.




Image: Built-in GPS for precise tracking of activities.




Image: The 100+ sport modes available on the Jugeman V10 Smart Watch.

6. Health Monitoring

The watch provides 24/7 health tracking using an advanced LC10A optical sensor.

- **Heart Rate Monitoring:** Real-time heart rate data is continuously tracked.
- **Sleep Monitoring:** Automatically monitors sleep patterns, analyzing deep sleep, light sleep, and wake cycles.
- **Blood Oxygen (SpO2):** Measures blood oxygen levels.
- **Activity Tracking:** Records steps, walking distance, and calories burned throughout the day.
- **Menstrual Health Tracking:** Available for female users to track cycles.

Note: This device is not a medical device. Health data is for reference only and should not be used for medical diagnosis or treatment.



Image: All-day health tracking features including heart rate, sleep, and blood oxygen.

7. Other Smart Features

The V10 Smart Watch includes various tools for daily convenience:

- **Alarm Clock:** Set alarms directly on the watch or via the app.
- **Weather Updates:** View current weather conditions and forecasts.
- **Music Control:** Control music playback on your smartphone (play, pause, skip tracks).
- **Camera Control:** Use the watch as a remote shutter for your smartphone camera.
- **Sedentary Reminder:** Receive alerts to move after periods of inactivity.
- **Drinking Reminder:** Set reminders to stay hydrated.
- **Find My Phone:** Locate your paired smartphone.
- **Stopwatch/Timer:** Basic timing functions.



Image: Multifunctional features and practical tools of the Jugeman V10 Smart Watch.

MAINTENANCE

1. Water Resistance (IP68)

The Jugeman V10 Smart Watch is IP68 waterproof, meaning it is resistant to dust and can withstand immersion in water up to 1.5

meters for 30 minutes. It is suitable for daily activities such as washing hands, bathing, and exposure to rain or sweat.

- **Limitations:** The watch is **not** suitable for hot water baths, saunas, diving, or exposure to high-velocity water or corrosive liquids like seawater.
- After exposure to water, wipe the watch dry with a soft cloth.



Image: IP68 waterproof rating for the Jugeman V10 Smart Watch.

2. Cleaning

Regularly clean your watch and strap to prevent skin irritation and maintain functionality.

- Wipe the screen and watch body with a soft, damp, lint-free cloth.
- For the strap, use mild soap and water if necessary, then rinse thoroughly and dry completely before wearing.
- Avoid using harsh chemicals or abrasive materials.

3. Battery Care

- Avoid extreme temperatures, which can degrade battery life.
- Do not fully discharge the battery frequently. Charge it when the battery level is low.
- If storing the watch for an extended period, charge it to about 50% and store in a cool, dry place.

TROUBLESHOOTING

Watch Not Turning On

- Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes.
- Press and hold the power button for several seconds.

Cannot Pair with Phone

- Make sure Bluetooth and GPS are enabled on your phone.
- Ensure the **FitCloudPro** app is installed and open.
- Restart both your phone and the watch.
- Forget the device in your phone's Bluetooth settings and try pairing again through the app.
- Ensure the watch battery is not critically low.

Notifications Not Appearing

- Check notification settings within the **FitCloudPro** app to ensure desired apps are enabled.

- Verify that your phone's notification permissions are granted to the **FitCloudPro** app.
- Ensure the watch is connected via Bluetooth.

Inaccurate Health Data

- Ensure the watch is worn snugly on your wrist, not too tight or too loose.
- Clean the sensor on the back of the watch.
- Environmental factors and individual physiology can affect readings.

SPECIFICATIONS

Brand	Jugeman
Model	V10
Screen Size	2.06 Inches
Screen Resolution	320*385
Battery Capacity	380 mAh (Lithium Polymer)
Charging Time	Approx. 2.5 Hours
Battery Life (Normal Use)	Up to 7 Days
Standby Time	Up to 30 Days
Connectivity	Bluetooth
Water Resistance	IP68
Compatibility	iOS 9.0+ / Android 5.0+
Product Dimensions	1.8 x 9 x 14 cm
Item Weight	160 g



Image: Dimensions of the Jugeman V10 Smart Watch.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for warranty claims.

For further assistance, visit the official Jugeman website or contact their customer service department.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question