

[Manuals.plus](#) /

› [VINGLI](#) /

› VINGLI Wooden Patio Glider (Model: VL-G56001230) - Instruction Manual

VINGLI VL-G56001230

VINGLI Wooden Patio Glider (Model: VL-G56001230) - Instruction Manual

Brand: VINGLI

PRODUCT OVERVIEW

This manual provides detailed instructions for the assembly, operation, and maintenance of your VINGLI Wooden Patio Glider. Designed for outdoor use, this heavy-duty glider features an ergonomic design, a high backrest, and convenient cup holders, offering a comfortable and smooth rocking experience. Crafted from solid fir wood, it is built for durability and can support up to 600 lbs.



Image: The VINGLI Wooden Patio Glider in white, featuring a high backrest and armrests, situated on a green lawn.

Key Features:

- **Ergonomic Design:** Extended backrest and spacious seat for enhanced comfort, accommodating various body types.
- **Sturdy Frame:** Constructed from solid fir wood, ensuring robustness and durability with a 600 lbs weight capacity.
- **Smooth Rocking Mechanism:** Equipped with durable stainless steel rocking arms for silent and gentle gliding.
- **Versatile Outdoor Seating:** Ideal for porches, balconies, gardens, patios, and backyards, includes convenient cup holders.
- **Easy Assembly:** Designed for straightforward assembly, typically completed within 45 minutes with two people.

SAFETY INFORMATION

- Read all instructions carefully before assembly and use.
- Keep all small parts and packaging materials away from children.

- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight capacity of 600 lbs.
- Use on a flat, stable surface to prevent tipping.
- Avoid standing on the glider.
- Keep hands and fingers clear of moving parts during operation.

PARTS LIST

Before beginning assembly, verify that all components and hardware are present. Refer to the assembly video for visual identification of parts.



Image: Dimensions of the VINGLI Wooden Patio Glider, indicating a load capacity of 600 lbs and a weight of 31.5 lbs. Measurements are shown for height, width, and depth.

Note: The assembly video provides a detailed unboxing and parts check.

ASSEMBLY INSTRUCTIONS

Assembly typically requires two people and takes approximately 45 minutes. Follow the steps below and refer to the official installation video for visual guidance.

Your browser does not support the video tag.

Video: Official VINGLI Outdoor Glider Installation Video. This video demonstrates the step-by-step assembly process for the wooden glider chair.

Step-by-Step Guide:

1. **Unboxing and Parts Check:** Lay out all components and hardware. Compare them with the parts list shown in the video (0:05 mark) to ensure everything is present.
2. **Assemble the Base Frame (Part C1 & C2 with H):** Attach part H to C1 and C2 using the provided screws (8 x6, 45mm). (Refer to video 0:12-0:17)
3. **Connect Base Frame Sides (Part J):** Insert the three J parts between C1 and C2. (Refer to video 0:18-0:20)
4. **Secure Base Frame:** Use the 6x60mm bolts (Part 5) to secure the J parts to C1 and C2. (Refer to video 0:21-0:25)
5. **Attach Swing Arms (Part 3 & 6):** Connect the swing arms (Part 3) to the base frame using the 6x50mm bolts (Part 6). Ensure the bulge side of Part 3 and one washer face Part C. (Refer to video 0:26-0:30)
6. **Assemble Seat and Backrest (Part A & B):** Connect the seat (Part A) to the backrest (Part B) using the 8x50mm bolts (Part 2). (Refer to video 0:31-0:37)
7. **Attach Armrests (Part D, E, F, G1, G2):**
 - Mount the cup holder (Part D) onto either armrest (Part E or F) using the 4x15mm screws (Part 9) according to your preference. (Refer to video 0:38-0:42)
 - Attach the armrest supports (G1 and G2) to the armrests (E and F) using the 6x50mm bolts (Part 4). (Refer to video 0:43-0:50)
 - Connect the assembled armrests to the seat/backrest assembly using the 8x65mm bolts (Part 1). (Refer to video 0:51-0:56)
8. **Final Assembly:** Attach the seat/backrest assembly with armrests to the swing arms using the 6x45mm bolts (Part 7). (Refer to video 0:57-1:07)

OPERATING INSTRUCTIONS

Once fully assembled and all fasteners are secure, the VINGLI Wooden Patio Glider is ready for use. Sit comfortably on the seat and gently push off the ground with your feet to initiate the gliding motion. The glider is designed to provide a smooth, back-and-forth motion for relaxation.



Image: Illustration of the glider's smooth rocking mechanism, highlighting the gentle back and forth movement without noise.

The integrated cup holders on the armrests provide a convenient place for beverages. Ensure the glider is placed on a level surface for optimal performance and safety.

MAINTENANCE

- **Cleaning:** Wipe down the wooden surfaces with a damp cloth and mild soap. Avoid harsh chemicals that may damage the wood finish.
- **Wood Care:** As the glider is made of wood, consider applying a wood sealant or stain periodically to protect it from weather elements and prolong its lifespan, especially if exposed to direct sun and rain.
- **Fastener Check:** Regularly inspect all bolts and screws to ensure they remain tight. Re-tighten as needed to maintain stability and safety.
- **Lubrication:** If you notice any abnormal noise when using the glider, apply a small amount of lubricating oil to the bearings of the swing arms. (Refer to video 1:08-1:12)
- **Storage:** During prolonged periods of non-use or harsh weather conditions, it is recommended to cover the glider or

store it in a sheltered area to protect the wood.



Image: The glider is made from solid wood, designed to withstand various seasons, being UV-resistant, not prone to cracking, and waterproof.

TROUBLESHOOTING

- **Glider is wobbly:** Check all assembly bolts and screws. Ensure they are fully tightened. Verify that the glider is on a flat, even surface.
- **Squeaking noise during gliding:** Apply lubricating oil to the pivot points and bearings of the swing arms.
- **Difficulty assembling:** Review the assembly instructions and video carefully. Ensure all parts are correctly oriented and matched. If issues persist, contact customer support.
- **Wood cracking or splitting:** While the wood is treated, extreme weather can affect it. Consider applying a wood sealant. If significant damage occurs, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	VINGLI
Model Number	VL-G56001230
Color	White
Material	Wood (Fir Wood)
Product Dimensions (D x W x H)	28.7"D x 28"W x 44.8"H
Seat Depth	20 inches
Item Weight	31.5 Pounds
Maximum Weight Recommendation	600 Pounds
Assembly Required	Yes
Included Components	Glider (all necessary parts for assembly)

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the product packaging or contact VINGLI customer service directly. Keep your purchase receipt for any warranty claims.

Contact Information:

- Visit the [VINGLI Store on Amazon](#) for more products and support.
- Refer to the contact details provided in your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question