Conyat X5S

Conyat X5S Open-Ear Wireless Headphones User Manual

Model: X5S

1. Introduction

Thank you for choosing the Conyat X5S Open-Ear Wireless Headphones. This manual provides detailed instructions for the proper use, setup, and maintenance of your new headphones. Please read this manual thoroughly before use to ensure optimal performance and longevity of the product.

2. What's in the Box

Carefully unpack your Conyat X5S Open-Ear Wireless Headphones and ensure all items are present:

- Headphones (Left/Right) x 2
- USB-C Charging Cable x 1
- Portable Charging Case x 1
- User Manual x 1



Image: The Conyat X5S product packaging displaying the headphones, charging case, USB-C cable, and user manual.

3. Product Overview

The Conyat X5S headphones feature an open-ear design for comfort and situational awareness, advanced Bluetooth 6.0 connectivity, and intuitive touch controls.

Key Features:

- **Open-Ear Design:** Ergonomically designed to contour your ears without obstructing the ear canal, providing comfort and awareness of surroundings.
- **Bluetooth 6.0 Connectivity:** Ensures quick pairing and a stable, low-latency connection.
- **Immersive Sound:** Equipped with 14.2mm dynamic drivers for clear audio.
- **Clear Calls:** Features an ENC noise-cancelling microphone to reduce background noise.
- **Extended Playtime:** Up to 8-10 hours per charge, with a total of 40 hours using the charging case.
- **IP7 Water Resistance:** Protects against sweat and rain.
- **Smart Touch Control:** Manage music, calls, and voice assistant with simple taps.



Image: The Conyat X5S open-ear headphones and their compact charging case.

4. Setup

4.1. Charging the Headphones and Case

Before first use, fully charge the headphones and the charging case.

1. Place the headphones into the charging case.
2. Connect the USB-C charging cable to the charging port on the case and to a power source.
3. The LED display on the charging case will show the battery status. A full charge takes approximately 1.5 hours.



Image: The Conyat X5S headphones inside their charging case, illustrating the LED battery display and USB-C charging port.

4.2. Pairing with a Bluetooth Device

The headphones automatically enter pairing mode when removed from the charging case.

1. Open the charging case and remove both headphones. They will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, computer), enable Bluetooth.
3. Search for available Bluetooth devices and select "X5S" from the list.
4. Once connected, you will hear an audible confirmation, and the device will show "Connected".



Image: The Conyat X5S headphones in their charging case, with a smartphone screen showing the 'X5S' device connected via Bluetooth.

4.3. How to Wear the Headphones

For optimal comfort and sound, wear the headphones as follows:

1. Hook the end of the earphone onto your ear bone.
2. Rotate the earphone and slide it behind your ear.
3. Adjust the ear hook and pull it down slightly for a secure and comfortable fit.



Image: A visual guide demonstrating the correct method for wearing the Conyat X5S open-ear headphones.

5. Operating Instructions

5.1. Power On/Off

- **Power On:** Remove the headphones from the charging case. They will power on automatically.
- **Power Off:** Place the headphones back into the charging case. They will power off automatically.

5.2. Touch Controls

The Conyat X5S headphones feature intuitive touch controls on each earbud:

Action	Control
Play/Pause	Double-tap (L/R)
Answer/Hang up Call	Double-tap (L/R)
Refuse Incoming Call	Long tap 2s (L/R)
Volume Up	One-tap (R)
Volume Down	One-tap (L)
Previous Track	Long tap 2s (L)
Next Track	Long tap 2s (R)
Voice Assistant (Siri)	Triple-tap (L/R)



Image: A visual representation of the touch control gestures and their corresponding functions for the Conyat X5S headphones.

6. Maintenance

6.1. Cleaning

Regular cleaning helps maintain the performance and hygiene of your headphones.

- Wipe the headphones and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Ensure charging contacts are clean and dry before placing headphones in the case.

6.2. Water Resistance (IP7)

The Conyat X5S headphones are IP7 water-resistant, meaning they are protected against temporary immersion in water up to 1 meter for 30 minutes. They are resistant to sweat and rain, making them suitable for workouts and outdoor activities.

- Do not intentionally submerge the headphones in water for extended periods.
- Ensure the headphones are completely dry before placing them back in the charging case to prevent damage to the charging contacts.



Image: The Conyat X5S headphones shown with water splashes, highlighting their IP7 waterproof and sweatproof capabilities.

7. Troubleshooting

If you encounter issues with your Conyat X5S headphones, refer to the following common solutions:

Problem	Possible Solution
Headphones not pairing	Ensure headphones are charged. Turn off and on your device's Bluetooth. Forget "X5S" from your device's Bluetooth list and re-pair.
No sound or low volume	Check device volume and headphone volume. Ensure headphones are properly connected. Try re-pairing.
Headphones not charging	Ensure the charging cable is securely connected. Check if the charging case has power. Clean the charging contacts on both headphones and case.
Intermittent connection	Ensure no obstacles are between the headphones and your device. Stay within the Bluetooth range (typically 10 meters). Avoid strong electromagnetic interference.
Touch controls not responding	Ensure your fingers are clean and dry. Try restarting the headphones by placing them in the case and taking them out again.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Feature	Detail
Model Name	X5S
Brand	Conyat

Feature	Detail
Connectivity Technology	Bluetooth
Bluetooth Version	6.0
Earpiece Shape	Open-Ear
Audio Driver Type	Dynamic Driver (14.2mm)
Battery Life (Single Charge)	8-10 Hours
Total Playtime with Case	Up to 40 Hours
Charging Time	1.5 Hours (USB-C)
Water Resistance Level	IP7 (Waterproof)
Control Method	Touch
Special Features	Open-Ear Design, ENC Noise-Cancelling Microphone
Material	Plastic
Item Weight	3.84 ounces

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Conyat website. Keep your proof of purchase for warranty claims.

© 2025 Conyat. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question