

[Manuals.plus](#) /

> [Bellemave](#) /

> Bellemave Full Over Full Bunk Bed Instruction Manual

## Bellemave Full Over Full Bunk Beds

# Bellemave Full Over Full Bunk Bed Instruction Manual

Model: Full Over Full Bunk Beds (B0FLJNT1JS)

## 1. PRODUCT OVERVIEW

---

This manual provides detailed instructions for the assembly, safe use, and maintenance of your Bellemave Full Over Full Bunk Bed. Designed for efficiency and durability, this bunk bed offers a space-saving solution for bedrooms, dorms, or guest spaces, featuring a robust metal frame and integrated safety features.



Figure 1.1: Assembled Bellemave Full Over Full Bunk Bed (Black Ladder)

The Bellemave Full Over Full Bunk Bed is constructed with heavy-duty, rust-resistant metal, ensuring long-lasting durability and stability. It includes a built-in ladder and high guardrails for enhanced safety.

## 2. SAFETY INFORMATION

Your safety is paramount. Please read and adhere to all safety warnings and instructions before assembly and use.

- **Weight Capacity:** The upper bunk has a maximum weight capacity of 250 lbs. The lower bunk has a maximum weight capacity of 350 lbs. Do not exceed these limits.
- **Guardrails:** The upper bunk is equipped with guardrails on all four sides. Ensure they are properly installed and secured at all times.
- **Ladder:** The built-in ladder is designed for safe access to the upper bunk. It can only be installed on the right side of the bed. Always use the ladder when accessing or exiting the upper bunk.
- **Mattress Thickness:** Use only mattresses that comply with the recommended thickness to ensure the effectiveness of the guardrails. Refer to the specifications section for details.
- **No Jumping:** Do not allow jumping on the bed.

- **Assembly:** Ensure all connections are tight and secure before use. Periodically check and re-tighten hardware as needed.
- **Ventilation:** Ensure adequate ventilation around the bed.



Figure 2.1: Convenient Design and Safety Features

This product is CPC-certified, indicating it meets specific safety standards for children's products.

### 3. PRODUCT COMPONENTS

The Bellemave Full Over Full Bunk Bed is shipped in one compact box. Before beginning assembly, verify that all parts are present and undamaged. The main components include:

- Metal Frame Sections (Headboards, Footboards, Side Rails)
- Integrated Ladder
- Guardrails for Upper Bunk
- Metal Slats for Mattress Support
- Hardware Pack (Bolts, Nuts, Washers, Allen Wrench)



Figure 3.1: Key Product Attributes

### 4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the Bellemave Full Over Full Bunk Bed is designed to be straightforward. All parts are clearly

labeled, and detailed step-by-step instructions are included in the packaging. It is recommended to assemble the bed with at least two adults.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify each part using the provided parts list and diagrams.
3. Follow the numerical sequence of steps in the included assembly guide.
4. Ensure all bolts and screws are tightened securely, but do not overtighten to avoid stripping.
5. Confirm that the ladder is installed on the right side as specified for proper safety and stability.
6. Once assembled, double-check all connections for tightness and stability before use.

**Note: This bunk bed is designed as a single unit and cannot be converted into two separate beds.**

Your browser does not support the video tag.

Video 4.1: Assembly Overview for Full Over Full Metal Bunk Bed Black. This video provides a visual guide to the general assembly process and highlights the bed's features.

## 5. OPERATING INSTRUCTIONS (USAGE)

---

The Bellemave Full Over Full Bunk Bed is designed for efficient use of space, accommodating two full-size mattresses vertically. To ensure proper usage:

- Place appropriate full-size mattresses on both the upper and lower bunks. Ensure the upper bunk mattress does not exceed the recommended thickness to maintain guardrail effectiveness.
- Always use the built-in ladder for safe access to the upper bunk. Do not climb on the frame or other furniture.
- Ensure the area around the bed is clear of obstructions to allow for safe movement.

# SIZE:INCH




Figure 5.1: Product Dimensions for Planning Mattress Placement



Figure 5.2: Mattress Thickness and Safety Fence Details



Figure 5.3: Weight Capacity and Anti-Rust Coating

## 6. MAINTENANCE AND CARE

To ensure the longevity and continued safety of your Bellemave bunk bed, follow these maintenance guidelines:

- **Cleaning:** Wipe down the metal frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the powder-coated finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections. Re-tighten any loose hardware to maintain structural integrity and prevent squeaking.
- **Anti-Rust Coating:** The bed features an anti-rust coating for durability. Avoid scratching or chipping the coating, as this could expose the metal to moisture and lead to rust.
- **Movement:** When moving the bed, lift it rather than dragging it to prevent damage to the frame and your flooring.

## 7. TROUBLESHOOTING

If you encounter any issues with your Bellemave Full Over Full Bunk Bed, consider the following common solutions:

| Problem                      | Possible Cause                                     | Solution  |
|------------------------------|--|---|
| Bed feels wobbly or unstable | Loose hardware connections.                        | Check all bolts and screws and tighten them securely using the provided Allen wrench.                           |
| Squeaking noises             | Loose connections or friction between metal parts. | Re-tighten all hardware. Apply a small amount of silicone lubricant to connection points if squeaking persists. |
| Ladder feels loose           | Ladder attachment bolts are not tight.             | Ensure the ladder attachment bolts are fully tightened.   |

If you experience any problems not listed here, or if the issue persists after attempting the suggested solutions, please contact customer support.

## 8. SPECIFICATIONS

| Feature                        | Detail                   |
|--------------------------------|--------------------------|
| Size                           | Full Size                |
| Product Dimensions (L x W x H) | 77" x 56" x 54"          |
| Color                          | Black Ladder             |
| Finish Type                    | Powder Coated            |
| Material                       | Metal                    |
| Upper Bunk Weight Capacity     | 250 lbs                  |
| Lower Bunk Weight Capacity     | 350 lbs                  |
| Item Weight                    | 46 Pounds                |
| Assembly Required              | Yes                      |
| Included Components            | Guardrails, Ladder       |
| Model Number                   | Full Over Full Bunk Beds |
| UPC                            | 197793811927             |

## 9. WARRANTY AND SUPPORT

For any product inquiries, assistance with assembly, or to report issues, please contact Bellemave customer support directly.

**Customer Support Email:** [US-VC@bellemavehome.com](mailto:US-VC@bellemavehome.com)

Please provide your model number (B0FLJNT1JS) and a detailed description of your issue when contacting support to ensure a prompt resolution.