

Doro Doro Leva E21

DORO Leva E21 4G Telephone User Manual

Model: Doro Leva E21

1. IMPORTANT SAFETY INFORMATION

Please read this manual carefully before using your Doro Leva E21 telephone. Keep it for future reference. This section contains important information regarding safety, proper use, and disposal of the device.

- **Battery Safety:** Use only Doro approved batteries and chargers. Do not short-circuit, puncture, or expose the battery to extreme temperatures.
- **Hearing Protection:** Avoid prolonged listening at high volume levels to prevent possible hearing damage.
- **Driving Safety:** Always prioritize driving safety. Use hands-free accessories if permitted by law.
- **Medical Devices:** Maintain a safe distance between the phone and medical implants like pacemakers. Consult your physician and the medical device manufacturer for specific guidelines.
- **Disposal:** Dispose of the phone and battery responsibly according to local regulations. Do not dispose of with household waste.

2. GETTING STARTED

2.1 Unboxing Your Doro Leva E21

Your Doro Leva E21 package should contain the following items:

- Doro Leva E21 Mobile Phone
- Charging Station
- USB Cable
- Battery
- User Manual (this document)

2.2 Installing the SIM Card and Battery

Before you can use your phone, you need to insert the SIM card and the battery.

1. **Open the Back Cover:** Gently pry open the back cover of the phone.
2. **Insert SIM Card:** Locate the SIM card slot. Insert your SIM card with the gold contacts facing down and the cut corner aligned as shown in the diagram (if available). Ensure it clicks into place.
3. **Insert Battery:** Align the battery contacts with the phone's contacts and gently press the battery into its

compartment.

4. **Close the Back Cover:** Replace the back cover, ensuring it snaps securely into place.

2.3 Charging the Battery

It is recommended to fully charge the battery before first use.

1. Connect the USB cable to the charging station and then to a power outlet.
2. Place your Doro Leva E21 phone into the charging station. Ensure it is seated correctly and the charging indicator appears on the screen.
3. Alternatively, you can connect the USB cable directly to the phone's charging port.

2.4 Powering On/Off

- **To Power On:** Press and hold the red End/Power button () until the Doro logo appears.
- **To Power Off:** Press and hold the red End/Power button () until the power off options appear, then select 'Power off'.

3. UNDERSTANDING YOUR PHONE

3.1 Phone Overview

The Doro Leva E21 features a clear display and well-spaced, high-contrast buttons designed for ease of use. Below is an illustration of the phone's key components.





Image 3.1: Front view of the Doro Leva E21 phone, open. The top half shows the screen displaying '09:20', 'Menu', and 'doro' logo, along with 4G signal, battery, and sound icons. The bottom half shows the large, well-spaced keypad with dedicated buttons for call, end, navigation, camera, messages, and numeric input.

3.2 Keypad Functions

- **Call Button (Green):** Press to make a call or answer an incoming call.
- **End/Power Button (Red):** Press to end a call, reject an incoming call, or press and hold to power the phone on/off.
- **OK Button:** Confirms selections and opens menus.
- **Navigation Buttons (Up/Down/Left/Right):** Used to scroll through menus and options.
- **Star Button (*):** Used for special characters or functions.
- **Hash Button (#):** Used for special characters or functions.
- **Camera Button ():** Quick access to the camera function.
- **Message Button ():** Quick access to messages.
- **Volume Buttons:** Located on the side of the phone, used to adjust call volume or ringtone volume.

4. BASIC OPERATIONS

4.1 Making a Call

1. From the idle screen, enter the phone number using the numeric keypad.
2. Press the green Call button () to dial the number.
3. To end the call, press the red End button ().

4.2 Receiving a Call

- When an incoming call rings, press the green Call button () to answer.
- To reject an incoming call, press the red End button ().

4.3 Sending and Receiving Messages

1. **To Send a Message:** Press the Message button () or navigate to 'Menu' > 'Messages' > 'Write new message'. Enter your message using the keypad. Select the recipient from your contacts or enter a number. Send the message.
2. **To Read a Message:** When a new message arrives, an icon will appear on the screen. Press the Message button () or navigate to 'Menu' > 'Messages' > 'Inbox' to read it.

4.4 Managing Contacts

1. **Adding a Contact:** Navigate to 'Menu' > 'Contacts' > 'Add new contact'. Enter the name and phone number, then save.
2. **Searching for a Contact:** Navigate to 'Menu' > 'Contacts' > 'Search'. Enter the first few letters of the contact's name.

5. ADVANCED FEATURES

5.1 Using the Camera

Your Doro Leva E21 includes a camera for taking photos.

1. Press the Camera button () to open the camera application.
2. Frame your shot using the screen as a viewfinder.
3. Press the OK button to take a picture.
4. Photos are saved to the phone's gallery.

5.2 Doro Secure Button

The Doro Secure button (often located on the back of the phone) is an emergency assistance feature. When activated, it can automatically call and/or send an SMS message to pre-programmed emergency contacts.

- **Setup:** Configure emergency contacts and settings via 'Menu' > 'Settings' > 'Assistance'.
- **Activation:** Press and hold the Doro Secure button for a few seconds to activate the emergency sequence.

6. MAINTENANCE

6.1 Cleaning Your Phone

- Use a soft, slightly damp, lint-free cloth to clean the phone's surface.
- Avoid using harsh chemicals, cleaning solvents, or strong detergents.
- Do not allow moisture into any openings.

6.2 Battery Care

- Do not expose the battery to extreme temperatures.
- Avoid fully discharging the battery frequently.
- If the phone will not be used for an extended period, store it with a partially charged battery.

7. TROUBLESHOOTING

If you encounter issues with your Doro Leva E21, try the following solutions:

Problem	Possible Solution
Phone does not turn on	Ensure the battery is correctly inserted and charged. Connect the phone to the charger and try again.
No network signal	Check if the SIM card is properly inserted. Move to an area with better network coverage. Restart the phone.
Cannot make/receive calls	Verify network signal. Check if call barring is active. Ensure the number is correctly dialed.
Battery not charging	Ensure the charger/charging station is properly connected to both the phone and the power outlet. Check for damage to the cable or charger.
Sound issues	Adjust the volume using the side buttons. Ensure the phone is not in silent mode. Clean the speaker/microphone if obstructed.

8. SPECIFICATIONS

Key technical specifications for the Doro Leva E21:

Feature	Detail
Brand	Doro
Model Name	Doro Live E21
Operating System	Mocor RTOS
Screen Size	2.8 Inches
Display Type	LCD
Cellular Technology	4G
Wireless Network Technology	LTE
Memory Storage Capacity	128 GB
Flash Memory Installed Size	64 MB
Digital Storage Capacity	128 MB
Battery Power Rating	1150 mAh
Form Factor	Foldable Screen

Feature	Detail
Included Components	USB Cable
Item Model Number	Doro Leva E21


9. WARRANTY AND SUPPORT


Your Doro Leva E21 is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including the warranty period and coverage details.

For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Doro customer service. Contact information can typically be found on the Doro official website or on the warranty card.

- **Online Support:** Visit the official Doro website for FAQs, support articles, and contact options.
- **Phone Support:** Refer to your warranty documentation for regional support telephone numbers.

Related Documents - Doro Leva E21

Doro Leva E21  doro	Doro Leva E21 User Manual: Guide to Features and Operations Comprehensive user manual for the Doro Leva E21 clamshell mobile phone, detailing setup, calls, messages, settings, safety instructions, and specifications for easy and accessible communication.
Doro Leva E20/E21/E22 Repair Manual DFC-0610  doro	Doro Leva E20/E21/E22 Repair Manual Comprehensive repair manual for the Doro Leva E20, E21, and E22 mobile phones, covering disassembly, component replacement, assembly, and troubleshooting.
	Doro Leva L20 Quick Start Guide Quick start guide for the Doro Leva L20 mobile phone, covering setup, basic functions, calls, contacts, safety, and technical specifications.

Doro Leva E30/E31 Repair Manual DFC-0620 English  doro	Doro Leva E30/E31 Repair Manual: Disassembly, Assembly, and Troubleshooting Guide Comprehensive repair manual for Doro Leva E30 and E31 flip phones. Provides step-by-step instructions for disassembly, component replacement, assembly, and troubleshooting. Includes parts lists and diagrams. Find spare parts at doro.com/repair.
Doro Leva L11 Swedish  doro	Doro Leva L11 - Bruksanvisning Denna bruksanvisning ger detaljerade instruktioner för Doro Leva L11-telefonen, inklusive funktioner, inställningar och säkerhetsinformation, speciellt anpassad för senioranvändare.
	Doro 780X Quick Start Guide: Setup, Features, and Safety Get started with your Doro 780X mobile phone. This guide covers initial setup, making calls, using messaging, settings, safety instructions, and technical specifications for the Doro 780X.


Documents - Doro – Doro Leva E21



[Doro Leva E21 User Manual: Guide to Features and Operations](#)

Comprehensive user manual for the Doro Leva E21 clamshell mobile phone, detailing setup, calls, messages, settings, safety instructions, and specifications for easy and accessible communication.

lang:en score:56 filesize: 555.67 K page_count: 64 document date: 2025-05-26



[\[pdf\]](#) User Manual

Manual Doro Leva E20 E21 Finnish SuomiDoro Doromanual doro leva e21 fi v10 r22988doro
globalassets inriver resources manual r22988 |||

Doro Leva E21 Suomi Suomi Sislt Yleiskatsaus

..... 5 Onnittelut hankintasi
johdosta 6
Aloittaminen.....
lang:fi **score:51** filesize: 562.18 K page_count: 68 document date: 2025-05-26



[\[pdf\]](#) User Manual

Manual Doro Leva E20 E21 Swedish SvenskaDoro Doromanual doro leva e21 sv v10 r23000doro
globalassets inriver resources manual r23000 E21Doro r23000manual srsltid
AfmBOor6llqrcOVaSgXa9qzBRNGUtJUUTo2Sh1K3Rehy7pvRA1DKXnQu ||| ||| Doro Leva E21 Svenska
Svenska Innehll versikt 5 Gratulerar till ditt kp 6 Komma igng 6 Ta ut telefonen ur frpackningen 6 Stta i
SIM-kort, minneskort och batteri . 7 Ladda telefonen . 9 Spara energi . 10 Sl p och stnga av telefonen 10
Lra kn

Doro Leva E21 Svenska Svenska Innehll versikt

..... 5 Gratulerar till ditt
kp 6 Komma
igng.....
lang:no **score:42** filesize: 563.78 K page_count: 68 document date: 2025-05-26



[\[pdf\]](#) User Manual

manual doro leva e21 no v10 r22998doro globalassets inriver resources r22998 Doro Leva E21manual
r22998manual srsltid AfmBOoq9wULvHlo3vnL GThjpD96OGGSFz gb4l0ENuNymwrYp8ZNAVddoro ||| |||
Doro Leva E21 Norsk Norsk Innhold Oversikt 5 Gratulerer med anskaffelsen . 6 Komme i gang . 6 Pakk ut
den nye telefonen . 6 Sett inn SIM-kort, minnekort og batteri 7 Lade telefonen . 8 Spare strm 10 Sl
telefonen p og av 10 Bli kjent med tel

Doro Leva E21 Norsk Norsk Innhold Oversikt

..... 5 Gratulerer med
anskaffelsen 6 Komme i
gang.....
lang:no **score:41** filesize: 562.84 K page_count: 68 document date: 2025-05-26

[\[pdf\]](#) User Manual Quick Start Guide Frequently Asked Questions

Doro Leva E21 Hereby declares that the radio equipment type DFC 0610 E21 is in compliance with Directives 2014/53/EU and 2011/65/EU including manual doro leva e21 en v10 r22991 doro global assets inriver resources manual r22991 srsItd AfmBOorrE

t74iZfVYs9yObVRilGaXsfqWGwQeYx8lJIT6LNy8nmQYcP r22991 manual

t74iZfVYs9yObVRilGaXsfqWGwQeYx8lJIT6LNy8nmQYcPdoro E21 Download Hereby including Doro E22

Doro manual E21 Doro AfmBOorz8id4l z9EkxQCQzHjIQ76pQ9OTguOG3KuX0nmqrooymc3bdoro including Keypad tone to select sound you hear when press keys Mobile phones use signals mobile

phone network terrestrial network Doro AfmBOorvD1HRk6zr7HJFcuCTHYWtbcpFaQq3ZS7W4k4t

EIR0dniY2BQdoro AfmBOoo7ZbFncIz9GGa7L54mVpK67hopL2FhIb3rXGpR9fuY79p6QhO4doro

network Hereby AfmBOoob5FonnXKjcCmb3STTHDLk4rBwhRuUta4mvVnurNia24cL3Z2hdoro

AfmBOoqzGLW9YVmnrsC96arzfw3Jwbh24mNTcBVxvGXN19KamEeuovUUdoro

AfmBOoqBjentyuoPluMuLjkkR Q Pt4RkJuMBEzSqt2l z2rpMFha0 8doro

AfmBOooZEIn90caMKA77OvKXKqufdfoUJ98vOfG8fOBTIkg6Tf2 hSNsdoro AfmBOopL

5jefP0Dwjo9o5N0bdGUj41LgywWvh6irAi6VeqTfO1FVgEndoro ||| ||| Doro Leva E21 English English

Contents Overview 5 Congratulations on your purchase 6 Getting started . 6 Unbox your new phone . 6

Insert SIM card, memory card and battery . 7 Charge the phone . 8 Save energy 10 Turn the phone on

and off . 1 ||| Doro Leva E21 English English Contents Overview 5 Congratulations on your purchase 6

Getting started . 6 Unbox your new phone . 6 Insert SIM card, memory card and battery . 7 Charge the

phone . 8 Save energy 10 Turn the phone on and off . 1 ||| Doro Leva E21 English English Contents

Overview 5 Congratulations on your purchase 6 Getting started . 6 Unbox your new phone . 6 Insert SIM

card, memory card and battery . 7 Charge the phone . 8 Save energy 10 Turn the phone on and off . 1 |||

Doro Leva E21 English English Contents Overview 5 Congratulations on your purchase 6 Getting started

. 6 Unbox your new phone . 6 Insert SIM card, memory card and battery . 7 Charge the phone . 8 Save

energy 10 Turn the phone on and off . 1 ||| Doro Leva E21 English English Contents Overview 5

Congratulations on your purchase 6 Getting started . 6 Unbox your new phone . 6 Insert SIM card,

memory card and battery . 7 Charge the phone . 8 Save energy 10 Turn the phone on and off . 1 ||| Doro

Leva E21 English English Contents Overview 5 Congratulations on your purchase 6 Getting started . 6

Unbox your new phone . 6 Insert SIM card, memory card and battery . 7 Charge the phone . 8 Save

energy 10 Turn the phone on and off . 1 ||| Doro Leva E21 English English Contents Overview 5

Congratulations on your purchase 6 Getting started . 6 Unbox your new phone . 6 Insert SIM card,

memory card and battery . 7 Charge the phone . 8 Save energy 10 Turn the phone on and off . 1 ||| Doro

Leva E21 English English Contents Overview 5 Congratulations on your purchase 6 Getting started . 6

Unbox your new phone . 6 Insert SIM card, memory card and battery . 7 Charge the phone . 8 Save

energy 10 Turn the phone on and off . 1 ||| Doro Leva E21 English English Contents Overview 5

Congratulations on your purchase 6 Getting started . 6 Unbox your new phone . 6 Insert SIM card,

memory card and battery . 7 Charge the phone . 8 Save energy 10 Turn the phone on and off . 1

Doro Leva E21 English English Contents Overview

..... 5 Congratulations
on your purchase 6 Getting started
.....

lang:en score:38 filesize: 555.67 K page_count: 64 document date: 2025-05-26





UTILISATION,
ÉCOUTE ET
LECTURE
FACILITÉES

DORO Leva E20

POURQUOI DORO ?

Alors que les technologies évoluent vite et deviennent plus complexes, chez Doro, nous avons fait le choix de mettre l'accent sur la simplicité. C'est ce que nos utilisateurs recherchent, et c'est pourquoi la simplicité est au cœur de l'ADN des téléphones Doro. Vous pourrez utiliser votre téléphone facilement et rapidement pour téléphoner, envoyer des messages ou regarder des photos.

TÉLÉPHONE À CLAPET FACILE À UTILISER POUR DES CONVERSATIONS CLAIRES

Le Doro Leva E20 est idéal pour les personnes qui recherchent un téléphone portable à usage facile à utiliser et un son exceptionnel. Pour des appels, envoyez des SMS et prenez des photos en toute simplicité grâce aux touches parfaitement espacées et contrastées et au grand écran de 2,8 pouces. Parmi les autres caractéristiques, citons une qualité audio améliorée grâce à la technologie HD Voice, la compatibilité avec les appareils auditifs (HAC) et des contacts de secours à proximité pour les favoris, l'appelant d'origine et les messages. La fonction d'assistance Doro-Secure Button peut également être utilisée pour alerter des contacts de confiance si vous avez besoin d'aide.

LES AUTRES, C'EST LA QUALITÉ

Àvec nos téléphones, les utilisateurs peuvent apprécier, chez Doro, nos valeurs : nos téléphones sont un vrai plaisir à utiliser et sont toujours étonnamment confortables, même avec quelques difficultés d'audition, le son est de qualité. Nos téléphones offrent un son clair et puissant, proposent un écran contrasté, des touches également et une interface intuitive. Nous prenons en compte tous les besoins spécifiques de votre vie : nous pouvons offrir facilement votre téléphone.

[pdf]

UTILISATION ÉCOUTE ET LECTURE FACILITÉESLEVAE20GRAPHITEprocie dudelange datas Visuels
fiches techniques LEVAE20GRAPHITE |||

UTILISATION, COUTE ET LECTURE FACILITES DORO Leva E20 POURQUOI
DORO Alors que les technologies v ... t LTE DL VoLTE Cat 4 Gnral ID E20/E21 Nom
du modle DFC-0610 Nom commercial Doro Leva E20 / **Doro Leva E21** Format Clam
Taille Taille du tlphone HxLxP mm 107.7*56.7*20.5 Poids du tlphone ...
lang:fr **score:20** filesize: 819.85 K page_count: 3 document date: 2025-09-11