Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hupoaf H87

Hupoaf H87 Wireless Sport Earbuds Instruction Manual

Model: H87

Introduction

Thank you for choosing the Hupoaf H87 Wireless Sport Earbuds. These earbuds are designed to provide an immersive audio experience with deep bass and clear calls, featuring a secure ear hook design ideal for active lifestyles. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

What's in the Box

- 1 x Fast Charging Case
- 2 x Wireless Earbuds Sport
- 3 x Pairs of Earplugs (S, M, L)
- 1 x USB-C Charging Cable
- 1 x Instruction Manual



Image: All items included in the Hupoaf H87 Wireless Sport Earbuds package.

Product Overview

The Hupoaf H87 earbuds feature advanced technology for superior sound and user convenience.

- **Immersive Sound:** Equipped with 14.2mm dynamic drivers for powerful deep bass and crisp treble.

- **ENC Noise Cancellation:** Built-in high-performance ENC noise-cancelling microphones reduce background noise for crystal-clear calls.
- **Secure Fit:** Ergonomic ear hook design with soft silicone material ensures stability during high-intensity activities.
- **Bluetooth 5.4:** Provides faster, more stable connections with reduced delays and wide compatibility across iOS, Android, and Windows devices.
- **Long Battery Life:** Up to 10 hours of single playback, with a total of 50 hours using the charging case. USB-C fast charging fully charges in 1.5 hours.
- **IP7 Waterproof:** Designed to resist sweat, rain, and short-term immersion, making them ideal for sports enthusiasts.
- **Smart Touch Control:** Easily manage music, calls, volume, and voice assistant with simple touch gestures.
- **LED Display:** Real-time display of charging case power and individual earbud charging status.



Image: Hupoaf H87 earbud highlighting ENC Noise Canceling for clear calls.



Image: Detailed internal structure of the Hupoaf H87 earbud, emphasizing its 14.2mm dynamic driver for high-fidelity stereo sound.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case. Place the earbuds into the charging case. Connect the USB-C charging cable to the port on the back of the case and to a power source. The LED display on the case will show the battery percentage of the case and the charging status of each earbud.

- Charging Time: Approximately 1.5 hours for a full charge.
- Earbud Playback: Up to 10 hours on a single charge.
- Total Playtime: Up to 50 hours with the charging case.



Image: The Hupoaf H87 charging case with earbuds inside, showing the digital battery percentage for the case and individual earbud charge indicators.

2. Pairing with Your Device

The earbuds will automatically enter pairing mode when removed from the charging case.

1. Ensure your device's Bluetooth is turned on.
2. Open the charging case and remove both earbuds. They will automatically power on and enter pairing mode.
3. On your device, search for Bluetooth devices and select "H87" from the list.
4. Once connected, you will hear a voice prompt confirming successful pairing.
5. The earbuds are compatible with iOS, Android, and Windows devices.




Image: A smartphone displaying the Bluetooth pairing menu, with the Hupoaf H87 earbuds visible and connected, illustrating quick and broad compatibility.

3. Wearing the Earbuds

For optimal sound quality and a secure fit, choose the correct ear tip size and adjust the ear hooks.

1. Select the ear tips (S, M, L) that best fit your ear canal.
2. Place the earbud into your ear canal and gently rotate it to ensure a snug fit.
3. Adjust the flexible ear hook over your ear to secure the earbud in place.



Image: The Hupoaf H87 earbuds are shown with their flexible ear hooks and various ear tip sizes, emphasizing their suitability for sports and IP7 waterproof design.

Operating Instructions

The Hupoaf H87 earbuds feature intuitive touch controls for easy management of your audio and calls.

Touch Controls Overview

- **Play/Pause:** Single tap on either earbud.
- **Volume Up:** Single tap on the Right earbud.
- **Volume Down:** Single tap on the Left earbud.
- **Next Track:** Press and hold the Right earbud for 2 seconds.
- **Previous Track:** Press and hold the Left earbud for 2 seconds.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Activate Voice Assistant (Siri/Google Assistant):** Triple tap on either earbud.



Image: A visual guide to the smart touch controls on the Hupoaf H87 earbuds, showing icons for various functions like play/pause, volume, calls, and Siri activation.

Maintenance

Proper care will extend the life and performance of your Hupoaf H87 earbuds.

- **Cleaning:** Regularly wipe the earbuds and charging case with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** The earbuds are IP7 waterproof, meaning they can withstand sweat, rain, and short-term immersion in water. However, they are not suitable for swimming or prolonged submersion. Ensure the charging port is dry before charging.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged. Avoid extreme temperatures.




Image: The Hupoaf H87 earbuds are shown partially submerged in water, demonstrating their IP7 waterproof capabilities, suitable for rain, splashes, and sweat.

Troubleshooting

If you encounter any issues with your earbuds, try the following steps:

- **No Sound:** Ensure earbuds are charged and properly paired. Check device volume.
- **Pairing Issues:** Place earbuds back in the case, then remove them to re-enter pairing mode. Forget "H87" from your device's Bluetooth list and try pairing again.
- **Intermittent Connection:** Ensure earbuds are within Bluetooth range (20 meters) of your device. Avoid obstacles that may interfere with the signal.
- **Earbuds Not Charging:** Check if the charging cable is securely connected and the charging case has power. Clean the charging contacts on both the earbuds and the case.

Specifications

Feature	Specification
Model Name	H87

Feature	Specification
Connectivity Technology	Wireless (Bluetooth 5.4)
Bluetooth Range	20 Meters
Noise Control Features	ENC Noise Cancellation, Sound Isolation
Water Resistance Level	IP7 Waterproof
Battery Life (Earbuds)	10 Hours (single charge)
Total Battery Life (with case)	50 Hours
Charging Time	1.5 Hours
Control Type	Touch Control
Ear Placement	In Ear
Form Factor	Over Ear
Audio Driver Type	Dynamic Driver
Item Weight	5 ounces
Product Dimensions	1.18 x 0.79 x 1.18 inches

Warranty and Support

Hupoaf is committed to your satisfaction.

- **1-Year Warranty:** Your Hupoaf H87 earbuds come with a 1-year warranty from the date of purchase.
- **Customer Service:** For any questions, troubleshooting assistance, or warranty claims, please contact our dedicated 24/7 customer service team. Refer to the contact information provided in the packaging or on the official Hupoaf website.

Official Product Video

Your browser does not support the video tag.

Video: An official Hupoaf video showcasing the Hupoaf Wireless Earbuds Sports with Earhook, demonstrating their features and use for running and active lifestyles.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FLJWRTFY

More documents and user manuals: **https://manuals.plus/**