

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Blaupunkt](#) /

› **Blaupunkt BTW300 Xtreme Moksha Maxbuds User Manual**

## Blaupunkt BTW300

# Blaupunkt BTW300 Xtreme Moksha Maxbuds User Manual

Model: BTW300

Brand: Blaupunkt

## INTRODUCTION

Welcome to the user manual for your Blaupunkt BTW300 Xtreme Moksha Maxbuds. These true wireless earbuds are designed to provide a premium audio experience with advanced features such as True Active Noise Cancellation (ANC), a long-lasting 700mAh battery, Quad AI Microphones with Crisp Environmental Noise Cancellation (ENC), Blink Pair technology for instant connectivity, Dual Pairing, and Dual EQ modes for customized sound. Please read this manual carefully to ensure proper use and optimal performance of your device.

Your browser does not support the video tag.

*Video: Overview of Blaupunkt BTW300 Xtreme Moksha Maxbuds features.*

## WHAT'S IN THE BOX

Upon unboxing your Blaupunkt BTW300 Xtreme Moksha Maxbuds, you will find the following items:

- True Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual
- Additional Eartips (various sizes)



## ORDINARY ANC EARBUD PROBLEMS

1. ANC consumes a lot of power
2. The battery is too small for continuous ANC
3. Switching Off ANC is the only solution

# THE TECHNOLOGY OF ALL DAY ANC

The Largest  
Battery -700mAh

Moksha True  
ANC Efficiency

Power for More  
than 7 Charges

100 years  
brand est. 1924

*Image: Front view of the Blaupunkt BTW300 Xtreme Moksha Maxbuds earbuds and their charging case.*

## SETUP

### Initial Charging

Before first use, fully charge your Maxbuds. Place both earbuds into the charging case and connect the case to a power source using the provided USB cable. The LED indicators on the case will show the charging status. A full charge ensures optimal battery performance.

### Pairing with a Device (Blink Pair Tech)

1. Open the charging case. The earbuds will automatically enter pairing mode (Blink Pair Tech).
2. On your device (smartphone, tablet, laptop), go to Bluetooth settings.
3. Select "Blaupunkt BTW300" from the list of available devices.
4. Once connected, you will hear an audio prompt, and the LED indicators on the earbuds will change.

### Dual Pairing

The BTW300 Maxbuds support dual pairing, allowing you to connect to two devices simultaneously. To use this feature:

1. Pair the earbuds with your first device as described above.
2. Disconnect the earbuds from the first device (or turn off Bluetooth on the first device temporarily).
3. Pair the earbuds with your second device.
4. Reconnect the earbuds to the first device from its Bluetooth settings. The earbuds should now be connected to both devices, allowing seamless switching between them.

## OPERATING INSTRUCTIONS

---

### Touch Controls

The BTW300 Maxbuds feature intuitive touch controls on each earbud. Specific functions may vary, but common controls include:

- **Single Tap:** Play/Pause music, Answer/End call.
- **Double Tap (Left/Right):** Previous/Next track.
- **Triple Tap (Left/Right):** Volume Down/Up.
- **Long Press:** Activate Voice Assistant, Toggle ANC/Transparency Mode.

### Active Noise Cancellation (ANC)

The True Active Noise Cancellation feature blocks out ambient distractions, providing an immersive listening experience. You can toggle ANC on/off or switch to Transparency Mode (if available) via the touch controls or your connected device's settings.

# WE'VE TAKEN MIC TECH TO THE NEXT LEVEL

QUAD MICS + ENC.  
QUAD MICS + ENC.  
QUAD MICS + ENC.



*Image: Visual representation of the All Day ANC technology, highlighting its efficiency and battery capacity.*

# THE PRIDE OF A 100 YEAR OLD ICONIC GERMAN BRAND

GERMAN PRECISION  
GERMAN PRECISION  
GERMAN PRECISION  
GERMAN PRECISION



*Image: Depiction of Moksha True ANC, emphasizing effective noise cancellation.*

## Quad AI Microphones with Crispr ENC

The Maxbuds are equipped with four AI-enhanced microphones (two per earbud) and Crispr Environmental Noise Cancellation technology. This ensures crystal-clear voice pickup during calls by filtering out background noise, allowing your voice to be heard clearly even in noisy environments.

# TOGGLE BETWEEN TWO SOUND MODES WITH A TAP



*Image: Illustration of the Quad AI Mics with Crispr ENC technology for clear communication.*

## Dual EQ Modes

Customize your audio experience with Dual EQ Modes: Bass Boost and Balanced Mode. You can switch between these profiles with a single tap, allowing you to tailor the sound to your preference, whether you desire deeper bass or a more balanced audio output.

# THE LARGEST BATTERY. EVER!

LARGEST BATTERY  
LARGEST BATTERY  
LARGEST BATTERY  
LARGEST BATTERY



700mAh  
BEAST BATTERY

7+ CHARGES  
AND MORE

100 years  
brand est. 1924

*Image: Visual representation of Dual EQ Modes, indicating customizable sound profiles.*

## CHARGING

The BTW300 Maxbuds come with a 700mAh mega battery in the charging case, providing extended playback time. The earbuds themselves also have internal batteries. To charge:

- **Earbuds:** Place the earbuds into the charging case. They will automatically begin charging.
- **Charging Case:** Connect the charging case to a USB power adapter using the provided USB cable. The LED indicators on the case will show the charging progress.

A fully charged case can provide multiple charges to the earbuds, extending your listening time significantly.

# INSTANT CONNECTION WITH TWO DEVICES

BLINKPAIR TECH  
BLINKPAIR TECH  
BLINKPAIR TECH  
BLINKPAIR TECH



100 years  
brand est. 1924

*Image: A user enjoying music with the earbuds, illustrating the 'All Day Playtime' capability.*

## MAINTENANCE

To ensure the longevity and optimal performance of your Blaupunkt BTW300 Xtreme Moksha Maxbuds, follow these maintenance guidelines:

- Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- Eartips:** Remove and clean the eartips periodically. Ensure they are completely dry before reattaching.
- Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- Avoid Water:** While the earbuds may have some water resistance, avoid submerging them in water or exposing them to excessive moisture.
- Temperature:** Do not expose the earbuds to extreme temperatures (hot or cold).

## TROUBLESHOOTING

If you encounter any issues with your Maxbuds, refer to the following common troubleshooting steps:

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Place them back in the case, close, then open again to re-enter pairing mode. Check your device's Bluetooth settings and forget previous connections if necessary.
Only one earbud working	Place both earbuds back in the charging case, close the lid, wait a few seconds, then open again. Ensure both earbuds are charged.
Low volume or poor sound quality	Adjust volume on both your device and earbuds. Ensure eartips are properly sealed in your ear. Clean any debris from the earbud speakers. Check EQ settings.
ANC not working effectively	Ensure earbuds are properly seated in your ears for a good seal. Toggle ANC on/off using touch controls or device settings.
Earbuds not charging	Ensure the charging cable is securely connected to both the case and power source. Check if the charging case itself has power. Clean charging contacts on both earbuds and case.

If the issue persists, please contact customer support.

## SPECIFICATIONS

Detailed technical specifications for the Blaupunkt BTW300 Xtreme Moksha Maxbuds:

- **Model Name:** BTW Series
- **Connectivity Technology:** Wireless (Bluetooth)
- **Control Method:** Touch
- **Noise Control:** Active Noise Cancellation (True ANC)
- **Microphones:** Quad AI Mics with Crispr ENC Tech
- **Battery Capacity:** 700mAh (Charging Case)
- **Battery Type:** Lithium Polymer
- **Special Features:** Blink Pair Tech, Dual Pairing, Dual EQ Modes (Bass Driver)
- **Earpiece Shape:** Bud (In Ear)
- **Item Weight:** 100 Grams
- **Product Dimensions:** 5 x 5 x 5 cm
- **Compatible Devices:** Tablets, Cellphones, Laptops, Desktops, Smart Speaker, Television
- **Country of Origin:** China

## WARRANTY AND SUPPORT

Your Blaupunkt BTW300 Xtreme Moksha Maxbuds come with a standard brand warranty. For specific warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official Blaupunkt India website.

For customer support, technical assistance, or any queries regarding your product, you can contact:

- **WhatsApp Support:** 8860022600
- **Email ID:** [wecare@blaupunktaudio.in](mailto:wecare@blaupunktaudio.in)

Please have your product model number (BTW300) and proof of purchase ready when contacting support.

© 2025 Blaupunkt. All rights reserved.