

[Manuals.plus](#) /

› [RIVERSONG](#) /

› RIVERSONG Rhythm G1 Gaming Wired Headphones User Manual - Model RHYTHMG1

RIVERSONG RHYTHMG1

RIVERSONG Rhythm G1 Gaming Wired Headphones User Manual

Model: RHYTHMG1

INTRODUCTION

Thank you for choosing the RIVERSONG Rhythm G1 Gaming Wired Headphones. This manual provides essential information for setting up, operating, and maintaining your headset to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.



Image: The RIVERSONG Rhythm G1 Gaming Wired Headphones, featuring a black design with blue RGB lighting accents on the earcups and an adjustable boom microphone. The headset is shown from a three-quarter angle, highlighting its over-ear design and wired connection.

PACKAGE CONTENTS

- RIVERSONG Rhythm G1 Gaming Wired Headphones
- User Manual (this document)
- Warranty Card

PRODUCT FEATURES

- **360° HD Stereo Sound:** Immersive audio experience for gaming.
- **ENC Noise-Cancelling Microphone:** Reduces background noise for clear communication.
- **Adjustable Boom Mic:** Flexible positioning for optimal voice capture.
- **Dynamic RGB Lighting:** Aesthetic lighting on earcups.
- **Comfort-Focused Design:** Soft over-ear cushions and lightweight frame for extended use.
- **Dual Connectivity:** USB and 3.5mm jack for broad compatibility.
- **Durable Cable:** 2-meter cable for flexible movement.

SETUP

Connecting to Your Device

The Rhythm G1 headphones offer dual connectivity options: USB and 3.5mm audio jack.

1. For 3.5mm Audio Connection:

- Locate the 3.5mm audio jack on your PC, gaming console controller, or laptop.
- Insert the 3.5mm connector from the headset cable into the audio jack.
- Ensure the connection is secure. Audio output and microphone input will be handled via this connection.

2. For USB Connection (for RGB Lighting and additional power):

- Locate an available USB port on your PC, gaming console, or laptop.
- Insert the USB connector from the headset cable into the USB port.
- The RGB lighting on the earcups will illuminate upon successful USB connection. The USB connection primarily powers the RGB lighting.

Note: For full functionality including audio, microphone, and RGB lighting, both 3.5mm and USB connections may be required depending on your device's configuration. The 3.5mm jack handles audio and microphone, while USB powers the RGB lighting.

OPERATING INSTRUCTIONS

Adjusting Volume

The headset features an in-line volume control wheel on the cable. Rotate the wheel upwards to increase volume and downwards to decrease volume.

Microphone Usage

- **Positioning:** Adjust the flexible boom microphone to a comfortable position near your mouth for optimal voice pickup.
- **Mute Function:** The in-line control also includes a microphone mute switch. Slide the switch to mute or unmute the microphone as needed.
- **ENC Technology:** The Environmental Noise Cancelling (ENC) feature automatically works to reduce ambient background noise, enhancing voice clarity during communication.

RGB Lighting

The dynamic RGB lighting on the earcups is powered via the USB connection. Once connected, the lighting will activate automatically. There are no user-adjustable settings for the RGB lighting patterns or colors directly on the headset.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headset. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid sharp bends or excessive pulling on the cable to prevent damage.
- **Ear Cushions:** The ear cushions are designed for comfort and durability. Avoid puncturing or tearing them.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No audio from headphones.	3.5mm jack not fully inserted.	Ensure 3.5mm jack is securely connected.
	Volume too low.	Increase volume using in-line control or device settings.
	Incorrect audio output device selected on computer/console.	Verify headset is selected as the default audio output device in your system settings.
Microphone not working.	Microphone muted.	Unmute microphone using the in-line switch.
	Incorrect input device selected.	Select the headset microphone as the default input device in your system settings.
	Microphone not positioned correctly.	Adjust the boom mic closer to your mouth.
RGB lighting not working.	USB cable not connected or faulty.	Ensure USB cable is securely connected to a powered USB port.
	Insufficient power from USB port.	Try a different USB port.

SPECIFICATIONS

Feature	Detail
Model Name	RHYTHMG1
Brand	RIVERSONG
Connectivity Technology	Wired (USB + 3.5mm Jack)
Ear Placement	Over Ear
Noise Control	Environmental Noise Cancellation (ENC)
Cable Length	2 meters (approx.)
Compatible Devices	Desktops, Gaming Consoles, Laptops
Color	Black

WARRANTY AND SUPPORT

The RIVERSONG Rhythm G1 Gaming Wired Headphones come with a standard warranty. Please refer to the included Warranty Card for specific terms, conditions, and duration of coverage. For technical support, troubleshooting assistance, or warranty claims, please contact RIVERSONG customer service through their official website or the contact information provided on the warranty card.

Keep your purchase receipt and warranty card in a safe place as proof of purchase may be required for warranty services.

Safety Information

- Avoid prolonged listening at high volumes to prevent hearing damage.
- Do not expose the headset to water or excessive moisture.
- Do not attempt to disassemble or modify the headset. This will void the warranty.
- Keep out of reach of children.

© 2025 RIVERSONG. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FLKJPFDV>

More documents and user manuals: <https://manuals.plus/>