

[manuals.plus](#) /

› [CHiQ](#) /

› [CHiQ 92L Mini-Fridge Instruction Manual QRD03B1W](#)

CHiQ QRD03B1W

CHiQ 92L Mini-Fridge Instruction Manual QRD03B1W

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new CHiQ 92L Mini-Fridge, model QRD03B1W. Please read these instructions thoroughly before using the appliance and retain them for future reference.



Image: Front view of the CHiQ 92L Mini-Fridge, showcasing its compact and clean white design.

2. SAFETY INFORMATION

To ensure safe operation, please observe the following safety precautions:

- Ensure the appliance is connected to a 220V power supply.
- Do not place flammable, explosive, or corrosive materials inside the refrigerator.
- Keep ventilation openings clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- Children should be supervised to ensure that they do not play with the appliance.
- Unplug the appliance before cleaning or performing maintenance.

3. SETUP

3.1 Unpacking

Carefully remove the mini-fridge from its packaging. Inspect for any damage during transit. Retain packaging materials for future transport if needed.

3.2 Placement

- Place the appliance on a firm, level surface to prevent vibrations and noise.
- Ensure adequate space around the mini-fridge for proper ventilation (at least 10 cm on sides and back).
- Avoid direct sunlight or proximity to heat sources (e.g., stoves, radiators) to optimize energy efficiency.
- This model features adjustable front feet. Use them to level the appliance if the floor is uneven.



Image: The CHiQ 92L Mini-Fridge integrated into a kitchen environment, demonstrating its compact size and suitable placement.

3.3 Door Reversal

The mini-fridge is designed with a reversible door, allowing it to open from either the left or right side. This provides flexibility for installation in various spaces. Refer to the detailed instructions in the separate door reversal guide (if provided) or contact customer support for assistance with this procedure.

3.4 Power Connection

After placement, wait at least 2-4 hours before plugging the appliance into a 220V power outlet. This allows the refrigerant to settle. Ensure the power cord is not trapped or damaged.

4. OPERATING INSTRUCTIONS

4.1 Temperature Control

Your CHiQ mini-fridge features a mechanical temperature control with 7 adjustable levels. Turn the thermostat dial to select the desired cooling intensity. A higher number generally indicates a colder setting. Start with a medium setting (e.g., 3 or 4) and adjust as needed based on ambient temperature and contents.



Image: Interior view of the CHiQ 92L Mini-Fridge, highlighting the glass shelves, door storage, and the extra cold compartment.

4.2 Storage Organization

- **Glass Shelves:** The two tempered glass shelves are removable and can be adjusted to accommodate items of various sizes.
- **Door Compartments:** Utilize the door compartments for bottles (up to 2L), cans, and smaller items.
- **Extra Cold Compartment:** A dedicated compartment provides a colder zone for items requiring lower temperatures, such as dairy or frozen snacks.



Image: The interior of the CHiQ 92L Mini-Fridge, demonstrating effective organization of food and beverages using its shelves and door storage.

5. MAINTENANCE

5.1 Cleaning

- Always unplug the appliance before cleaning.
- Clean the interior and exterior surfaces regularly with a soft cloth and mild detergent. Avoid abrasive cleaners or solvents.
- The internal PCM white finish is designed for easy cleaning and impact resistance.
- Wipe down door seals to ensure a tight closure.

5.2 Manual Defrosting

This mini-fridge features manual defrosting. When frost accumulates to a thickness of about 5mm, unplug the appliance and remove all contents. Allow the frost to melt naturally. Do not use sharp objects to remove ice. Once defrosted, wipe the interior dry and plug the appliance back in.

5.3 Power Saving Tips

- Do not open the door frequently or leave it open for extended periods.
- Ensure the door seal is clean and intact.
- Allow hot foods to cool to room temperature before placing them in the mini-fridge.
- Place the appliance in a cool, well-ventilated area away from direct sunlight and heat sources.

6. TROUBLESHOOTING

Before contacting customer support, please check the following common issues:

Problem	Possible Cause	Solution
Appliance does not operate	No power; plug loose; circuit breaker tripped.	Check power supply; ensure plug is secure; reset breaker.
Not cooling sufficiently	Temperature setting too high; door opened too often; poor ventilation; too much food inside.	Adjust thermostat; reduce door openings; ensure proper clearance; do not overload.
Unusual noises	Appliance not level; objects touching the back; normal compressor operation.	Adjust leveling feet; move objects away; some sounds are normal.
Water on floor	Drain hole blocked; excessive humidity.	Clear drain hole; ensure proper ventilation.

7. SPECIFICATIONS

Feature	Detail
Brand	CHiQ
Model	QRD03B1W
Capacity	92 Liters
Voltage	220V
Frequency	60Hz
Dimensions (L x A x P)	47 cm x 83 cm x 44 cm
Net Weight	21 kg
Energy Efficiency	A+ (Brazil A)
Temperature Control	Mechanical, 7 levels
Defrost Type	Manual
Door Features	Reversible

Feature	Detail
Shelves	2 Tempered Glass, Removable
Special Features	Low Noise, Adjustable Front Feet, Extra Cold Compartment, 2L Bottle Storage

8. WARRANTY INFORMATION

This CHiQ mini-fridge comes with a **10-year warranty on the compressor**. For details regarding the full product warranty and terms, please refer to the warranty card included with your purchase or visit the official CHiQ website.


9. CUSTOMER SUPPORT


If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact CHiQ customer support. Have your model number (QRD03B1W) and purchase information ready when you call.

For the most up-to-date contact information, please visit the official CHiQ website: www.chiq.com

© 2025 CHiQ. All rights reserved.

Related Documents - QRD03B1W

 <p>CHiQ Top Mount Refrigerator User Manual - CTM348NW5E, CTM347NB5E</p> <p>Comprehensive user manual for CHiQ Top Mount Refrigerators, models CTM348NW5E and CTM347NB5E. Covers installation, operation, safety instructions, maintenance, and troubleshooting.</p>
 <p>CHiQ MF-415W User Manual</p> <p>User manual for the CHiQ MF-415W refrigerator. This guide covers essential safety, operation, food storage tips, maintenance, and troubleshooting for your CHiQ appliance. Learn how to use and care for your refrigerator effectively.</p>
 <p>CHiQ CTM200NSS5E Top Mount Refrigerator User Manual</p> <p>User manual for the CHiQ CTM200NSS5E Top Mount Refrigerator, covering installation, operation, safety, maintenance, and troubleshooting for optimal appliance performance.</p>

 <p>TOP MOUNT REFRIGERATOR USER MANUAL</p> <p>MODEL CTM255NW</p> <p>Customer Service 1300 790 088 www.chiq.com.au</p>	<p><u>CHiQ CTM255NW Top Mount Refrigerator User Manual</u></p> <p>User manual for the CHiQ CTM255NW Top Mount Refrigerator, providing detailed instructions on installation, operation, safety precautions, maintenance, and troubleshooting.</p>
 <p>FOUR DOORS REFRIGERATOR USER MANUAL</p> <p>MODEL CFD502NBS CFD501NB CFD500NSS CFD499NS CFD498NW</p> <p>Customer Service 1300 790 088 www.chiq.com.au</p>	<p><u>CHiQ Four Doors Refrigerator User Manual - Models CFD502NBS, CFD501NB, CFD500NSS, CFD499NS, CFD498NW</u></p> <p>Comprehensive user manual for CHiQ Four Doors Refrigerators, including models CFD502NBS, CFD501NB, CFD500NSS, CFD499NS, and CFD498NW. This guide covers essential safety instructions, installation procedures, operating modes, product features, energy-saving tips, maintenance, and troubleshooting for your CHiQ refrigerator. Visit www.chiq.com.au for support.</p>
 <p>INSTRUCTION MANUAL</p> <p>Model No.: CQRT18Y1GD1W/CQRT18Y1GD1S</p>	<p><u>CHiQ CQRT18Y1GD1W/CQRT18Y1GD1S Refrigerator Instruction Manual</u></p> <p>Comprehensive instruction manual for the CHiQ CQRT18Y1GD1W/CQRT18Y1GD1S refrigerator. Learn about safety, installation, operation, food storage, maintenance, and troubleshooting for your CHiQ appliance.</p>