

[Manuals.plus](#) /

> [ZVOX](#) /

> ZVOX AccuVoice AV835 Dialogue Clarifying Soundbar Instruction Manual

ZVOX AV835

ZVOX AccuVoice AV835 Dialogue Clarifying Soundbar

Model: AV835

INTRODUCTION

This manual provides instructions for the setup, operation, maintenance, and troubleshooting of your ZVOX AccuVoice AV835 Dialogue Clarifying Soundbar. Please read this manual thoroughly before using the product to ensure proper function and longevity.



Clarify Voices
on your TV

AV835

DIALOGUE CLARIFYING SOUNDBAR

Image: The ZVOX AccuVoice AV835 Soundbar shown with its remote control, illustrating the product's sleek design.

SETUP

1. Unpacking the Soundbar

Carefully remove all components from the packaging. Ensure the following items are present:

- ZVOX AccuVoice AV835 Soundbar
- Remote Control (with 2x AAA batteries included)
- ARC-HDMI compatible cable
- Optical digital cable
- Mini RCA analog to 3.5mm cable
- 3.5mm analog cable
- Power Adapter

IN THE BOX

AV835 Dialogue Clarifying Soundbar



Dimensions: 17.6" W x 5.0" D x 1.9" H



Image: An illustration of all items included in the ZVOX AV835 product box, such as the soundbar, remote, and connection cables.

2. Placement

The AV835 soundbar is designed to be placed directly in front of your television or on a shelf below it. Its low-profile design (1.9 inches high) allows it to fit under most TVs 32 inches and larger without obstructing the screen. Ensure the soundbar is placed on a stable, flat surface.

3. Connecting to Your TV

The AV835 offers multiple connection options. Choose the method that best suits your television.

- **HDMI ARC (Recommended):** Connect one end of the HDMI cable to the HDMI ARC port on the soundbar and the other end to the HDMI ARC port on your TV. This connection allows your TV remote to control the soundbar's volume.
- **Optical Digital:** Connect one end of the optical digital cable to the OPTICAL IN port on the soundbar and the other end to the Optical Digital Output port on your TV.
- **Analog:** Use either the 3.5mm analog cable or the Mini RCA analog to 3.5mm cable to connect the soundbar's ANALOG IN port to the audio output (headphone jack or RCA stereo output) on your TV.

What Customers Say About ZVOX

“The voices are so much better”
- Nancy A.

“The speech is way better”
- Mark N.

“Works very well for us older folks
with high frequency hearing loss”
- Bob

Image: A visual representation of the three primary connection types: Optical Digital (Toslink), Analog (Minijack), and HDMI-ARC Compatible.

After connecting the audio cable, plug the power adapter into the soundbar and then into a wall outlet. The soundbar will automatically power on.

OPERATING THE SOUNDBAR

1. Power On/Off

Press the **POWER** button on the remote control to turn the soundbar on or off. If connected via HDMI ARC, the soundbar may power on/off automatically with your TV.

2. Volume Control

Use the **VOLUME UP** (\wedge) and **VOLUME DOWN** (\vee) buttons on the remote to adjust the overall sound level. The current volume level will be displayed on the soundbar's front panel.

3. AccuVoice Settings

The AV835 features AccuVoice technology to enhance dialogue clarity. Press the **ACCUVOICE** button on the remote to cycle through 20 levels of voice boost. Each press increases the clarity, making voices more distinct from background sounds. Experiment to find your preferred setting.

THREE EASY WAYS TO CONNECT

This product features optical, analog, and HDMI inputs.
It cannot be used as a center speaker. **Check your TV for compatibility.**



**OPTICAL DIGITAL
INPUT**
(Toslink)



**MINIJACK ANALOG
INPUT**
(3.5mm)



**HDMI COMPATIBLE
DIGITAL INPUT**

Image: A graphic illustrating how AccuVoice technology lifts TV dialogue from background noise, offering 20 levels of dialogue boost.

4. PhaseCue Virtual Surround Sound

Press the **SURROUND** button on the remote to activate PhaseCue virtual surround sound. This feature creates a wider, more immersive audio experience from the compact soundbar.

5. Output Leveling

The Output Leveling feature automatically reduces the impact of loud commercials or sudden volume changes, providing a more consistent listening experience. This feature is always active.

6. USB Playback

To play audio files from a USB flash drive, insert the drive into the USB port on the soundbar. The soundbar will automatically detect and begin playing compatible audio tracks. Use the **PLAY/PAUSE**, **BACK**, and **FWD** buttons on the remote to control playback.

7. Remote Control

The included remote control provides full functionality for the AV835. Ensure the batteries (2x AAA) are correctly installed. The soundbar features a behind-the-grille display that illuminates to show current settings when adjustments are made.



Image: The ZVOX AV835 Soundbar and its remote control, highlighting the easy-to-read display and user-friendly design.

MAINTENANCE

Cleaning

To clean the soundbar, gently wipe the exterior surfaces with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these may damage the finish or internal components. Ensure the soundbar is powered off and unplugged before cleaning.

Storage

If storing the soundbar for an extended period, disconnect it from power and store it in a cool, dry place, preferably in its original packaging to protect it from dust and physical damage.

TROUBLESHOOTING

If you encounter issues with your ZVOX AV835, refer to the following common solutions:

- **No Sound:**
 - Ensure the soundbar is powered on and not muted.

- Verify that the audio cable (HDMI ARC, Optical, or Analog) is securely connected to both the soundbar and the TV.
- Check your TV's audio output settings to ensure it is sending audio to the correct output (e.g., external speakers, HDMI ARC).
- Try a different audio cable or connection method if available.

- **Distorted or Poor Sound Quality:**

- Check for loose cable connections.
- Ensure the soundbar's volume is not set too high, causing clipping.
- Adjust the AccuVoice settings to see if clarity improves.
- If using analog connection, ensure the TV's volume is not too low or too high, which can affect the signal quality.

- **Remote Control Not Responding:**

- Replace the AAA batteries in the remote control.
- Ensure there are no obstructions between the remote and the soundbar.
- Point the remote directly at the front of the soundbar.

SPECIFICATIONS

Model Number	AV835
Brand	ZVOX
Speaker Type	Soundbar
Speaker Maximum Output Power	45 Watts
Connectivity Technology	ARC-HDMI Compatible, Analog, Optical
Audio Output Mode	Surround (PhaseCue)
Control Method	Remote Control
Number of AccuVoice Levels	20
Dimensions (W x D x H)	17.6" x 5" x 1.9"
Item Weight	3.2 Pounds
Enclosure Material	Aluminum
UPC	882360083516

WARRANTY INFORMATION

The ZVOX AccuVoice AV835 Soundbar comes with a One Year Limited Parts and Labor Warranty. This warranty covers defects in materials and workmanship under normal use. For specific terms and conditions, please refer to the warranty card included with your product or visit the official ZVOX website.

SUPPORT

For further assistance, technical support, or to inquire about replacement parts, please contact ZVOX customer service. You can find contact information and additional resources on the official ZVOX website:

[Visit the ZVOX Store on Amazon](#)

Please have your model number (AV835) and purchase information ready when contacting support.