Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bonnlo SF20251007B0FLNNPZ2T

Bonnlo 4 Burner Propane Gas Grill with Side Burner and Porcelain-Enameled Grates Instruction Manual

Model: SF20251007B0FLNNPZ2T

Introduction

This manual provides essential information for the safe assembly, operation, and maintenance of your Bonnlo 4 Burner Propane Gas Grill. Please read all instructions carefully before using the grill to ensure optimal performance and safety.

The Bonnlo 4 Burner Propane Gas Grill features a powerful 58,000 BTU output, including a dedicated side burner, and a spacious 548 square-inch cooking area with porcelain-enameled grates. Its design prioritizes convenience with one-touch ignition, portable rolling wheels, and ample storage.

Safety Information

Always follow these safety guidelines to prevent injury or property damage:

- Use the grill outdoors only in a well-ventilated area.
- Keep the grill away from combustible materials.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Always check for gas leaks before each use.
- Keep children and pets away from the grill at all times.
- Never leave a lit grill unattended.
- Wear protective gloves when handling hot components.

Components Overview

Familiarize yourself with the main components of your grill:



Image: All grill components prior to assembly.

- **Main Grill Body:** Houses the main burners and cooking grates.
- **Side Burner:** Integrated cooking surface for pots and pans.
- **Control Panel:** Knobs for burner control and ignition.
- **Side Shelves:** Provides additional workspace and storage.
- **Cabinet:** Storage area for propane tank and accessories.
- **Wheels:** For easy mobility.

Setup and Assembly

Follow these steps for proper assembly of your grill. Ensure all parts are present before beginning.

Assembly Video Guide

Your browser does not support the video tag.

Video: Detailed steps for barbecue grill installation.

Key Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list in your printed manual.
2. **Assemble Base Frame:** Secure the bottom panel to the vertical support legs using the provided screws.
3. **Attach Side Panels:** Fasten the side panels to the base frame.
4. **Install Wheels:** Securely attach the four rolling wheels to the bottom of the base frame. Ensure locking wheels are placed as indicated in the manual.
5. **Mount Grill Head:** Carefully place the main grill head onto the assembled base frame and secure it with screws.
6. **Connect Gas Line:** Attach the gas hose and regulator to the grill's gas inlet and ensure a tight connection.
7. **Install Side Burner and Side Shelf:** Attach the side burner unit and the fixed side shelf to the main grill body.
8. **Place Heat Tents and Grates:** Position the heat tents over the burners, then place the porcelain-enameled cooking grates and warming rack.
9. **Insert Drip Tray:** Slide the full-size pull-out drip tray into its designated slot beneath the main cooking area.
10. **Attach Cabinet Doors:** Install the cabinet doors to the front of the grill base.




Image: The fully assembled Bonnlo 4 Burner Propane Gas Grill.

Operating Instructions

Learn how to safely and effectively operate your Bonnlo grill.

Lighting the Main Burners

1. Ensure the propane tank valve is fully open.
2. Open the grill lid.
3. Push in and turn any main burner control knob counter-clockwise to the HIGH position.
4. Press and hold the electronic ignition button until the burner ignites. You should hear a clicking sound.
5. Once lit, release the ignition button and adjust the burner to your desired heat setting.
6. If the burner does not light within 5 seconds, turn the knob to OFF, wait 5 minutes, and repeat the lighting

procedure.

Using the Side Burner

1. Open the side burner lid.
2. Push in and turn the side burner control knob counter-clockwise to the HIGH position.
3. Press and hold the electronic ignition button until the side burner ignites.
4. Adjust the flame as needed.



Image: Grill control knobs and temperature gauge.

Temperature Control

The built-in thermometer on the grill lid allows you to monitor the internal temperature without opening the lid, helping maintain consistent cooking heat.



Image: Grill in operation with various foods cooking.

Grilling Demonstration

Your browser does not support the video tag.

Video: Demonstration of the Endark Propane Gas Grill in use, showcasing cooking capabilities.

Maintenance and Care

Regular cleaning and maintenance will prolong the life of your grill and ensure safe operation.

- **Cleaning Cooking Grates:** After each use, once the grates have cooled, brush off any food residue with a grill

brush. For deeper cleaning, wash with warm soapy water.

- **Cleaning Drip Tray:** The full-size pull-out drip tray should be emptied and cleaned regularly to prevent grease buildup and potential flare-ups.
- **Exterior Cleaning:** Wipe down stainless steel surfaces with a soft cloth and a stainless steel cleaner. For painted surfaces, use mild soap and water.
- **Burner Maintenance:** Periodically check burner ports for blockages (e.g., from insects). Clean with a wire brush or paperclip if necessary.
- **Covering the Grill:** Use a weather-resistant grill cover when the grill is not in use to protect it from the elements.



Image: The pull-out drip tray for easy cleaning.

Troubleshooting

If you encounter issues with your grill, refer to the following common problems and solutions:

- **Burner Fails to Light:**
  - Check propane tank for gas.

- Ensure gas valve is fully open.
- Verify ignition electrode is clean and properly positioned.
- Check for blockages in burner ports.

- **Low Flame/Uneven Heat:**
  - Check propane tank level.
  - Ensure gas hose is not kinked.
  - Clean burner ports if clogged.

- **Gas Leak Smell:**
  - Immediately turn off gas supply.
  - Do not operate the grill.
  - Check all gas connections for leaks using a soapy water solution. Bubbles indicate a leak.
  - Contact qualified service personnel if unable to resolve.

Specifications

Feature	Specification
Brand	Bonnlo
Model Name	SF20251007B0FLNNPZ2T
Product Dimensions	52.95"L x 24.8"W x 44.49"H
Fuel Type	Propane Gas
Main Burner Count	4
Side Burner Count	1
Total BTU Output	58,000 BTU
Main Burner Heat Output	48,000 BTU (12,000 BTU each)
Side Burner Heat Output	10,000 BTU
Cooking Surface Area	548 Square Inches (404 sq. in. cooking rack + 144 sq. in. warming rack)
Material	Iron and Steel (Porcelain-Enameled Grates)
Special Feature	Portable, Rolling Wheels
Assembly Required	Yes

Warranty and Support

For warranty information, please refer to the documentation included with your product packaging. If you require technical assistance or have questions regarding your Bonnlo 4 Burner Propane Gas Grill, please contact Bonnlo customer support through the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FLNNPZ2T

More documents and user manuals: **https://manuals.plus/**