

TCL NXTPAPER 14

TCL NXTPAPER 14 Android Tablet User Manual

Model: NXTPAPER 14

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your TCL NXTPAPER 14 Android Tablet. The TCL NXTPAPER 14 is designed to offer a versatile experience, functioning as a tablet, drawing pad, and digital notebook. It features a 14.3-inch 2.4K NXTPAPER display, a 4096-pressure-level T-PEN stylus, and comes with a protective flip case.

Key features include:

- 14.3-inch 2.4K NXTPAPER Display for a paper-like viewing experience.
- T-PEN Stylus with 4096 pressure levels for precise input.
- NXTPAPER 3.0 display technology with anti-glare, blue light reduction, and DC dimming for eye comfort.
- Three display modes: Regular, Ink Paper, and Color Paper.
- MediaTek Helio G99 processor, 8GB RAM (plus 8GB expandable), and 256GB storage.
- 10,000mAh battery with 33W fast charging and reverse charging capabilities.
- Dual front cameras (13MP + 5MP) and an 8MP rear camera, all supporting 2K video.
- Quad stereo speaker system with Smart PA.
- Multi-window productivity features including floating windows, split screen, screen mirroring, and extended displays.



Image 1.1: The TCL NXTPAPER 14 Android Tablet with its T-PEN stylus and flip case, showcasing the vibrant display.

2. WHAT'S IN THE BOX

Please verify that all items are present in the package:

- TCL NXTPAPER 14 Tablet
- T-PEN Stylus
- Flip Case
- USB-C Cable

Your Creative Companion

Tablet, Drawing Pad & Digital Notebook — All in One



Flip Case

- All-Round Protection
- Multiple Viewing Angles



T-PEN Stylus

- 4096 Pressure Levels
- Magnetically Attaches to the Flip Case



* The tablet works only with the included T-PEN stylus. The stylus supports tapping and swiping on the system interface. For writing or drawing, please use apps that support handwriting.

Image 2.1: The TCL NXTPAPER 14 Tablet, T-PEN Stylus, and Flip Case, as typically included in the product packaging.

3. INITIAL SETUP

3.1 Charging the Tablet

Before first use, fully charge your TCL NXTPAPER 14 Tablet. Connect the included USB-C cable to the tablet's charging port and to a compatible USB wall adapter (not included). The tablet supports 33W fast charging.

3.2 Powering On/Off

- **To Power On:** Press and hold the Power button located on the side of the tablet until the TCL logo appears on the screen.
- **To Power Off:** Press and hold the Power button, then select 'Power off' from the options that appear on the screen.
- **To Restart:** Press and hold the Power button, then select 'Restart' from the options.

3.3 Attaching the Flip Case

The included flip case provides protection and acts as a stand. Align the tablet with the case and gently press it into place. Ensure all ports and buttons are accessible. The T-PEN stylus can be magnetically attached to the flip case for secure storage.

3.4 Initial Android Setup

Upon first power-on, follow the on-screen prompts to complete the initial Android setup. This includes selecting your language, connecting to a Wi-Fi network, signing in with your Google account, and setting up security features.

4. OPERATION

4.1 NXTPAPER Display Modes

The TCL NXTPAPER 14 features a dedicated NXTPAPER Key to switch between three display modes, optimizing your viewing experience for different tasks.

- **Regular Mode:** Provides vibrant visuals suitable for multimedia consumption like movies and video calls.
- **Ink Paper Mode:** Recreates the texture of e-paper, ideal for extended reading or note-taking, reducing eye strain.
- **Color Paper Mode:** Delivers soft, low-saturation tones, perfect for digital art, comics, and creative projects.

Tap to Transform

Instant switch between Regular & Paper UI



Image 4.1: The three distinct display modes (Color Paper, Regular, Ink Paper) accessible via the NXPAPER Key.

4.2 T-PEN Stylus Usage

The T-PEN Stylus offers 4096 levels of pressure sensitivity for precise drawing, writing, and navigation. It is compatible with the tablet for tapping and swiping on the system interface. For handwriting or drawing, use applications that support stylus input.



Image 4.2: A user drawing on the TCL NXTPAPER 14 tablet with the T-PEN stylus.

4.3 Multitasking and Productivity


The tablet's Android 14 operating system and TCL's smart UI enhance productivity through several features:

- **Floating Windows:** Allows applications to run in resizable windows over other apps.
- **Split Screen:** Divides the screen to display two applications simultaneously.
- **Screen Mirroring:** Cast your tablet's display to a larger screen.
- **Extended Displays:** Use your tablet as a secondary display for a PC (Windows 10 or later, both devices on the same network).


Powerful Multitasking, Effortless Flow

8 GB
RAM

256 GB
ROM



Floating window



Split screen

Image 4.3: Examples of floating window and split screen functionalities on the tablet.

4.4 Camera and Audio

The tablet is equipped with dual front cameras (13MP + 5MP) and an 8MP rear autofocus camera, all capable of 2K video recording. The quad stereo speaker system with Smart PA delivers enhanced audio output.



Image 4.4: A user engaged in a video call, demonstrating the tablet's camera capabilities.

4.5 Battery Management

The 10,000mAh battery provides extended usage time. It supports 33W fast charging, allowing a full recharge in approximately two hours. The tablet also features reverse charging (requires an OTG cable, sold separately) to power other devices.

Long Battery Life for Extended Use



33W PD
Fast Charging Capable¹



1.5 A
Reverse Charging²



10,000mAh
Battery




Image 4.5: An illustration detailing the 10,000mAh battery, 33W fast charging, and reverse charging capabilities.

5. MAINTENANCE

5.1 Cleaning the Tablet

To clean the tablet screen, use a soft, lint-free cloth specifically designed for electronics. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner solution. Avoid using harsh chemicals, abrasive materials, or excessive moisture.

5.2 Stylus Care

Keep the T-PEN stylus clean and free from debris. Store it securely, ideally attached magnetically to the flip case, to prevent loss or damage. Avoid exposing the stylus to extreme temperatures or direct sunlight.

5.3 General Care

- Avoid dropping the tablet or exposing it to strong impacts.
- Keep the tablet away from water and high humidity.

- Do not expose the tablet to extreme temperatures.
- Use only approved charging accessories.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your TCL NXTPAPER 14 Tablet.

Problem	Solution
Tablet does not power on.	Ensure the tablet is charged. Connect it to a power source for at least 30 minutes. If it still doesn't power on, perform a forced restart by holding the Power button for 10-15 seconds.
Screen is unresponsive.	Restart the tablet. If the issue persists, ensure the screen is clean and free of debris.
T-PEN Stylus is not responding.	Ensure the stylus tip is clean. Check if the application you are using supports stylus input. Restart the tablet.
Battery drains quickly.	Reduce screen brightness, close unused applications, disable Wi-Fi/Bluetooth when not in use. Check for background app activity.
Tablet is slow or freezes.	Close unnecessary apps, clear cache, or restart the tablet. Ensure sufficient storage space is available.

7. SPECIFICATIONS

Feature	Detail
Model Name	TCL NXTPAPER 14
Display Size	14.3 Inches
Max Screen Resolution	2400 x 1600 Pixels
Operating System	Android 14
Processor Brand	MediaTek (Helio G99)
Memory (RAM)	8GB (plus 8GB expandable)
Storage (Flash Memory)	256 GB
Item Weight	4 pounds
Product Dimensions (LxWxH)	8.74 x 12.69 x 0.27 inches
Color	Gray
Battery	10,000mAh (Nonstandard Battery, included)
Charging	33W Fast Charging, Reverse Charging capable
Cameras	Dual Front (13MP + 5MP), Rear (8MP Autofocus)
Audio	Quad Stereo Speakers with Smart PA

8. WARRANTY AND SUPPORT

8.1 Warranty Information

For detailed warranty information, please refer to the documentation included with your product or visit the official TCL website. Warranty terms and conditions may vary by region.

8.2 Support Resources

For further assistance, you can access the following resources:

- **User Manual (PDF):** [Download PDF](#)
- **Safety Information (PDF):** [Download PDF](#)
- **Official TCL Store:** [Visit Store](#)

