

ReHisk RE-241KV4m

ReHisk RE-241KV4m 24-Inch Curved FHD 100Hz Monitor User Manual

Model: RE-241KV4m | Brand: ReHisk

1. INTRODUCTION

Welcome to the user manual for your new ReHisk RE-241KV4m 24-inch Curved FHD 100Hz Monitor. This guide provides detailed instructions for setting up, operating, and maintaining your monitor to ensure optimal performance and longevity. Please read this manual thoroughly before using the product and retain it for future reference.

2. PACKAGE CONTENTS

Carefully unpack your monitor and verify that all the following items are included in the box. If any items are missing or damaged, please contact ReHisk customer support.

- ReHisk RE-241KV4m 24-Inch Curved FHD 100Hz Monitor
- Product Manual
- Monitor Stand (Bracket and Bracket Base)
- HDMI Signal Cable
- Power Adapter
- Mounting Screws and Tools

1800R CURVED DISPLAY

Built in dual speakers



Eye Save Mode



Flicker Free




Image: All components included in the ReHisk monitor package.

Your browser does not support the video tag.

Video: Unboxing and initial overview of the ReHisk 24-inch monitor and its accessories.

3. SETUP AND INSTALLATION

3.1 Attaching the Stand

1. Carefully remove the monitor from its packaging and place it face down on a soft, clean surface to prevent scratches.
2. Locate the monitor stand bracket and base.
3. Align the bracket with the mounting slot on the back of the monitor.

4. Secure the bracket using the provided screws.
5. Attach the stand base to the bracket and tighten the screws firmly.

Immersive Viewing Experience with 100Hz and FreeSync



1ms

100HZ

60HZ 5ms

Image: Step-by-step guide for assembling the monitor stand.

3.2 VESA Wall Mounting (Optional)

The monitor supports VESA 75 x 75mm mounting. If you prefer to wall-mount your monitor, remove the stand and attach a compatible VESA wall mount (sold separately) to the mounting holes on the back of the monitor. Ensure the wall mount can support the weight of the monitor.

Free-Sync Support

AMD FreeSync minimizes input latency during gaming

FreeSync



Image: Rear view of the monitor highlighting the VESA 75x75mm mounting points.

3.3 Connecting to a Device

Connect the monitor to your computer or other devices using the appropriate cables. The monitor features HDMI and VGA ports for versatile connectivity.

- **HDMI:** Use the provided HDMI cable to connect to an HDMI port on your device.
- **VGA:** Use a VGA cable (not included) to connect to a VGA port on your device.
- **Power:** Connect the power adapter to the monitor's power input and then to a power outlet.

4. FEATURES

4.1 Display Quality

Experience stunning visuals with the 24-inch Full HD (1920x1080p) IPS panel. Enjoy brighter whites, deeper blacks, and 16.7 million true-to-life colors, perfect for streaming, professional work, and daily browsing.



Image: The monitor showcasing wide color gamut and true color display capabilities.

4.2 Fluid 100Hz Refresh Rate & 3ms Response Time

Say goodbye to lag and motion blur. The 100Hz refresh rate provides smoother transitions and more responsive visuals compared to standard 60Hz screens. Combined with a 3ms response time, your movies, videos, and games will look incredibly fluid and sharp.




Image: Visual representation of the immersive viewing experience with 100Hz refresh rate and fast response time.

4.3 Modern Micro-Edge Curved Design

The 1800R curvature wraps around your field of view, creating a panoramic effect that allows for a more immersive experience. The 3-sided micro-edge bezel maximizes your viewing area, while the 178° ultra-wide viewing angle ensures vibrant and accurate colors from virtually any position.



Image: Illustration of the 1800R curved display and its benefits for human field of view.

Low Blue Light 7 Flicker Free Protect Your Eyes"



Image: Demonstrating the panoramic view and wide viewing angles of the monitor.


4.4 Ergonomic Tilt for All-Day Comfort

Designed with your health in mind, the stand offers an adjustable tilt range from -5° forward to 15° backward. Easily find your optimal viewing angle to maintain a comfortable posture and significantly reduce neck and eye strain during long sessions.

4.5 Eye Care Technology

The monitor incorporates Flicker-Free technology and a Blue Light Filter to protect your eyes. These features reduce eye strain and fatigue, allowing for more comfortable viewing during extended use.

Wide color Gamut and True color Display



178° VIEW ANGLE



250CD/M²
BRIGHTNESS



1920X1080
RESOLUTION



90%
DCI-P3



1000:1
Ratio



16.7M
Color Support

Image: Demonstrating the eye care features like Low Blue Light and Flicker-Free technology.

Eye Care Technology

The anti-flicker technology provides a more comfortable viewing environment. Allow a long time to use without eye stress

Anti-flicker



Without Anti-flicker




Image: Visual comparison of a monitor with and without anti-flicker technology.

4.6 AMD FreeSync Compatible

Enjoy tear-free and stutter-free gaming with AMD FreeSync compatibility. This technology synchronizes the monitor's refresh rate with your GPU's frame rate, eliminating visual artifacts and providing a smoother gaming experience.



Image: Demonstrating the benefits of FreeSync technology in reducing screen tearing and lag.

Your browser does not support the video tag.

Video: The ReHisk 24-inch monitor showcasing its performance during gaming, highlighting smooth visuals.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press the power button located on the monitor to turn it on or off. The power indicator light will illuminate when the monitor is on.

5.2 Input Selection

Use the monitor's OSD (On-Screen Display) menu to select your desired input source (HDMI, VGA). Navigate the menu using the buttons usually located on the back or bottom edge of the monitor.

5.3 OSD Menu Navigation

The OSD menu allows you to adjust various display settings such as brightness, contrast, color temperature, and picture modes. Refer to the on-screen prompts for specific navigation and adjustment options.

6. MAINTENANCE

6.1 Cleaning the Monitor

- Always unplug the monitor before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive screen cleaner.
- Do not spray cleaner directly onto the screen.
- Avoid using alcohol, ammonia, or abrasive cleaners.

6.2 General Care

- Keep the monitor away from direct sunlight, heat sources, and excessive moisture.
- Ensure proper ventilation around the monitor.
- Avoid placing heavy objects on the monitor or its cables.

7. TROUBLESHOOTING

If you encounter any issues with your monitor, please refer to the following common problems and solutions:

- **No Power:** Ensure the power cable is securely connected to both the monitor and the power outlet. Check if the power adapter is functioning correctly.
- **No Signal:** Verify that the video cable (HDMI/VGA) is properly connected to both the monitor and your device. Ensure the correct input source is selected in the OSD menu.
- **Blurry or Distorted Image:** Check the display resolution settings on your computer to ensure they match the monitor's native resolution (1920x1080p). Adjust the monitor's OSD settings for sharpness and clarity.
- **Flickering Screen:** Ensure the refresh rate is set correctly (100Hz). If FreeSync is enabled, ensure your graphics card drivers are up to date.

If the problem persists after trying these solutions, please contact ReHisk customer support.

8. SPECIFICATIONS

Feature	Specification
Model Number	RE-241KV4m
Screen Size	24 Inches (23.6" viewable)
Resolution	1920 x 1080 (FHD 1080p)
Refresh Rate	100Hz
Response Time	3ms
Panel Type	IPS
Curvature	1800R
Aspect Ratio	16:9
Viewing Angle	178° (Ultra-wide)
Connectivity	HDMI, VGA, DP, Audio, USB
Eye Care Features	Flicker-Free, Blue Light Filter, Eye Save Mode
Sync Technology	AMD FreeSync Compatible
Product Dimensions	6.4 x 24 x 13.6 inches

9. WARRANTY AND SUPPORT

Your ReHisk monitor comes with a manufacturer's warranty. For specific warranty details, please refer to the warranty card included in your package or visit the official ReHisk website. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact ReHisk customer service.

ReHisk Customer Support:

- Email: sz.info@ganymedebos.com
- Phone: 508-434-7740

© 2025 ReHisk. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question