

[Manuals.plus](#) /

› [Baseus](#) /

› Baseus Inspire XH1 Adaptive Active Noise Cancelling Headphones User Manual

Baseus Inspire XH1

Baseus Inspire XH1 Adaptive Active Noise Cancelling Headphones User Manual

1. INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your Baseus Inspire XH1 Adaptive Active Noise Cancelling Headphones. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Image: Baseus Inspire XH1 Adaptive Active Noise Cancelling Headphones in Cosmic Black.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- Baseus Inspire XH1 Active Noise Cancelling Headphones ×1

- Audio Cable ×1
- USB-A to USB-C Charging Cable ×1
- Protective Carrying Case ×1



Image: All items included in the Baseus Inspire XH1 headphone package.

3. SETUP

3.1 Charging the Headphones

Before first use, fully charge the headphones. Connect the USB-C charging cable to the headphone's charging port and the other end to a USB power source. The indicator light will show charging status and turn off when fully charged.

3.2 Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the power button until the indicator light flashes, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "Baseus Inspire XH1" from the list to connect. A voice prompt will confirm successful pairing.

3.3 Baseus App and SoundFit Personalization

For full functionality and personalized audio, download the Baseus App (V2.8.9+). Ensure your headphone firmware is updated to V1.1.07+ via the app. The app allows for SoundFit hearing personalization, EQ adjustments, and control over various features.




Image: The Baseus app interface for smart control and personalization.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

- **Power On:** Press and hold the power button for 2 seconds.
- **Power Off:** Press and hold the power button for 3 seconds.

4.2 Active Noise Cancellation (ANC) and Transparency Mode

- **Toggle ANC/Transparency:** Press the ANC button once. Cycle through ANC On, Transparency Mode, and ANC Off.
- **Quick Attention:** Press and hold the ANC button for 2 seconds to temporarily activate Transparency Mode and lower volume. Release to return to previous mode.

4.3 Music Playback and Call Control


- **Play/Pause:** Press the Multifunction button once.
- **Next Track:** Press and hold the Volume Up button for 2 seconds.
- **Previous Track:** Press and hold the Volume Down button for 2 seconds.
- **Answer/End Call:** Press the Multifunction button once.
- **Reject Call:** Press and hold the Multifunction button for 2 seconds.

4.4 Volume Control

- **Volume Up:** Press the Volume Up button once.
- **Volume Down:** Press the Volume Down button once.

4.5 Dolby Audio and Low Latency Mode

- **Toggle Dolby Audio:** Press the Multifunction button twice.
- **Activate Low Latency Mode:** Press the Multifunction button three times.



Week-Long Playtime

Enjoy up to 100 hours on a single charge—enough for a full week of nonstop listening. Need more? A quick 10-minute charge adds 12 extra hours to keep your music playing anywhere.

100 hr ANC Off ²	65 hr ANC On ²
10 min ⚡ Charge	= 12 hr ▶ Playtime ⁴

Image: Overview of headphone button controls.

Your browser does not support the video tag.

Video: An official product video demonstrating the features and design of the Baseus Inspire headphones, highlighting the 'Sound by Bose' collaboration.

5. MAINTENANCE

5.1 Cleaning

Wipe the headphones with a soft, dry cloth. Do not use harsh chemicals or abrasive materials. Avoid getting moisture into any openings.

5.2 Storage

When not in use, store the headphones in the provided protective carrying case to prevent damage from dust, scratches, and impacts. Store in a cool, dry place.




Image: Headphones folded and stored in their protective case.

5.3 Battery Care


To prolong battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in constant use. Do not expose to extreme temperatures.

6. TROUBLESHOOTING

- **No Power:** Ensure the headphones are charged. Connect to a power source and check the charging indicator.
- **Cannot Pair:** Ensure the headphones are in pairing mode (flashing indicator). Turn off and on your device's Bluetooth. If issues persist, try forgetting the device in your Bluetooth settings and re-pairing.
- **No Sound:** Check volume levels on both headphones and the connected device. Ensure the headphones are correctly paired.
- **Poor ANC Performance:** Ensure the earcups form a proper seal around your ears. Adjust the fit if necessary. Update headphone firmware via the Baseus App.
- **App Connectivity Issues:** Ensure Bluetooth is enabled and the headphones are connected to your device. Update the Baseus App to the latest version.

7. SPECIFICATIONS

Feature	Specification
Model Number	Baseus Inspire XH1
Bluetooth Version	6.1
Full Charge Time	Approx. 1.5 hours
Charging Port	USB-C
Music Playback Time (ANC OFF)	Up to 100 hours
Music Playback Time (ANC ON)	Up to 65 hours
Impedance	16 ohm
Audio Driver Type	Dynamic Driver
Audio Driver Size	35 millimeters
Frequency Range	20Hz - 40kHz
Noise Control	Active Noise Cancellation
Enclosure Material	Leather, Foam, Plastic/Silicone



What's in the Box

- Inspire XH1
- Aux Cable
- USB-C Cable
- Carrying Case

Image: Product dimensions of the Baseus Inspire XH1 headphones.

8. WARRANTY AND SUPPORT

The Baseus Inspire XH1 headphones come with a **2-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product meets its specified performance standards under normal use. For warranty claims, technical support, or further assistance, please contact Baseus customer service through their official website or the contact information provided with your purchase documentation. Please retain your proof of purchase for warranty validation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question